Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Olympia OE-700

Olympia OE-700 Rice Cooker Instruction Manual

Model: OE-700

Introduction

Thank you for purchasing the Olympia OE-700 Rice Cooker. This appliance is designed to cook rice perfectly and efficiently. Please read this instruction manual carefully before using the appliance to ensure safe operation and optimal performance. Keep this manual for future reference.

Important Safety Instructions

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the rice cooker body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The Olympia OE-700 Rice Cooker consists of several key components designed for ease of use and efficient cooking.

- Main Unit (Rice Cooker Body)
- Removable Inner Pot

- Glass Lid
- Steamer Basket (for steaming vegetables, etc.)
- Rice Paddle
- Measuring Cup



Figure 1: The Olympia OE-700 Rice Cooker with its steamer basket and rice paddle, showcasing its compact design and floral pattern.



Figure 2: The rice cooker shown with the included measuring cup and rice paddle, essential accessories for accurate cooking.



Figure 3: The rice cooker with its lid and steamer basket detached, illustrating the removable components for easy cleaning and versatile use.

Setup

1. Unpack all components and remove any packaging materials.
2. Wash the inner pot, glass lid, rice paddle, measuring cup, and steamer basket with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. Place the rice cooker on a stable, flat, heat-resistant surface, away from walls or cabinets to allow for proper ventilation.

Operating Instructions

Cooking Rice

1. Measure the desired amount of rice using the provided measuring cup. One cup of uncooked rice typically yields about 2-3 cups of cooked rice.
2. Rinse the rice thoroughly under cold water until the water runs clear. This helps remove excess starch.
3. Place the rinsed rice into the removable inner pot.
4. Add the appropriate amount of water. A general guideline is 1.5 to 2 cups of water for every 1 cup of rice, but this may vary depending on the type of rice and desired consistency. Refer to the water level markings inside the inner pot if available.
5. Place the inner pot into the main unit, ensuring it is seated properly.
6. Cover the inner pot with the glass lid.
7. Plug the power cord into a standard electrical outlet. The 'Warm' indicator light may illuminate.
8. Press the 'Cook' switch down. The 'Cook' indicator light will illuminate, indicating that cooking has started.
9. Once the rice is cooked, the 'Cook' switch will automatically flip up, and the rice cooker will switch to 'Warm' mode. The 'Warm' indicator light will illuminate.
10. Allow the rice to rest in 'Warm' mode for 5-10 minutes after cooking for best results.
11. Unplug the rice cooker from the outlet when serving is complete.

Steaming Food

1. Add water to the inner pot (ensure water level is below the steamer basket).
2. Place the food to be steamed into the steamer basket.
3. Place the steamer basket into the inner pot.
4. Cover with the glass lid.
5. Press the 'Cook' switch down to start steaming.
6. Monitor the food and turn off the cooker manually by unplugging it once steaming is complete, or allow it to switch to 'Warm' mode if cooking rice simultaneously.

Maintenance and Cleaning

Regular cleaning will ensure the longevity and optimal performance of your rice cooker.

1. Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot, Lid, Steamer Basket, Rice Paddle, and Measuring Cup:**These parts are removable and should be washed by hand with warm, soapy water. Rinse thoroughly and dry completely before storing or next use. Do not

use abrasive cleaners or metal scouring pads, as they may damage the non-stick coating of the inner pot.

3. **Main Unit (Exterior):** Wipe the exterior of the rice cooker body with a soft, damp cloth. Do not immerse the main unit in water or any other liquid. Ensure no water enters the electrical components.
4. **Heating Plate:** If any rice or debris sticks to the heating plate, gently wipe it clean with a damp cloth. Do not use harsh abrasives or sharp objects that could scratch the surface.
5. **Condensation Collector (if applicable):** Some models have a condensation collector. Empty and clean it regularly.

Troubleshooting

Problem	Possible Cause	Solution
Rice is too hard/undercooked	Not enough water; rice not soaked (if required); power interruption.	Add more water next time; ensure proper water-to-rice ratio; check power connection.
Rice is too soft/mushy	Too much water.	Reduce water next time; ensure proper water-to-rice ratio.
Rice sticks to the bottom of the pot	Not enough water; inner pot not properly cleaned; prolonged 'Warm' cycle.	Ensure proper water-to-rice ratio; clean inner pot thoroughly; do not leave on 'Warm' for excessive periods.
Cooker does not turn on	Not plugged in; power outage; faulty outlet.	Check power cord connection; test outlet with another appliance; check circuit breaker.
Steam escaping from lid during cooking	Lid not properly seated; lid seal damaged.	Ensure lid is securely placed; inspect lid and replace if damaged.

Specifications

Brand	Olympia
Model Number	OE-700
Color	White
Capacity	1.8 Liters
Power	500 Watts
Material	Mixed
Item Weight	1.98 Kilograms
Product Dimensions	29 x 27 x 26.2 cm
Power Source	Corded Electric
Care Instructions	Hand Wash
Included Components	Instruction Manual

Warranty and Support

This Olympia OE-700 Rice Cooker comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical support, service, or warranty claims, please contact Olympia customer service through the contact information provided on your product packaging or the official Olympia website. Please have your model number (OE-700) and proof of purchase ready when contacting support.

© 2024 Olympia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07P9NFLPS

More documents and user manuals: **https://manuals.plus/**