Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GMO1898

Geepas GMO1898 Microwave Oven User Manual

Model: GMO1898 | 45 Liters | 1000W

1. Introduction

Thank you for purchasing the Geepas GMO1898 Microwave Oven. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read these instructions thoroughly before use and retain them for future reference.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy, observe the following basic precautions:

- Read all instructions before using the appliance.
- Read and follow the specific “PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY” found in this manual.
- This appliance must be grounded. Connect only to a properly grounded outlet. See “GROUNDING INSTRUCTIONS” in this section.
- Install or locate this appliance only in accordance with the provided installation instructions.
- Do not heat whole eggs or sealed containers, as they may explode.
- Use this appliance only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this appliance.
- Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
- Do not immerse cord or plug in water.
- Keep cord away from heated surfaces.
- Do not let cord hang over edge of table or counter.
- To reduce the risk of fire in the oven cavity: Do not overcook food. Carefully attend appliance when paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking. Remove wire twist-ties from paper or plastic bags before placing bags in oven. If materials inside the oven should ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
- Liquids such as water, coffee, or tea can be overheated beyond the boiling point without appearing to boil. This

can result in very hot liquids suddenly boiling over when a spoon or other utensil is inserted into the liquid.

- Always ensure the turntable and roller ring are correctly positioned before operating the microwave.

3. Product Overview

The Geepas GMO1898 is a 45-liter countertop microwave oven designed for efficient cooking and reheating. It features touch controls, multiple power levels, and a child safety lock.

Components

- Microwave Oven Unit
- Glass Turntable
- Roller Ring
- Instruction Manual



Figure 3.1: Front view of the Geepas GMO1898 Microwave Oven, showcasing its sleek design and control panel.



Figure 3.2: The microwave oven positioned on a kitchen counter, illustrating its compact footprint for a 45-liter capacity.



Figure 3.3: The microwave oven with its door open, revealing the spacious 45-liter interior and glass turntable.



Figure 3.4: A closer look at the interior of the microwave, highlighting the clean design and removable glass turntable for easy cleaning.

Control Panel

The control panel features a digital display and touch-sensitive buttons for various functions, including power level, time

setting, and pre-programmed menus.



Figure 3.5: A hand interacting with the touch control panel, demonstrating the ease of setting power levels and cooking times.

4. Setup

Unpacking

1. Remove all packaging materials from inside and outside the microwave oven.
2. Check the oven for any damage, such as dents or a misaligned door. Do not operate the oven if it is damaged.
3. Ensure all accessories, including the glass turntable and roller ring, are present.

Placement

- Place the microwave oven on a flat, stable surface that can support its weight and the heaviest food item likely to be cooked in it.
- Ensure adequate ventilation. Leave a minimum of 20 cm (8 inches) of space above the oven, 10 cm (4 inches) at

the rear, and 5 cm (2 inches) on each side.

- Do not block air vents.
- Keep the oven away from heat sources and strong magnetic fields.

Electrical Connection

- Plug the power cord into a standard 220-240V, 50/60Hz grounded electrical outlet.
- Do not use extension cords or adapters.

5. Operating Instructions

Basic Operation

1. Place food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. Press the 'Power Level' button to select the desired power (e.g., P100 for 100% power). The GMO1898 offers 10 power levels.
4. Use the '10 Minute', '1 Minute', and '10 Second' buttons to set the cooking time.
5. Press the 'Start' button to begin cooking.

Using Pre-programmed Cooking Menus

The microwave includes several pre-programmed menus for common food items. Refer to the detailed instructions on the control panel or the full manual for specific menu options.



Figure 5.1: A cake being cooked inside the microwave, illustrating the use of pre-programmed cooking menus for various dishes.

Child Safety Lock

To prevent unintended operation, especially by children, the microwave is equipped with a child safety lock function.



Figure 5.2: A hand closing the microwave door, emphasizing the child safety lock feature that prevents accidental operation.

- **To activate:** Press and hold the 'Cancel' button for 3 seconds. A lock indicator will appear on the display.
- **To deactivate:** Press and hold the 'Cancel' button for 3 seconds again. The lock indicator will disappear.

6. Maintenance and Cleaning

Regular cleaning helps maintain the performance and longevity of your microwave oven.

- **Interior:** Wipe the interior cavity with a damp cloth after each use. For stubborn stains, use a mild detergent. Do not use abrasive cleaners or scouring pads.
- **Exterior:** Clean the exterior surfaces with a soft, damp cloth. Avoid getting water into the ventilation openings.
- **Door and Door Seals:** Keep the door and door seals clean to ensure proper closure.
- **Turntable and Roller Ring:** The glass turntable and roller ring can be removed and washed in warm soapy water or in a dishwasher. Ensure they are dry before placing them back in the oven.
- **Odor Removal:** To remove odors, combine a cup of water with the juice of one lemon in a microwave-safe bowl.

Microwave on high for 5 minutes, then let it sit in the oven for another 5 minutes before wiping the interior.

7. Troubleshooting

If you encounter issues with your microwave oven, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped; Child lock activated.	Ensure plug is firmly in outlet; Close door securely; Check household fuse/circuit breaker; Deactivate child lock.
Food not heating	Door not closed properly; Cooking time/power level set incorrectly; Food container not microwave-safe.	Close door securely; Adjust time/power; Use microwave-safe cookware.
Turntable not rotating	Turntable or roller ring not positioned correctly; Debris under turntable.	Reposition turntable and roller ring; Clean under the turntable.
Sparking inside oven	Metal in oven; Food residue.	Remove any metal objects; Clean oven interior thoroughly.

If the problem persists after attempting these solutions, please contact Geepas customer support.

8. Specifications

Feature	Specification
Brand	Geepas
Model Number	GMO1898
Capacity	45 Liters
Microwave Output Power	1000 Watts
Power Levels	10
Control Type	Touch Control
Installation Type	Countertop
Material	Stainless Steel
Special Features	Child Safety Lock
Exterior Dimensions (H x W x D)	31.1 x 55.3 x 48.2 cm
Item Weight	11.7 Kilograms
Voltage/Frequency	AC 220-240V ~ 50/60Hz

9. Warranty and Support

The Geepas GMO1898 Microwave Oven comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage. For technical support, service, or inquiries, please contact Geepas customer service through their official website or the contact information provided in your warranty documentation.



Figure 9.1: The cover of the Geepas Digital Microwave Oven manual, displaying key features and specifications.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PF687TW

More documents and user manuals: **https://manuals.plus/**