Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GIC6101

Geepas Infrared Cooker GIC6101 User Manual

Model: GIC6101

1. Introduction

Thank you for purchasing the Geepas Infrared Cooker GIC6101. This appliance is designed for efficient and versatile cooking, featuring a ceramic heating element and touch controls. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is equipped with overheat protection and overcurrent/high/low voltage protection.
- Ensure the appliance is placed on a stable, heat-resistant surface.

3. Product Overview

The Geepas Infrared Cooker GIC6101 is a versatile tabletop cooking appliance. It features a durable ceramic heating surface and an intuitive touch control panel.

Components

- Ceramic Heating Plate
- Touch Control Panel
- 4-Digit LED Display
- Power Cord



Image: The Geepas Infrared Cooker GIC6101, showcasing its sleek design and control panel.

Control Panel

The control panel features various buttons for different cooking functions and settings:

- **ON/OFF:** Powers the unit on or off.
- **+:** Increases power level or timer duration.
- **-:** Decreases power level or timer duration.
- **Timer:** Activates and adjusts the cooking timer (up to 120 minutes).
- **Pause:** Temporarily stops the cooking process.
- **Preset Functions:** Hot Pot, Fry, Stir-Fry, BBQ, Soup, Water, Warm, High Temp.



Image: A detailed view of the touch control panel and LED display on the Geepas Infrared Cooker GIC6101.

4. Setup

Before first use, ensure the cooker is properly set up.

1. **Unpacking:** Carefully remove the cooker from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the infrared cooker on a flat, stable, and heat-resistant surface. Ensure there is adequate ventilation around the unit (at least 10-15 cm clearance from walls or other objects).
3. **Power Connection:** Plug the power cord into a grounded electrical outlet (220-240V, 50/60Hz).
4. **Cookware:** This infrared cooker is suitable for all types of cookware, including stainless steel, cast iron, ceramic, and glass. Ensure the base of the cookware is flat and covers the heating zone adequately.



Image: The Geepas Infrared Cooker GIC6101 positioned on a kitchen counter, surrounded by fresh ingredients, indicating readiness for cooking.

5. Operating Instructions

Follow these steps to operate your Geepas Infrared Cooker:

1. **Power On:** Place your desired cookware with food on the ceramic heating plate. Press the **ON/OFF** button to turn on the cooker. The LED display will illuminate.
2. **Select Function/Power:**
    - **Manual Adjustment:** Use the **+** and **-** buttons to adjust the power level. The cooker offers 10 power levels for precise control.
    - **Preset Functions:** Select a specific cooking mode by pressing one of the preset function buttons (e.g., Hot Pot, Fry, Stir-Fry, BBQ, Soup, Water, Warm, High Temp). The cooker will automatically adjust to an appropriate power level for that function.
3. **Set Timer (Optional):** Press the **Timer** button, then use the **+** and **-** buttons to set the desired cooking time, up to

120 minutes. The cooker will automatically turn off when the timer expires.

4. **Cooking:** The cooker will begin heating. The ceramic plate will glow red during operation.
5. **Pause Function:** During cooking, you can press the **Pause** button to temporarily stop the heating process without turning off the unit. Press it again to resume.
6. **Power Off:** Once cooking is complete, press the **ON/OFF** button to turn off the cooker. The display will turn off, and the fan may continue to run for a short period to cool down the unit.



Image: A hand interacting with the control panel of the Geepas Infrared Cooker GIC6101 while a pot of food is cooking.



Image: The Geepas Infrared Cooker GIC6101 actively heating a pot of food, demonstrating its cooking capability.

6. Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your infrared cooker.

- **Cleaning the Ceramic Plate:** After the cooker has completely cooled down and is unplugged, wipe the ceramic surface with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic cooktops. Do not use abrasive pads or harsh chemicals.
- **Cleaning the Body:** Wipe the exterior body with a soft, damp cloth. Do not immerse the cooker in water or any other liquid.
- **Ventilation:** Ensure the ventilation openings on the underside and sides of the cooker are free from dust and debris to prevent overheating.
- **Storage:** Store the cooker in a dry place when not in use.

7. Troubleshooting

If you encounter issues with your Geepas Infrared Cooker, refer to the following table:

Problem	Possible Cause	Solution
Cooker does not turn on.	No power supply; Power cord not properly plugged in.	Check power outlet; Ensure power cord is securely plugged in.
Cooker not heating.	Incorrect power level selected; Overheat protection activated.	Increase power level; Allow cooker to cool down if it was recently used.
Display shows an error code.	Internal malfunction; Voltage fluctuation.	Unplug the unit, wait a few minutes, then plug it back in. If the error persists, contact customer support.
Fan continues to run after turning off.	Normal cooling process.	This is normal. The fan will stop automatically once the unit has cooled sufficiently.

8. Specifications

Feature	Specification
Brand	Geepas
Model Number	GIC6101
Type	Infrared Cooker (Radiant Cooktop)
Power	2000W (Max 2200W as per product description)
Voltage	220-240V AC, 50/60Hz
Material	Ceramic
Control Type	Touch
Heating Elements	1
Power Levels	10
Timer Function	Up to 120 minutes
Dimensions (H x W x D)	8.8 cm x 40 cm x 31.8 cm (approx.)
Weight	1.9 kg
Special Features	Overheat Protection, Overcurrent/High/Low Voltage Protection, No Electromagnetic Radiation



Image: Product packaging for the Geepas Digital Infrared Cooker GIC6101N, highlighting 2000W power, 4-digit LED display, and 10 power levels.

9. Warranty and Support

Your Geepas Infrared Cooker GIC6101 comes with a**2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.
For technical support, service, or warranty inquiries, please contact Geepas customer service through their official website or the retailer where the product was purchased.
UPC: 6294010889869

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question