Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sandoo HA1487

Sandoo 1400W Tabletop IH Cooker User Manual

Model: HA1487

1. Important Safety Information

Please read all safety instructions carefully before using the appliance.

General Safety Precautions

- Do not touch the cooking surface immediately after use; it remains hot and can cause burns.
- Do not place aluminum foil or metal objects on the cooking surface, as this may cause fire or injury.
- Ensure proper ventilation during use.
- Keep out of reach of children.

Product Specific Warnings



Image: Top view of the Sandoo IH Cooker. Note the warning labels on the top left, indicating high temperature and caution against touching the hot surface. The control panel is visible at the bottom.

- The top plate becomes hot during and after use. Do not touch it directly.
- Do not place aluminum foil or metal objects on the cooking surface.
- Do not use with pots smaller than 12cm or larger than 24cm in diameter.
- If the pot is empty or contains very little liquid, the temperature may rise rapidly, leading to fire.

2. Product Overview

Parts and Features

The Sandoo IH Cooker HA1487 is a compact and efficient tabletop induction cooker designed for various cooking needs.



Image: The Sandoo IH Cooker shown on a kitchen counter, highlighting its compact design suitable for small spaces. It is designed to fit easily into limited kitchen areas.

- **Compact Size:** Designed to fit easily in narrow spaces and limited kitchen areas.
- **Control Panel:** Intuitive interface for power, heat adjustment, timer, and cooking modes.
- **Magnetic Plug:** For enhanced safety and easy connection/disconnection.
- **Glass Surface:** Easy to clean and maintain.

3. Setup

1. **Unpacking:** Carefully remove the IH cooker from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the cooker on a stable, flat, heat-resistant surface. Ensure there is adequate ventilation around

the unit (at least 10 cm clearance from walls or other appliances).

3. **Power Connection:** Insert the magnetic power plug firmly into the cooker's power port, then plug the other end into a standard electrical outlet. Ensure the outlet voltage matches the cooker's requirements (100V for Japan).
4. **Initial Cleaning:** Before first use, wipe the glass surface with a soft, damp cloth.

4. Operating Instructions

Basic Operation



Image: A user interacting with the control panel of the Sandoo IH Cooker, showing its ease of use. The image also highlights the smooth glass panel design, which simplifies cleaning.

1. **Power On:** Press the " / " (Power On/Off) button to turn on the appliance. The display will light up.
2. **Place Cookware:** Place an IH-compatible pot or pan centrally on the cooking surface.
3. **Select Mode:** Choose your desired cooking mode:
    - **Heat Adjustment ( ):** For general cooking.
    - **Deep-fry Mode ( ):** For frying.

- **Keep Warm ( ):** To maintain food temperature.
- **Simmer ( ):** For slow cooking.
- **Heating ( ):** For quick heating.

4. **Adjust Settings:** Use the " " (decrease) and " " (increase) buttons to adjust heat level or temperature.
5. **Set Timer (Optional):** Press the " " (Timer) button and use the adjustment buttons to set the desired cooking time. Press " " (Cancel) to clear the timer.
6. **Power Off:** After cooking, press the " / " (Power On/Off) button to turn off the appliance. Unplug the power cord when not in use.

Heat Adjustment ( )

This mode allows for precise control over the cooking power.



Image: The control panel of the Sandoo IH Cooker, illustrating the 7 levels of heat adjustment (200W to 1400W) and 6 levels of temperature adjustment (150°C to 200°C). Examples of dishes suitable for different settings are shown above the panel.

- The cooker offers 7 levels of heat adjustment, from 200W to 1400W.
- Use the " " and " " buttons to cycle through the power levels.

Deep-fry Mode ( )

This mode is specifically designed for deep-frying, offering stable temperature control.

- The cooker provides 6 temperature settings for deep-frying, ranging from 150°C to 200°C.
- Select this mode and adjust the temperature using the " " and " " buttons.
- *Note:* The actual temperature may differ slightly from the displayed temperature (approximately 10°C difference).

5. Safety Functions

The Sandoo IH Cooker is equipped with 8 safety functions to ensure safe operation.



Image: A visual representation of the eight safety features integrated into the Sandoo IH Cooker. These include automatic power-off, pot sensor function, no-pot shut-off, small object detection, abnormal temperature rise prevention, short circuit protection, abnormal voltage warning, and lightning surge protection.

- **Automatic Power-Off (OFF):** Automatically turns off if left unattended for a long period.
- **Pot Sensor Function ( ):** Detects if a suitable pot is placed on the cooking surface.
- **No-Pot Shut-Off (OFF):** Turns off if no pot is detected.
- **Small Object Heat Prevention ( ):** Prevents heating of small, non-cookware objects.

- **Abnormal Temperature Rise Prevention ( ):** Shuts off if the temperature exceeds safe limits.
- **Short Circuit Protection ( ):** Protects against electrical short circuits.
- **Abnormal Voltage Warning ( ):** Alerts to unstable voltage.
- **Lightning Surge Protection ( ):** Protects against power surges from lightning.

Child Lock

- To activate the child lock, press and hold the " " (Lock) button for 2 seconds.
- To deactivate, press and hold the " " (Unlock) button for 2 seconds.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your IH cooker.

1. **Before Cleaning:** Always unplug the cooker and allow it to cool completely before cleaning.
2. **Glass Surface:** Wipe the glass surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic or glass cooktops. Dry thoroughly with a clean cloth.
3. **Control Panel:** Wipe the control panel with a soft, dry or slightly damp cloth. Do not use excessive water.
4. **Ventilation Openings:** Ensure the ventilation openings on the bottom and sides of the cooker are free from dust and debris. Use a soft brush or vacuum cleaner to clear them if necessary.
5. **Storage:** Store the cooker in a dry place when not in use.

7. Troubleshooting

If you encounter issues with your Sandoo IH Cooker, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in correctly; power outage; faulty outlet.	Check power cord connection; check household circuit breaker; try a different outlet.
Cookware not heating.	Cookware is not IH-compatible; cookware is too small/large; pot not centered.	Use IH-compatible cookware; ensure pot diameter is between 12cm and 24cm; center the pot on the cooking zone.
Error code displayed.	Refer to the specific error code in the full manual (if available) or contact customer support.	Unplug the unit, wait a few minutes, then plug it back in. If the error persists, contact Sandoo customer support.
Fan noise is loud.	Normal operation for cooling; ventilation blocked.	Ensure adequate ventilation around the unit. This is often normal during high power operation.

8. Specifications

Feature	Detail
Model	HA1487
Brand	Sandoo

Feature	Detail
Power	1400W
Heat Adjustment	7 levels
Deep-fry Temperature	6 levels (150°C - 200°C)
Dimensions (Product)	34.5 cm (W) x 27.6 cm (D) x 5.7 cm (H)
Material	Glass
Color	Black
UPC	798542282861

9. Warranty and Support

Sandoo provides an 18-month maintenance period for this product.



Image: Documents indicating quality management and certification, including a Certificate of Insurance and a TUV Rheinland test report, demonstrating Sandoo's commitment to product quality and safety standards.

For warranty claims, technical support, or any inquiries, please contact Sandoo customer service. Refer to your purchase documentation for specific contact details.

- **Maintenance Period:** 18 months from the date of purchase.
- **Customer Support:** Please visit the official Sandoo website or refer to the contact information provided with your product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PHQMNGK

More documents and user manuals: **https://manuals.plus/**