Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

All-Clad 11644005450

All-Clad Stainless Steel Electric Slow Cooker 7-Quart Instruction Manual

Brand: All-Clad | **Model:** 11644005450

Product Overview

This All-Clad Stainless Steel Electric Slow Cooker offers a generous 7-quart capacity, ideal for preparing meals for families and gatherings. It features a durable stainless steel exterior and a removable cast aluminum insert with a nonstick ceramic coating, allowing for versatile cooking directly on the cooktop or in the oven before slow cooking. The programmable LCD screen provides intuitive control over cooking times and modes, including automatic keep-warm functionality.

Key Features:

- **Family-Sized Capacity:** 7-quart capacity suitable for large meals.
- **4 Preset Modes:** Low, High, High/Low slow cooking, and automatic keep-warm for up to 6 hours.
- **Multi-Functional Insert:** Removable cast aluminum insert with nonstick ceramic coating, safe for cooktop, oven, and serving.
- **Intuitive LCD Screen:** Digital display for monitoring cooking mode and time.
- **Convenient Design:** Stainless-steel lid to maintain heat and moisture, easy-to-grip handles, and sleek silver finish.



Figure 1: All-Clad 7-Quart Stainless Steel Electric Slow Cooker with LCD display.

Setup and First Use

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the removable aluminum insert and the stainless steel lid with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the slow cooker base with a damp cloth. Do not immerse the base in water.
3. **Placement:** Place the slow cooker base on a flat, stable, heat-resistant surface, away from walls or heat-sensitive materials. Ensure adequate ventilation around the unit.
4. **Insert Placement:** Carefully place the cleaned aluminum insert into the slow cooker base. Ensure it is seated properly.



Figure 2: Proper placement of the aluminum cooking insert into the slow cooker base.

Operating Instructions

The All-Clad Slow Cooker features an intuitive LCD screen and controls for easy operation.

Control Panel Overview:

- **Power Button:** Turns the unit on/off.
- **SET Button:** Used to confirm selections or cycle through settings.
- **UP/DOWN Buttons:** Adjust cooking time or temperature.
- **START Button:** Initiates the cooking cycle.
- **COOK Indicator:** Illuminates when the unit is actively cooking.
- **WARM Indicator:** Illuminates when the unit is in Keep Warm mode.

Cooking Modes:

1. **Slow Cook (Low, High, High/Low):**
    - Press the Power button to turn on.
    - Use the SET button to select your desired slow cook mode (Low, High, or High/Low).
    - Use the UP/DOWN buttons to set the cooking time (up to 20 hours).
    - Press START to begin slow cooking. The COOK indicator will light up.

2. **Automatic Keep Warm:**

   After the set slow cooking time is complete, the unit will automatically switch to Keep Warm mode for up to 6 additional hours. The WARM indicator will light up.

3. **Using the Aluminum Insert for Searing/Browning:**

   The removable cast aluminum insert can be used directly on your cooktop (gas or electric) or in the oven for searing meats or sautéing vegetables before slow cooking. This reduces the need for additional pans and simplifies meal preparation.



Figure 3: The versatile aluminum insert can be used on the stovetop for searing or browning ingredients.

Maintenance and Cleaning

Proper care ensures the longevity and performance of your All-Clad Slow Cooker.

- **Removable Insert and Lid:** The cast aluminum insert with ceramic coating and the stainless steel lid are dishwasher-safe for easy cleanup. For best results and to preserve the nonstick coating, hand washing with warm, soapy water is recommended. Avoid abrasive cleaners or scouring pads.
- **Slow Cooker Base:** The exterior of the main unit should be wiped clean with a damp cloth. Do not immerse the electrical base in water or any other liquid.
- **Storage:** Ensure all parts are completely dry before storing. Store in a cool, dry place.

Troubleshooting

If you encounter any issues with your slow cooker, please refer to the following common solutions:

- **Unit Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the power button has been pressed.
- **Food Not Cooking Properly:** Verify that the correct cooking mode (Low, High, High/Low) and time have been selected. Ensure the lid is properly seated to retain heat and moisture. Avoid frequently lifting the lid, as this can extend cooking times.
- **Food Sticking to Insert:** Although the insert has a nonstick ceramic coating, using a small amount of cooking oil or spray can further prevent sticking, especially with certain ingredients.
- **Lid Condensation:** It is normal for condensation to form on the underside of the lid during cooking. This helps to keep food moist.

For issues not covered here, please contact All-Clad customer support.

Specifications

Feature	Detail
Brand	All-Clad
Model Number	11644005450
Capacity	7 Quarts
Material	Stainless Steel (exterior), Aluminum with Ceramic Coating (insert)
Color	Silver
Product Dimensions	14.2"D x 19.9"W x 11.3"H
Item Weight	16.27 pounds
Wattage	320 Watts
Voltage	120.0 Volts
Control Type	Programmable LCD with Push Button Controls
Dishwasher Safe (Insert/Lid)	Yes



Figure 4: Product dimensions for the All-Clad 7-Quart Slow Cooker.

Warranty and Support

All-Clad products are designed for durability and performance. For specific warranty information and customer support, please refer to the documentation included with your product or visit the official All-Clad website.
For further assistance, you may also contact All-Clad customer service directly.

© 2025 All-Clad. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my All-Clad 11644005450 slow cooker beep and not heat?

The provided manual for the All-Clad 11644005450 slow cooker does not specifically mention beeping as a troubleshooting issue. However, if your slow cooker is not heating, here are some general troubleshooting steps based on...

Read full answer

Open the live page

https://manuals.plus/asin/B07PJH6LPX

More documents and user manuals: **https://manuals.plus/**