Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 Multi-model compatible (MP7640i, MP7740, MP8649, MP8748, MP8749, MP8765)

User Manual: Easytry123 Replacement Remote Control

Model Compatibility: 3M MP7640i, MP7640iA, S40, MP7740, MP7740i, X40, X40I, MP7740IA, MP8649, MP8748, MP8749, MP8765 3LCD Projectors

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Easytry123 replacement remote control. This remote is designed to function as a replacement for various 3M 3LCD Projector models. Please read this manual thoroughly before use to ensure optimal performance and to understand the capabilities and limitations of this replacement unit.

2. Compatible Models

This replacement remote control is compatible with the following 3M 3LCD Projector models:

- 3M MP7640i
- 3M MP7640iA
- 3M S40
- 3M MP7740
- 3M MP7740i
- 3M X40
- 3M X40I
- 3M MP7740IA
- 3M MP8649
- 3M MP8748
- 3M MP8749
- 3M MP8765

Important Note: *As a replacement unit, this remote may not support all functions or features of the original projector remote control. Functionality is primarily based on the projector's infrared receiver capabilities. Please ensure your projector model is listed above for compatibility.*

3. Product Overview

Familiarize yourself with the layout and functions of your new remote control.



Figure 3.1: Front view of the remote control. This image displays the entire front surface of the remote, highlighting the arrangement of various control buttons such as power, source selection, volume, navigation, and specific projector functions like keystone and focus.



Figure 3.2: Rear view of the remote control with the battery compartment open. This image illustrates the location of the battery compartment and the two slots for AA batteries, indicating the required battery type and orientation.



Figure 3.3: Rear view of the remote control with the battery compartment closed. This image shows the sleek, ergonomic design of the remote's back, with the battery cover securely in place.

The remote features standard buttons for projector control, including power, source selection, volume adjustment, menu navigation, and specific projector functions like keystone correction and focus.

4. Setup: Battery Installation

The remote control requires two (2) AA batteries for operation. Batteries are not included with the remote.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it. (Refer to Figure 3.2)
3. Insert two (2) AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: *Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.*

5. Operating Instructions

To operate your projector using the Easytry123 replacement remote control, point the remote directly at the projector's infrared (IR) receiver. Ensure there are no obstructions between the remote and the projector.

- **Power On/Off:** Press the **Power** button (often red or clearly marked with a power symbol) to turn the projector on or off.
- **Source Selection:** Use the **SOURCE** or **INPUT** button to cycle through available input sources (e.g., HDMI, VGA, USB).
- **Volume Control:** Adjust the audio output using the **VOLUME +** and **VOLUME -** buttons.
- **Menu Navigation:** Use the directional arrow buttons (**UP, DOWN, LEFT, RIGHT**) to navigate through the projector's on-screen menu. Press **ENTER** or **OK** to confirm selections.
- **Keystone Correction:** Use the **KEYSTONE** buttons to adjust the image shape if it appears trapezoidal.
- **Focus Adjustment:** Use the **FOCUS** buttons to sharpen or blur the image.
- **Mute:** Press the **MUTE** button to temporarily silence the audio.
- **Blank:** The **BLANK** button may temporarily hide the projected image.
- **D-Zoom:** Use the **D-ZOOM** buttons for digital zoom functionality.

Specific button functions may vary slightly depending on your projector model. Refer to your projector's original manual for detailed function descriptions.

6. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the projector's IR receiver.
  - Verify you are within the effective range of the projector's IR receiver.
- **Some functions do not work:**
  - This is a replacement remote. As stated in the product description, it may not work with all functions as the original remote.
  - Ensure your projector model is listed in the compatibility section.
  - Some advanced or proprietary functions may not be supported by generic replacement remotes.

8. Specifications

Attribute	Detail
Brand	Easytry123
Compatible Devices	3M 3LCD Projectors (specific models listed in Section 2)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Special Feature	Ergonomic design
Batteries Required	2 x AA batteries (not included)
ASIN	B07PKLYG2D
Date First Available	March 11, 2019

9. Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the retailer or the original purchase documentation. For technical support or inquiries regarding compatibility, please contact the seller directly through the platform where the purchase was made.
For general information about the product, you may visit theproduct page on Amazon.

© 2024 Easytry123. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PKLYG2D

More documents and user manuals: **https://manuals.plus/**