Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RL800UNI

LEXiBOOK Unicorn Digital Alarm Clock RL800UNI Instruction Manual

Model: RL800UNI | Brand: LEXiBOOK

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your LEXiBOOK Unicorn Digital Alarm Clock (Model RL800UNI). This alarm clock features a digital display, a luminous unicorn night light, unicorn sound effects, and a snooze function, designed for ease of use.

2. Safety Information

- Recommended for ages 3 years and up.
- Keep batteries out of reach of small children.
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.
- Avoid exposing the device to extreme temperatures or direct sunlight.
- Do not immerse the device in water.

3. Package Contents

Please check that all items are present:

- 1 x LEXiBOOK Unicorn Digital Alarm Clock (Model RL800UNI)
- 1 x Instruction Manual

4. Product Overview

Familiarize yourself with the main components of your alarm clock:

- **Unicorn Figure:** Luminous figure on top, acts as night light and snooze/alarm stop button.
- **LCD Backlit Screen:** Displays time, alarm status, and other indicators.
- **Speaker Button (Left Front):** Activates unicorn sound effects.
- **Plus (+) and Minus (-) Buttons (Right Front):**Adjust time and alarm settings.

- **Alarm Set Button (Rear):** Used to set the alarm time.
- **Time Set Button (Rear):** Used to set the current time.
- **Battery Compartment (Rear Bottom):** Holds 3 x AA/LR6 batteries.



Figure 1: Front view of the LEXiBOOK Unicorn Digital Alarm Clock. The pink base features a digital display showing the time, with a speaker button on the left and plus/minus buttons on the right. A white unicorn figure with pink mane and blue horn sits atop the base.


LEXIBOOK
AM
12:39

Figure 2: Side view of the LEXiBOOK Unicorn Digital Alarm Clock, highlighting its compact design.

5. Battery Installation

The alarm clock requires 3 x AA/LR6 batteries (not included).

1. Locate the battery compartment on the bottom rear of the clock.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 3 new AA/LR6 batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

A low battery indicator will appear on the screen when batteries need replacement.

Figure 3: Rear view of the alarm clock with the battery compartment open, illustrating the correct placement of AA batteries.

6. Setup

6.1 Setting the Current Time

1. Press and hold the **Time Set** button located on the rear of the clock. The hour display will start flashing.
2. Use the **+** and **-** buttons on the front to adjust the hour.
3. Press the **Time Set** button again to confirm the hour and move to setting the minutes. The minute display will start flashing.
4. Use the **+** and **-** buttons to adjust the minutes.
5. Press the **Time Set** button one last time to confirm the minutes and exit time setting mode.

6.2 Setting the Alarm

1. Press and hold the **Alarm Set** button located on the rear of the clock. The alarm hour display will start flashing.
2. Use the **+** and **-** buttons on the front to adjust the alarm hour.
3. Press the **Alarm Set** button again to confirm the alarm hour and move to setting the alarm minutes. The alarm minute display will start flashing.
4. Use the **+** and **-** buttons to adjust the alarm minutes.
5. Press the **Alarm Set** button one last time to confirm the alarm minutes and exit alarm setting mode. The alarm icon will appear on the screen, indicating the alarm is active.

6.3 Adjusting Alarm Volume and Ringtones

While in alarm setting mode (after setting the minutes), you can adjust the volume and select ringtones:

- After setting the alarm minutes, press the **Alarm Set** button again. The current ringtone number will flash.
- Use the **+** and **-** buttons to cycle through the available unicorn-themed ringtones.
- Press the **Alarm Set** button again. The current volume level will flash.
- Use the **+** and **-** buttons to adjust the alarm volume.
- Press the **Alarm Set** button to save settings and exit.



Figure 4: The alarm clock display indicating the selection of unicorn ringtones.

7. Operation

7.1 Night Light Function

To activate the luminous unicorn night light, simply press down on the unicorn figure. The light will illuminate for a few minutes before automatically turning off. This function can also be activated by pressing the top of the clock.



Figure 5: The unicorn figure on the alarm clock glowing as a night light, providing soft illumination.

7.2 Snooze Function

When the alarm sounds, press down on the unicorn figure or the top of the clock to activate the snooze function. The alarm will temporarily stop and sound again after a short interval.

7.3 Stopping the Alarm

To completely stop the alarm, press down on the unicorn figure or the top of the clock for a longer duration, or press the **Alarm Set** button on the rear to deactivate the alarm for the day.

7.4 Unicorn Sound Effects

Press the **Speaker Button** on the front left of the clock to play various unicorn sound effects.

8. Features Overview

- **Luminous Unicorn:** The unicorn figure lights up, serving as a gentle night light.
- **Sleep-Friendly LCD Screen:** Backlit display ensures clear visibility without disturbing sleep.

- **Unicorn Sound Effects:** Engage with fun, themed sound effects.
- **Adjustable Alarm:** Customize alarm volume and choose from multiple unicorn-themed ringtones.
- **Easy Snooze/Stop:** Conveniently snooze or stop the alarm by pressing the top of the clock or unicorn.



Figure 6: Visual representation of the alarm clock's key features, including the luminous unicorn, backlit screen, unicorn ringtones, and

snooze function.



Figure 7: The alarm clock in a bedroom setting, showing a child waking up, demonstrating its intended use.



Figure 8: The alarm clock functioning as a night light in a child's room, promoting a comfortable sleep environment.

9. Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Battery Replacement:** Replace all 3 AA/LR6 batteries when the low battery indicator appears or when the

display dims.

- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

10. Troubleshooting

Problem	Possible Cause	Solution
Clock display is blank or dim.	Low or dead batteries.	Replace all 3 AA/LR6 batteries.
Alarm does not sound.	Alarm not set or volume too low.	Ensure alarm is set correctly and volume is adjusted. Check battery level.
Unicorn light does not turn on.	Low batteries or light function not activated correctly.	Replace batteries. Press firmly on the unicorn figure or top of the clock.
Incorrect time display.	Time not set correctly.	Follow instructions in Section 6.1 to reset the time.

11. Specifications

Feature	Detail
Brand	LEXiBOOK
Model Number	RL800UNI
Display Type	Digital LCD
Power Source	3 x AA/LR6 Batteries (not included)
Material	Acrylonitrile Butadiene Styrene (Plastic)
Product Dimensions	3.54"W x 7.17"H (approx. 13.5 x 9 x 18.2 cm)
Special Features	Adjustable Volume, Alarm, Battery Indicator, Illuminated Unicorn, Snooze Function
Recommended Age	3 years and up

12. Official Product Video

Watch the official product video for a visual guide on the LEXiBOOK Unicorn Digital Alarm Clock's features and operation.

▶ **Watch video online**
Lexibook - Unicorn Digital Alarm Clock for kids RL800UNI

Video 1: Official demonstration of the LEXiBOOK Unicorn Digital Alarm Clock, showcasing its design, night light, and sound features.

13. Warranty and Support

For warranty information, technical support, or further inquiries, please visit the official LEXiBOOK website or contact their customer service department. Keep your purchase receipt as proof of purchase.
Manufacturer: LEXIBOOK

You can find more information on the LEXiBOOK Store Page.

© 2023 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07QJJP8YL

More documents and user manuals: **https://manuals.plus/**