Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FGET3066UF

Frigidaire FGET3066UF 30" Gallery Series Double Electric Wall Oven

Instruction Manual

1. Introduction

Welcome to the user manual for your new Frigidaire FGET3066UF 30" Gallery Series Double Electric Wall Oven. This appliance is designed to provide exceptional cooking performance and convenience with its advanced features and spacious capacity. Please read this manual thoroughly before operating your oven to ensure safe and efficient use.



Figure 1: Front view of the Frigidaire FGET3066UF Double Electric Wall Oven.

2. Key Features

- **True Convection:** Ensures even cooking results by circulating hot air throughout the oven cavity.
- **Effortless Temperature Probe:** Monitors the internal temperature of food for precise cooking.
- **Quick Preheat:** Rapidly heats the oven to the desired temperature, saving time.
- **Vari-Broil Temperature Control:** Offers adjustable broiling temperatures for customized cooking.
- **Air Fry:** Provides a healthier way to prepare crispy foods with little to no oil.

- **Self Clean & Steam Clean:** Multiple cleaning options for convenient maintenance.
- **Delay Start:** Allows you to program the oven to begin cooking at a later time.
- **Bread Proof:** Creates the ideal environment for proofing dough.



Figure 2: Oven interior demonstrating cooking capacity with multiple dishes.



Figure 3: Multiple racks allow for baking large quantities, such as several trays of cookies simultaneously.

3. Setup

Proper installation is crucial for the safe and optimal performance of your double wall oven. It is highly recommended that installation be performed by a qualified installer or service technician.

3.1. Pre-Installation Checklist

- Ensure the electrical supply meets the requirements specified in theSpecifications section.
- Verify cabinet dimensions are appropriate for a 30-inch double wall oven.

- Remove all packaging materials, tape, and protective film from the oven before installation.

3.2. Initial Use

Before first use, clean the oven interior with warm, soapy water. It is normal for a new oven to emit a slight odor and smoke during its first few uses as manufacturing oils burn off. Run the oven on a high temperature (e.g., 350°F) for approximately 30 minutes to an hour with good ventilation to dissipate these odors.



Figure 4: The double wall oven seamlessly integrated into kitchen cabinetry.

4. Operating Instructions

Your Frigidaire double oven features intuitive controls for both the upper and lower oven cavities. The control panel allows you to select various cooking modes, set temperatures, and manage timers.

4.1. Control Panel Overview

The digital control panel is located above the upper oven door. It features touch-sensitive buttons for mode selection, temperature adjustment, and timer functions. The display shows the current time, temperature, and active settings.



Figure 5: Detailed view of the oven's digital control panel.



Figure 6: Angled perspective of the control panel, highlighting its sleek design.

4.2. Setting a Cooking Mode

1. Press the desired cooking mode button (e.g.,**Bake**, **Broil**, **Conv Bake**, **Air Fry**).
2. Use the numeric keypad to enter the desired temperature.
3. Press **OK/START** to begin cooking.

4.3. Using the Timer

The timer can be set independently of cooking functions. Press the**Timer On-Off** button and use the numeric keypad to set the desired time. Press **OK/START** to begin the countdown. You can also use the**Add 1 Minute** button for quick adjustments.

4.4. Oven Racks

Each oven cavity is equipped with multiple racks that can be adjusted to different positions to accommodate various dish sizes. Some models feature gliding racks for easier access to food.



Figure 7: The oven interior with doors open, showcasing the adjustable rack positions.

5. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life and efficiency of your Frigidaire oven.

5.1. Self Clean Cycle

The Self Clean cycle uses high temperatures to burn off food residue, turning it into ash that can be easily wiped away. Ensure the oven is empty and the door is securely latched before starting the cycle. Follow the instructions on the control panel for selecting the appropriate cleaning duration.

5.2. Steam Clean Cycle

For lighter soils, the Steam Clean cycle uses water and low heat to loosen grime. Pour water into the oven cavity as instructed in the display, then activate the Steam Clean function. After the cycle, wipe away softened residue with a damp cloth.

5.3. Exterior Cleaning

Clean the stainless steel exterior with a soft cloth and a mild detergent or a specialized stainless steel cleaner. Avoid abrasive cleaners or scouring pads that can scratch the surface. The oven features a smudge-proof stainless steel finish for easier upkeep.

6. Troubleshooting

If you encounter issues with your oven, refer to the following common troubleshooting tips. For persistent problems, contact customer support.

Problem	Possible Cause	Solution
Oven not heating	Power supply issue; incorrect settings.	Check circuit breaker; ensure oven is plugged in; verify cooking mode and temperature settings.
Uneven cooking	Improper rack position; overloaded oven; convection fan issue.	Adjust rack position; avoid overcrowding; ensure convection fan is not obstructed.
Error Code F045	Indicates an issue with the cooling fan.	Turn off the oven and unplug it for a few minutes. If the error persists upon restarting, contact Frigidaire customer support for service.
Oven light not working	Bulb needs replacement.	Refer to the full user manual for instructions on replacing the oven light bulb.

7. Specifications

Feature	Detail
Brand	Frigidaire
Model Number	FGET3066UF
Product Dimensions	27.12 x 30 x 50.44 inches
Color	Smudge-Proof Stainless Steel
Finish Type	Stainless Steel
Installation Method	Wall Mount

Feature	Detail
Fuel Type	Electric
Heating Method	Convection
Special Features	Double Wall, Self Clean, Self-cleaning

8. Warranty and Support

Your Frigidaire FGET3066UF Double Electric Wall Oven is covered by a manufacturer's warranty. For detailed information regarding warranty terms, coverage, and duration, please refer to the warranty card included with your product or visit the official Frigidaire website.

For technical assistance, troubleshooting beyond this manual, or to schedule service, please contact Frigidaire Customer Support. Have your model number (FGET3066UF) and serial number ready when contacting support to expedite the process.

You can visit the official Frigidaire Store on Amazon for more information:Frigidaire Store

© 2024 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07QMMPKJ1

More documents and user manuals: **https://manuals.plus/**