Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bushnell Bushnell Tour V4 Shift Patriot pack

Bushnell Tour V4 Shift (Slope) Golf Laser Rangefinder User Manual

Model: Bushnell Tour V4 Shift Patriot pack

Introduction

The Bushnell Tour V4 Shift Golf Laser Rangefinder is a precision optical instrument designed to provide accurate distance measurements for golfers. Featuring Slope-Switch Technology, it allows users to easily toggle between compensated distance readings (slope-adjusted) and non-compensated readings, making it suitable for both practice and tournament play. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.



Figure 1: Bushnell Tour V4 Shift Rangefinder, showing the device, protective skin, carrying case, and battery.

Setup

Battery Installation

Your Bushnell Tour V4 Shift Rangefinder requires one CR2 Lithium battery. To install or replace the battery:

1. Locate the battery compartment cover, typically on the side or bottom of the device.
2. Twist or slide the cover to open the compartment.
3. Insert the CR2 Lithium battery, ensuring the positive (+) and negative (-) terminals are aligned correctly as indicated inside the compartment.
4. Close the battery compartment cover securely.

Attaching the Protective Skin

The Bonus Slope Version includes a protective silicone skin. Carefully slide the skin onto the rangefinder, ensuring all buttons and optical openings are correctly aligned with the cutouts on the skin.

Operating Instructions

Powering On and Off

To power on the device, press the power button (usually located on the top). The reticle will appear in the display. The device will automatically power off after a short period of inactivity to conserve battery life.

Measuring Distances

While looking through the eyepiece, aim the reticle at your desired target. Press and hold the power button. The distance will be displayed almost instantly. For best results, keep the device steady.

Slope-Switch Technology

The Tour V4 Shift features a physical switch on the side of the unit to toggle the Slope function on or off. When the Slope function is enabled, the device provides compensated distances based on elevation changes. When disabled, it provides line-of-sight distances, making it legal for tournament play.



Figure 2: Illustration of the Slope On/Off switch, demonstrating how to enable or disable the slope compensation feature.

PinSeeker with JOLT Technology

This feature allows for easy acquisition of the flagstick without inadvertently capturing background targets. When multiple objects are present, the PinSeeker mode prioritizes the closest object. Once the flagstick is identified, the device will vibrate (JOLT) to confirm that the distance to the flag has been locked.

Fast Focus System

To ensure a clear view, adjust the eyepiece by rotating the diopter adjustment ring until the display and target appear sharp and in focus.

Maintenance

Cleaning the Lenses

Gently blow away any dust or debris from the lenses. Use a soft, clean microfiber cloth to wipe the lens surfaces. For

stubborn smudges, a small amount of lens cleaning fluid designed for optics can be applied to the cloth, not directly to the lens.

Storage

When not in use, store the rangefinder in its protective carrying case in a cool, dry place. Avoid exposing the device to extreme temperatures or direct sunlight for prolonged periods, as this can cause damage (e.g., "solar burn" as noted in some user experiences).

Battery Care

If the device will not be used for an extended period, it is recommended to remove the battery to prevent potential leakage and damage to the electronics.

Troubleshooting

- **No Display/Power:** Ensure the battery is correctly installed and fully charged. Replace the battery if necessary.
- **Inaccurate Readings:** Ensure the target is within the measuring range (up to 400 yards). Make sure the lens is clean and free from obstructions. Steady your hand or use a stable surface when measuring. Note that readings can sometimes vary by a few yards, as observed by some users; taking multiple readings can help confirm accuracy.
- **Spots in View Screen (Solar Burn):**Avoid pointing the rangefinder directly at the sun or leaving it exposed to direct sunlight for extended periods, especially through the eyepiece. This can cause permanent damage to the internal components, appearing as dark spots. If this occurs, contact customer support.
- **JOLT Feature Not Activating:** Ensure you are targeting the flagstick or a distinct object. The PinSeeker feature requires a clear target to differentiate it from the background.

Specifications

Feature	Detail
Brand	Bushnell
Model Name	Bushnell Tour V4 Shift Patriot pack
Color	White-Red
Material	Plastic
Sport	Golf
Item Weight	1 Pounds
Battery Type	Lithium (CR2)
Water Resistance Level	Not Water Resistant
Measuring Range	Up to 400 yards
UPC	029757000262
Item Dimensions (LxWxH)	4 x 1.57 x 3.11 inches
Part Number	201760P
Included Components	Laser, Battery, Case, Manual

Warranty Information

The Bushnell Tour V4 Shift Golf Laser Rangefinder comes with a**2-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the official Bushnell warranty documentation or contact Bushnell customer support.

Customer Support

For technical assistance, warranty claims, or general inquiries, please contact Bushnell customer support. You can find contact information and additional resources on the official Bushnell website. For more information about Bushnell products, you may visit the Bushnell Store on Amazon.

© 2024 Bushnell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07QQVL5ZN

More documents and user manuals: **https://manuals.plus/**