Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER 6ft Power Cord

PK Power 6ft Power Cord Instruction Manual

For Lenoxx CD Cassette Player CD-102

1. Introduction

This instruction manual provides essential information for the safe and effective use of your PK Power 6ft Power Cord. This power cord is designed to supply electrical power to compatible devices, specifically the Lenoxx CD Cassette Player CD-102. Please read this manual thoroughly before use and retain it for future reference.

2. Product Overview

The PK Power 6ft Power Cord is a replacement or spare AC power cable. It features a standard 2-prong US plug (NEMA 1-15P) on one end and a non-polarized 2-slot connector (IEC C7) on the other, commonly known as a "figure-8" connector. This design ensures compatibility with various electronic devices requiring this specific power input.



Image 1: PK Power 6ft Power Cord. This image displays the full length of the black power cord, showing both the standard US 2-

prong wall plug and the 2-slot figure-8 connector.

3. Compatibility

This power cord is specifically designed to be compatible with the following device:

- Lenoxx CD Cassette Player CD-102

It may also be compatible with other devices that require a 2-slot non-polarized (figure-8) power cord and operate within the specified voltage range (100-240V).

4. Setup and Installation

1. **Inspect the Cord:** Before connecting, visually inspect the power cord for any signs of damage, such as cuts, frayed wires, or bent prongs. Do not use a damaged cord.
2. **Connect to Device:** Locate the power input port on your Lenoxx CD Cassette Player CD-102. Carefully align the 2-slot (figure-8) connector of the PK Power cord with the device's power input and push it firmly until it is fully seated.
3. **Connect to Power Outlet:** Insert the 2-prong US plug into a standard 100-240V AC wall outlet. Ensure the outlet is easily accessible and not overloaded.
4. **Verify Connection:** Confirm that both ends of the power cord are securely connected.



Image 2: Close-up of the 2-slot (figure-8) connector. This image shows the end of the power cord that connects to the electronic device, highlighting its shape and connection type.

5. Operating Instructions

Once the PK Power 6ft Power Cord is correctly installed, your Lenoxx CD Cassette Player CD-102 should receive power. Operate your device according to its own instruction manual. The power cord itself does not require any specific operational steps beyond proper connection.

6. Maintenance and Care

- **Cleaning:** Disconnect the power cord from both the wall outlet and the device before cleaning. Wipe the

cord with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.

- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cord sharply, as this can damage the internal wires.
- **Handling:** Always grasp the plug body when inserting or removing the cord from an outlet or device. Never pull on the cable itself, as this can damage the connections.
- **Safety:** Do not expose the power cord to water or excessive moisture. Keep it away from heat sources and sharp objects.

7. Troubleshooting

If your device does not power on after connecting the PK Power 6ft Power Cord, consider the following:

- **No Power:**
  - Ensure the power cord is fully inserted into both the device and the wall outlet.
  - Check if the wall outlet is functional by plugging in another known working appliance.
  - Verify that the device's power switch is in the "On" position.
- **Cord Does Not Fit:**
  - Confirm that your device requires a 2-slot non-polarized (figure-8) power cord. This cord is specifically designed for the Lenoxx CD Cassette Player CD-102 and similar devices.
  - Do not force the connector. If it does not fit easily, it may not be the correct type for your device.
- **Visible Damage:** If the power cord shows any signs of damage (e.g., cuts, exposed wires, bent prongs), discontinue use immediately and replace it.



Image 3: PK Power cord with both plug types visible. This image provides a clear view of both the wall plug and the device connector, aiding in identification for troubleshooting.

8. Specifications

Input Voltage	100-240V AC
Frequency	50-60Hz

Length	6 feet (approx. 1.8 meters)
Connector Type (Wall)	US 2-prong (NEMA 1-15P)
Connector Type (Device)	2-slot non-polarized (IEC C7 / Figure-8)
Color	Black
Certifications	CE / FCC / RoHS certified
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)

9. Warranty and Support

PK-Power products are manufactured to meet and exceed OEM specifications. For warranty information or customer support, please refer to the contact information provided with your purchase or visit the official PKPOWER website. Our customer service team aims to respond within 24 hours for any inquiries.
For further assistance, you may contact the seller directly through the platform where the purchase was made.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07QZVYGWR

More documents and user manuals: **https://manuals.plus/**