Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MN67Z-BK

Minolta Pro Shot 20MP Digital Camera Instruction Manual

Model: MN67Z-BK

1. Introduction

The Minolta Pro Shot 20MP Digital Camera is designed for both amateur and advanced photographers seeking a versatile and powerful tool for capturing high-quality images and videos. Featuring a 20-megapixel sensor, 67x optical zoom, optical image stabilization, and Full HD 1080p video recording, this camera is equipped to handle a wide range of photographic situations. Its articulating LCD screen and Wi-Fi connectivity enhance usability and sharing capabilities.

2. What's in the Box

Verify that all items are present in the package:

- Minolta Pro Shot 20MP Digital Camera (MN67Z-BK)
- Rechargeable Lithium-Ion Battery
- Battery Charger
- USB Cable
- Neck Strap
- Lens Cap
- 16GB SD Card
- User Manual (this document)

3. Product Overview

Familiarize yourself with the key components of your Minolta Pro Shot camera.



Figure 3.1: Front view of the Minolta Pro Shot camera with the flash raised.



Figure 3.2: Top view showing the mode dial, shutter button, and zoom lever.



Figure 3.3: Rear view with the 3-inch articulating LCD screen fully extended and rotated.

▶ **Watch video online**
Minolta Pro Shot 20 Mega Pixel HD Digital Camera with 67X Optical Zoom, Full 1080P HD Video & 16G...

Video 3.1: A brief overview of the Minolta Pro Shot 20MP Digital Camera, highlighting its key features and design.

4. Setup

4.1 Battery Installation

1. Open the battery compartment cover located on the bottom of the camera.
2. Insert the rechargeable Lithium-Ion battery, ensuring the correct orientation as indicated by the diagram inside the compartment.
3. Close the battery compartment cover until it clicks securely into place.

4.2 SD Card Installation

1. Locate the SD card slot, typically next to the battery compartment.
2. Insert the 16GB SD card with the metal contacts facing the front of the camera until it clicks into place.
3. To remove, gently push the card in until it springs out.

4.3 Initial Power On and Date/Time Setting

1. Press the **ON/OFF** button to power on the camera.
2. Upon first use, the camera will prompt you to set the date, time, and time zone. Use the directional buttons to navigate and the **SET** button to confirm.
3. Ensure accurate settings for proper file management and timestamping of your photos and videos.

5. Operating the Camera

5.1 Taking Photos

1. Turn the mode dial to the desired shooting mode (e.g., Auto, Program, Scene).
2. Frame your shot using the 3-inch articulating LCD screen or the electronic viewfinder. Adjust the screen angle as needed for comfortable viewing.
3. Use the zoom lever to adjust the 67x optical zoom.
4. Press the shutter button halfway down to activate autofocus and exposure. The focus frame will turn green when focus is achieved.
5. Press the shutter button fully down to capture the photo.

5.2 Recording Videos

1. Set the mode dial to the video recording mode (usually indicated by a video camera icon).
2. Press the dedicated video record button to start recording.
3. Press the video record button again to stop recording.
4. Videos are recorded in Full HD 1080p resolution.

5.3 Using Scene Modes

The camera features 27 intelligent scene modes to optimize settings for various shooting conditions. Rotate the mode dial to 'SCN' and select from options like Portrait, Landscape, Night Shot, Fireworks, Panorama, and more. The camera automatically adjusts parameters for the best results.



Figure 5.1: Examples of diverse scenes that can be optimized using the camera's intelligent scene modes.

5.4 Wi-Fi Connectivity

The Minolta Pro Shot camera includes built-in Wi-Fi for easy sharing and remote control. Download the Minolta ProShot app on your smartphone or tablet to:

- Wirelessly transfer photos and videos to your smart device.
- Use your smart device as a remote control for shooting.



Figure 5.2: The camera's Wi-Fi feature allows seamless connection to smart devices via the Minolta ProShot app.

6. Maintenance

6.1 Cleaning the Camera and Lens

- Use a soft, lint-free cloth to clean the camera body. Do not use harsh chemicals.
- For the lens, use a lens brush to remove dust, then a lens cleaning solution and a microfiber cloth. Avoid touching the lens surface directly.
- Keep the lens cap on when not in use to protect the lens.

6.2 Battery Care

- Charge the battery fully before first use.
- Store batteries in a cool, dry place when not in use.
- Avoid exposing batteries to extreme temperatures.

6.3 Storage

When storing the camera for extended periods, remove the battery and SD card. Store the camera in a dry, dust-free environment, preferably in a camera bag or case to protect it from impacts.

7. Troubleshooting

7.1 Camera Does Not Power On

- Ensure the battery is fully charged and correctly inserted.
- Check if the battery contacts are clean.
- Try using a different, fully charged battery if available.

7.2 Images Are Blurry

- Ensure the lens is clean and free of smudges.
- Verify that autofocus is engaged (press shutter halfway).
- Check lighting conditions; low light can affect focus.
- Utilize the optical image stabilization feature, especially when zooming or in low light.



Figure 7.1: Optical Image Stabilization helps achieve sharp images, reducing blur from camera shake.

7.3 Wi-Fi Connection Issues

- Ensure the Minolta ProShot app is installed and updated on your smart device.
- Restart both the camera and your smart device.
- Check your device's Wi-Fi settings to ensure it's connected to the camera's network.

8. Specifications

Feature	Specification
Brand	Minolta
Model Name	Pro Shot
Model Number	MN67Z-BK
Effective Still Resolution	20 MP
Optical Zoom	67 x
Digital Zoom	4 x
Video Resolution	FHD 1080p
Frame Rate	30 FPS
Image Stabilization	Optical
Screen Size	3 Inches
Display Type	LCD (Articulating)
Connectivity Technology	Wi-Fi, USB, HDMI
Flash Memory Type	SD (16GB included)
Photo Sensor Technology	CMOS
Photo Sensor Size	1/2.3-inch
Battery Type	Lithium Ion
Item Weight	1.37 Pounds
Special Feature	27 Intelligent Shooting Modes

9. Warranty & Support

Your Minolta Pro Shot 20MP Digital Camera comes with a 1-Year Manufacturer Warranty. For warranty claims, technical support, or additional assistance, please refer to the official Minolta support channels.
For a detailed user guide in PDF format, please download it from the official sourceMinolta Pro Shot User Manual (PDF)

© 2024 Minolta. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07S7VBGLJ

More documents and user manuals: **https://manuals.plus/**