Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Haomaomao NBF3

Haomaomao Portable Neck Fan (Model NBF3) Instruction Manual

Thank you for choosing the Haomaomao Portable Neck Fan. This manual provides essential information for safe and efficient use of your device.

1. Product Overview

The Haomaomao Portable Neck Fan is a hands-free, wearable personal fan designed for cooling on the go. It features a double-headed design with 360-degree rotatable fan heads, three adjustable speed settings, and a built-in 2500 mAh rechargeable battery for extended use.

Key Features:

- Hands-free, wearable design for convenience.
- Double-headed fans with 360° rotation for customizable airflow.
- Three adjustable wind speeds (Low, Medium, High).
- 2500 mAh rechargeable battery.
- USB Type-C charging compatibility.
- Lightweight and portable construction.



Figure 1: Haomaomao Portable Neck Fan, illustrating its overall design and dual fan heads.

2. Safety Instructions

Please read and follow these safety guidelines to prevent injury or damage to the device.

- Do not insert fingers or any foreign objects into the fan blades.
- If you have long hair, tie it back to prevent it from getting caught in the fan blades during operation.
- Do not expose the fan to excessive moisture, rain, or immerse it in water.
- Keep the device out of reach of children and pets.
- Do not attempt to disassemble, modify, or repair the fan yourself. Contact customer support for assistance.
- Charge the fan only with the provided USB cable and a compatible 5V power source.
- Avoid dropping the fan or subjecting it to strong impacts.



Figure 2: Important safety tip regarding hair and fan blades.

3. Package Contents

Verify that all items are present in the package:

- 1 x Haomaomao Portable Neck Fan
- 1 x USB Charging Cable
- 1 x User Manual

4. Initial Setup

Before using your Haomaomao Portable Neck Fan for the first time, it is recommended to fully charge the battery. This process typically takes at least 2 hours and helps to ensure optimal battery performance and longevity.



Figure 3: Location of the Type-C charging port.

5. Operating Instructions

5.1. Power On/Off and Speed Adjustment

The fan is controlled by a single multi-function button located on the main body of the neckband.

- **To Power On/Off:** Press and hold the power button for approximately 3 seconds.
- **To Adjust Wind Speed:** Once the fan is on, short press the power button to cycle through the three available wind speed settings: Low (1st press), Medium (2nd press), High (3rd press). Pressing it a fourth time will return to Low speed.

5.2. Fan Head Adjustment

The two fan heads are connected to the neckband by flexible arms, allowing for 360-degree rotation. Adjust each fan head independently to direct the airflow precisely where you need it.



Figure 4: Fan head rotation and power button location.

6. Charging the Fan

To charge your neck fan, follow these steps:

1. Locate the Type-C charging port on the side of the neckband.
2. Connect the small end of the provided USB charging cable to the fan's Type-C port.
3. Connect the larger USB-A end of the cable to a compatible USB power source (e.g., computer USB port, USB wall adapter, power bank).

6.1. Indicator Lights

The LED indicator light provides information about the fan's charging status and battery level:

- **Charging:** The indicator light will be RED.
- **Fully Charged:** The indicator light will turn BLUE.
- **Low Battery:** The RED light will flash, indicating that the fan needs to be recharged soon.

A full charge provides approximately 3-10 hours of operation, depending on the selected speed setting.



Figure 5: Battery capacity and estimated usage times.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your neck fan.

- **Cleaning:** Use a soft, dry cloth to gently wipe the exterior of the fan. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface. Ensure the fan is turned off before cleaning.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place away from direct sunlight and extreme temperatures. It is advisable to fully charge the fan before storing it to maintain battery health.

8. Troubleshooting

If you encounter any issues with your Haomaomao Portable Neck Fan, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Fan does not turn on	Battery is depleted.	Charge the fan for at least 2 hours.
Weak airflow	Low speed setting or low battery.	Increase the speed setting or recharge the battery.
Fan blades stop or make unusual noise	Obstruction (e.g., hair, debris) in the fan blades.	Turn off the fan immediately. Carefully remove any obstructions.
Charging indicator not working	Faulty USB cable or power source; loose connection.	Try a different USB cable or power adapter. Ensure all connections are secure.

If problems persist after attempting these solutions, please contact Haomaomao customer support for further assistance.

9. Specifications

Detailed technical specifications for the Haomaomao Portable Neck Fan:

Brand	Haomaomao
Model Name	Portable Neck Fan
Model Number	NBF3 (LQ-229)
Power Source	Battery Powered
Battery Capacity	2500 mAh
Charging Port	USB Type-C
Number of Speeds	3
Product Dimensions (D x W x H)	10.4" x 7.11" x 1"
Item Weight	8.8 ounces
Material	Plastic
Voltage	5 volts
Wattage	1.5 watts
Noise Level	1 sones
Control Method	Push Button
Special Features	Neck Wearable, Portable, Lightweight, Foldable, 360° Rotate, Flexible Arms, Hands Free, Rechargeable

10. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your purchase or contact Haomaomao customer service directly through their official channels. Please have your model number (NBF3 or LQ-229) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SPDM4PN

More documents and user manuals: **https://manuals.plus/**