Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Duracell MN1300

Duracell Coppertop Alkaline D-Size Batteries User Manual

Model: MN1300 / 1156N70PK

Brand: Duracell

1. Introduction

This manual provides essential information for the safe and effective use of Duracell Coppertop Alkaline D-Size Batteries. These batteries are designed to provide long-lasting, reliable power for a wide range of devices. With a guaranteed 10-year shelf life in storage, they are a dependable power source for your household and electronic needs.



Image: A pack of 12 Duracell Coppertop D-Size Alkaline Batteries, showcasing the packaging.

2. Safety Information

Please read and follow these safety guidelines to prevent injury or damage to devices:

- **Do Not Recharge:** These are primary alkaline batteries and are not designed to be recharged. Attempting to recharge them may lead to leakage, fire, or explosion.
- **Proper Polarity:** Always insert batteries correctly according to the positive (+) and negative (-) marks in your device. Incorrect insertion can cause damage.
- **Do Not Disassemble or Mutilate:** Do not open, puncture, or otherwise damage batteries. This can release hazardous materials.
- **Keep Away from Children:** Batteries can be a choking hazard. Keep them out of reach of small children.
- **Proper Disposal:** Dispose of used batteries according to local regulations. Do not dispose of in fire.
- **Avoid Mixing:** Do not mix old and new batteries, or batteries of different types or brands, as this can reduce performance and cause leakage.

- **Storage:** Store batteries in a cool, dry place at room temperature. Avoid extreme temperatures.

3. Setup and Installation

Installing Duracell D-Size batteries is a straightforward process:

1. **Identify Battery Compartment:** Locate the battery compartment on your electronic device.
2. **Open Compartment:** Open the battery compartment cover. This may involve sliding, lifting, or unscrewing.
3. **Observe Polarity:** Note the positive (+) and negative (-) indicators inside the compartment.
4. **Insert Batteries:** Insert the Duracell D-Size batteries, aligning the positive (+) end of the battery with the positive (+) terminal in the device, and the negative (-) end with the negative (-) terminal.
5. **Close Compartment:** Securely close the battery compartment cover.



Image: A single Duracell Coppertop D-Size battery being held, illustrating its size and design for easy handling and installation.

4. Operating Instructions

Once installed, Duracell D-Size batteries provide power to your compatible devices. These batteries are particularly well-suited for high-drain devices, ensuring consistent and reliable performance.
Common applications include:

- Flashlights and lanterns
- Radios and boomboxes
- Children's toys
- Automatic air fresheners
- Medical devices requiring D-size batteries



Image: An illustration showing various household devices such as a robot toy, remote control, flashlight, clock, radio, and walkie-talkie, all powered by Duracell batteries, demonstrating their versatility.

Your browser does not support the video tag.

Video: A product overview video demonstrating the features and uses of Duracell Coppertop Alkaline D-Size Batteries, including their long-lasting power and compatibility with various devices.

5. Maintenance

Duracell D-Size batteries require minimal maintenance. To ensure optimal performance and longevity:

- **Clean Contacts:** Periodically check the battery contacts in your device and on the batteries. If they appear dirty or corroded, gently clean them with a pencil eraser or a cotton swab dipped in rubbing alcohol. Ensure contacts are dry before re-inserting batteries.
- **Remove When Not in Use:** For devices that will not be used for extended periods, it is recommended to remove the batteries to prevent potential leakage and damage to the device.
- **Proper Storage:** Store unused batteries in their original packaging in a cool, dry place at normal room temperature. Avoid storing them in direct sunlight or in areas with extreme temperature fluctuations.



Image: Duracell battery packaging highlighting the "Guaranteed 10 Years in Storage" feature, emphasizing the battery's long shelf life.

6. Troubleshooting

If your device is not functioning correctly with new Duracell D-Size batteries, consider the following:

Problem	Possible Cause	Solution
Device not powering on.	Incorrect battery insertion (polarity).	Check and correct battery polarity (+/-).
Device powers on but is weak or intermittent.	Batteries are low on power or contacts are dirty.	Replace batteries with new ones. Clean battery and device contacts.
Battery leakage observed.	Over-discharge, mixing battery types, or extreme temperatures.	Carefully remove leaking batteries (wear gloves). Clean compartment. Dispose of batteries properly. Ensure proper usage and storage.

7. Specifications

Key specifications for Duracell Coppertop Alkaline D-Size Batteries:

Brand: Duracell

Model Number: 1156N70PK (also known as MN1300)

Battery Cell Composition: Alkaline

Battery Size: D

Number of Batteries: 12 (in pack)

Battery Capacity: 1500 Milliamp Hours (typical)

Product Dimensions: 5.4 x 2.5 x 4.1 inches (packaging); Individual battery dimensions are standard D-size.

Weight: 3.5 Pounds (packaging)

Recommended Uses: Radio, flashlights, toys, and other compatible D-size battery devices.

Date First Available: April 1, 2008

8. Warranty and Support

Duracell Coppertop Alkaline D-Size Batteries come with a **10-year guarantee in storage**. This ensures that the batteries will retain their power for up to ten years when stored properly under normal conditions.

For any questions, concerns, or support regarding your Duracell batteries, please refer to the official Duracell website or contact their customer service directly. Contact information is typically available on the product packaging or the manufacturer's official website.

You can visit the official Duracell store on Amazon for more information: Duracell Store

© 2025 Duracell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07T22JV6V

More documents and user manuals: **https://manuals.plus/**