Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO GWK09

TRESKO 1.8L Electric Kettle with Tea Infuser and Water Filter - Model GWK09

This manual provides instructions for the safe operation, setup, and maintenance of your TRESKO electric kettle.

Important Safety Information

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the kettle is placed on a firm, flat, heat-resistant surface.
- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Do not operate the kettle if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Only use the kettle with its supplied power base.
- Do not fill the kettle above the maximum fill line or below the minimum fill line.
- Exercise caution when pouring hot water.
- The kettle features boil-dry protection and automatic shut-off for safety. If the kettle boils dry, it will automatically switch off. Allow it to cool before refilling.
- Unplug the kettle from the power outlet when not in use and before cleaning.
- This appliance is for household use only.

Product Overview

Familiarize yourself with the components of your TRESKO electric kettle:

- **Kettle Body:** Made of high-quality safety glass.
- **Lid:** Features a one-hand opening mechanism.
- **Handle:** Thermally insulated for safe handling.
- **Power Base:** 360-degree rotational base with cord storage and anti-slip feet.
- **Tea Infuser:** Removable and dishwasher-safe for brewing tea directly.
- **Limescale Filter:** Removable and washable, integrated into the spout.
- **Water Level Indicator:** External indicator for clear visibility.
- **Control Panel:** For temperature selection and activation.



The kettle features durable, heat-resistant, and shock-proof safety glass construction, consisting of a hardened inner layer, corrosion-resistant material, high-temperature resistant layer, and clear glass.

Initial Setup

Before first use, follow these steps:

1. Unpack the kettle and all accessories. Remove any packaging materials.
2. Clean the kettle interior by filling it with cold water to the maximum level and boiling it. Discard the water. Repeat this process two to three times to remove any manufacturing residues.
3. Place the power base on a stable, flat, and dry surface. Ensure the power cord is not dangling.
4. Plug the power cord into a suitable electrical outlet.



The 360-degree rotatable power base ensures stable placement and easy handling. It includes anti-slip rubber feet for secure positioning.

Operating Instructions

Filling the Kettle

Press the lid release button to open the lid. Fill the kettle with fresh cold water, ensuring the water level is between the MIN and MAX marks on the water level indicator. Close the lid securely.

Powering On and Off

Place the kettle onto the power base. Press the ON/OFF button on the control panel to start the heating process. The kettle will automatically switch off once the selected temperature is reached or if it boils dry.

Temperature Selection

The kettle offers five preset temperature options, indicated by a colored LED:

- **60°C:** Ideal for delicate teas or baby food.
- **70°C:** Suitable for white and green teas.
- **80°C:** Recommended for oolong teas.
- **90°C:** Perfect for coffee or black teas.
- **100°C:** For boiling water, herbal teas, or instant noodles.

Press the temperature selection button repeatedly to cycle through the desired temperature settings.



The control panel allows selection of five preset temperatures (60°C, 70°C, 80°C, 90°C, 100°C), indicated by a colored LED for precise heating.

Keep Warm Function

To activate the keep warm function (maintaining 85°C), press and hold the ON/OFF button for approximately 3 seconds after the water has reached the desired temperature. The kettle will maintain the temperature for a set period.

Using the Tea Infuser

The removable tea infuser allows you to brew loose leaf tea directly in the kettle:

1. Open the kettle lid.
2. Insert the tea infuser into the kettle, ensuring it is properly seated.
3. Add your desired amount of loose leaf tea to the infuser.
4. Fill the kettle with water and select the appropriate temperature for your tea.
5. Once brewing is complete, carefully remove the infuser using its handle.



The removable tea infuser allows for direct tea preparation within the kettle. It is dishwasher-safe for easy cleaning.

Maintenance

General Cleaning

Always unplug the kettle and allow it to cool completely before cleaning.

- Wipe the exterior of the kettle and power base with a soft, damp cloth. Do not use abrasive cleaners or scouring

pads.

- Never immerse the kettle or power base in water.

Limescale Filter Cleaning

Regular cleaning of the limescale filter is essential for optimal performance, especially in hard water areas.

1. Ensure the kettle is unplugged and cool.
2. Open the lid and locate the limescale filter in the spout.
3. Gently pull the filter upwards to remove it.
4. Rinse the filter under running water or place it in a dishwasher for thorough cleaning.
5. Once clean and dry, reinsert the filter into its slot until it clicks into place.



The integrated, removable limescale filter helps prevent mineral deposits and can be easily cleaned or washed in a dishwasher.

Troubleshooting

If you encounter any issues with your kettle, please refer to the following table before contacting customer support:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; no power at outlet; kettle not properly seated on base.	Check power connection; test outlet with another appliance; ensure kettle is correctly placed on the power base.
Water is not heating.	Kettle has boiled dry; insufficient water.	Allow kettle to cool down for 15-20 minutes before refilling; ensure water level is above MIN mark.
Kettle switches off too quickly.	Excessive limescale buildup.	Descale the kettle regularly (refer to maintenance section).
Water tastes unusual.	First use residues; limescale buildup.	Perform initial cleaning steps again; descale the kettle.

Technical Specifications

Feature	Specification
Model Number	GWK09
Capacity	1.8 Liters
Power	2200 Watts
Voltage	120 Volts
Material	Glass, Stainless Steel, Plastic
Dimensions (L x W x H)	19.4 x 12.6 x 20.5 cm
Temperature Settings	60°C, 70°C, 80°C, 90°C, 100°C (also 40°C for baby food)
Keep Warm Function	Yes (85°C)
Safety Features	Boil-dry protection, Overheat protection, Automatic shut-off, BPA-free
Special Features	LED illumination, Removable tea infuser, Removable limescale filter, 360° rotational base, Cord storage

Warranty Information and Customer Support

Your TRESKO electric kettle is covered by a manufacturer's warranty. Please refer to your purchase documentation or the retailer's website for specific warranty terms and conditions.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact the retailer or the manufacturer's customer support directly. Keep your proof of purchase handy when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07TLYRVYC

More documents and user manuals: **https://manuals.plus/**