Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi FET05600

Giochi Preziosi Feisty Pets Plush Bear Bruno Instruction Manual

Overview Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The Giochi Preziosi Feisty Pets Plush Bear Bruno is an interactive plush toy designed to surprise and entertain. This 25 cm brown bear transforms its expression from cute and cuddly to fierce with a simple squeeze, offering a unique play experience. It is suitable for children aged 6 years and older.



Image 1.1: A collection of various Feisty Pets, showcasing their initial cute appearance.

2. Setup

The Feisty Pets Plush Bear Bruno requires no assembly or batteries. It is ready for play directly out of the packaging.

1. Carefully remove the plush bear from its packaging.
2. Inspect the toy for any visible damage or defects.
3. Ensure all packaging materials are discarded safely, especially plastic bags, to prevent choking hazards.

3. Operating Instructions

The primary feature of the Feisty Pets Plush Bear Bruno is its ability to change expression. Follow these steps to activate its fierce look:

1. Hold the plush bear comfortably.
2. Locate the activation mechanism on the back of the bear's head, typically behind the ears.
3. Gently but firmly squeeze the sides of the bear's head or the specific area on the back where the mechanism is

located.

4. Observe as the bear's expression instantly changes from cute to fierce, with furrowed brows and an open mouth revealing teeth.
5. Release the squeeze to return the bear to its original cute and cuddly expression.



Image 3.1: Demonstrating how to squeeze the back of the bear's head to change its expression.



Image 3.2: The Feisty Pets bear displaying its fierce expression.

4. Maintenance

Proper care will ensure the longevity of your Feisty Pets Plush Bear Bruno.

- **Cleaning:** To clean the plush toy, use a damp cloth with a small amount of mild soap. Gently wipe the surface of the bear. Do not immerse the toy in water, machine wash, or use harsh chemicals, as this may damage the internal mechanism and plush material.
- **Drying:** Allow the toy to air dry completely after cleaning. Do not use a dryer or direct heat.
- **Storage:** Store the plush bear in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or material degradation.

5. Troubleshooting

If you encounter any issues with your Feisty Pets Plush Bear Bruno, refer to the following common solutions:

- **Mechanism Not Activating:**
  - Ensure you are applying pressure directly to the activation point on the back of the bear's head.
  - Check if any foreign objects are obstructing the mechanism.
  - Avoid excessive force, as this is not necessary for activation and could potentially damage the toy.
- **Expression Not Returning to Normal:**
  - Ensure you have fully released the pressure from the activation point.
  - Gently manipulate the plush around the mechanism to ensure it is not caught.
- **No Batteries Required:** This toy operates mechanically and does not require batteries, so issues related to power are not applicable.

6. Product Specifications

Brand	Giochi Preziosi
Model Number	FET05600
Animal Theme	Bear
Color	Brown
Product Dimensions (L x W x H)	25.4 x 13.3 x 16.5 cm
Assembly Required	No
Batteries Required	No
Included Components	Feisty Pets Plushie
Manufacturer Minimum Age	72 months (6 years)

7. Warranty and Support

For information regarding product warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased. It is recommended to retain your proof of purchase for any warranty claims. For direct inquiries, you may attempt to contact Giochi Preziosi customer service through their official website or contact channels.

© 2024 Giochi Preziosi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07V56XPWX

More documents and user manuals: **https://manuals.plus/**