Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Deco Gear Magnetic Wireless Sport Earbuds

Deco Gear Magnetic Bluetooth Wireless Sport Earbud Headphones User Manual

Model: Magnetic Wireless Sport Earbuds

Introduction

Thank you for choosing the Deco Gear Magnetic Bluetooth Wireless Sport Earbud Headphones. These headphones are designed to provide quality audio and practical functionality for active lifestyles. Featuring a magnetic on/off function, long battery life, and a secure fit, they are suitable for various activities including workouts, biking, running, and hiking.

Package Contents

Please verify that all items listed below are included in your package:

- Deco Gear Magnetic Bluetooth Wireless Sport Earbud Headphones
- USB Charging Cable
- Multiple Pairs of Ear Tips (various sizes)
- Cable Management Clips
- Protective Carrying Case



Figure 1: Package Contents

Product Overview

The Deco Gear Magnetic Bluetooth Wireless Sport Earbud Headphones feature an ergonomic design with ear hooks for a secure fit during physical activity. The earbuds are connected by a cable that houses an inline control module and microphone.



Figure 2: Deco Gear Earbud Headphones

Setup

1. Charging the Earbuds

Before initial use, fully charge the earbuds. Connect the supplied USB charging cable to the charging port on the control module and to a standard USB power source (e.g., computer USB port, wall adapter). The charging time is approximately 2 hours.

2. Selecting Ear Tips and Fit

Choose the ear tips that provide the most comfortable and secure fit for your ears. A proper fit is essential for optimal sound quality and noise isolation. Use the included cable management clips to secure the cable during strenuous activities.

Operating Instructions

1. Power On/Off

- **To Power On:** Separate the magnetic earbuds. The earbuds will automatically power on and enter pairing mode.
- **To Power Off:** Click the magnetic earbuds together. This action will power off the headphones and can also end a call.

2. Bluetooth Pairing

1. Ensure the earbuds are powered off.
2. Separate the magnetic earbuds to power them on. They will automatically enter Bluetooth pairing mode, indicated by a flashing LED light (refer to product for specific light indicator).
3. On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings.
4. Search for available devices and select "Deco Gear Earbuds" (or similar name) from the list.
5. Once connected, the LED indicator will change (e.g., solid blue) and a voice prompt may confirm the connection.

The earbuds have a Bluetooth range of up to 15 meters (approximately 49 feet).

3. Playback and Call Controls

The built-in control module allows for easy management of your audio and calls. Specific button functions may vary slightly, but generally include:

- **Volume Up/Down:** Press '+' or '-' buttons.
- **Play/Pause:** Press the multi-function button (often the center button).
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.
- **Answer/End Call:** Press the multi-function button.
- **Reject Call:** Long press the multi-function button.
- **Voice Assistant:** Double-press the multi-function button (compatible with Android and iOS).

The integrated microphone ensures clear voice transmission during calls or for voice commands.

Maintenance

Cleaning

Regularly clean the ear tips and earbud surfaces with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials. Ensure no moisture enters the charging port or speaker grilles.

Storage

When not in use, store the earbuds in the provided protective carrying case to prevent damage from dust, debris, or physical impact. Store in a cool, dry place away from direct sunlight and extreme temperatures.

Battery Care

To prolong battery life, avoid fully discharging the earbuds frequently. Charge them regularly, even if not used for extended periods. Do not expose the batteries to excessive heat.

Troubleshooting

Problem	Possible Cause	Solution
Earbuds do not power on.	Low battery.	Charge the earbuds fully.
Cannot pair with device.	Earbuds not in pairing mode; Bluetooth off on device; device too far.	Ensure earbuds are separated to power on and enter pairing mode. Turn on Bluetooth on your device. Move device closer to earbuds. Forget previous pairings on your device and try again.
No sound or low volume.	Volume too low; earbuds not connected; incorrect audio output selected on device.	Increase volume on both earbuds and connected device. Verify Bluetooth connection. Check audio output settings on your device.
Poor sound quality.	Improper ear tip fit; interference; device too far.	Adjust ear tips for a snug fit. Move away from sources of interference (e.g., Wi-Fi routers). Keep device within Bluetooth range.

Specifications

- **Model Name:** Deco Gear Magnetic Wireless Sport Earbuds
- **Connectivity Technology:** Wireless (Bluetooth)
- **Bluetooth Version:** 4.2
- **Bluetooth Range:** 15 Meters (approx. 49 feet)
- **Battery Life:** Up to 6 hours (playback/talk time), Up to 180 hours (standby time)
- **Charging Time:** Approximately 2 hours
- **Battery Type:** 2 x 40 mAh Lithium Polymer (included)
- **Control Type:** Media Control, Touch
- **Microphone:** Built-in
- **Compatible Devices:** Smartphones (Android, iOS)
- **Material:** Polymer
- **Item Weight:** 5.3 ounces

Warranty and Support

Deco Gear products are covered by a Full 1 Year Manufacturer's Limited Protection Plan. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official Deco Gear website. Please retain your proof of purchase for warranty service.

© 2023 Deco Gear. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07V9YZ3W9

More documents and user manuals: **https://manuals.plus/**