Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hoover H-FREE 200 HF222UPT

Hoover HF222UPT H-Free 200 Cordless Stick Vacuum Cleaner User Manual

Model: H-FREE 200 HF222UPT

1. Important Safety Instructions

Please read this manual carefully before using the appliance and keep it for future reference. Always follow basic safety precautions when using an electrical appliance.

- This appliance is intended for domestic use only.
- Do not use the appliance outdoors or on wet surfaces.
- Do not allow children to play with the appliance. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Use extra care when cleaning stairs.
- Disconnect the battery pack from the appliance before making any adjustments, changing accessories, or storing the appliance.
- Recharge only with the charger specified by the manufacturer.

2. Package Contents

Carefully unpack your new Hoover H-Free 200 vacuum cleaner and check that all items are present:

- Main Unit (Handheld Vacuum with Dustbin and Battery)
- Extension Wand (Blue)
- Main Motorized Floor Nozzle with LED Lights
- Mini Turbo Pet Nozzle
- 2-in-1 Crevice and Dusting Tool
- Long 2-in-1 Dusting and Furniture Tool
- Wall Mount Bracket
- Charger
- Instruction Manual (this document)



Image 2.1: All included accessories for the Hoover H-Free 200 vacuum cleaner, including the main unit, extension wand, various nozzles, and tools.

3. Assembly and Setup

3.1 Assembling the Vacuum Cleaner

1. **Attach the Extension Wand:** Insert the top end of the extension wand into the main handheld unit until it clicks

securely into place.

2. **Attach the Floor Nozzle:** Insert the bottom end of the extension wand into the main motorized floor nozzle until it clicks securely into place.
3. **Alternative Handheld Assembly:** For handheld use, attach desired accessories (e.g., Mini Turbo Pet Nozzle, Crevice Tool) directly to the main handheld unit until they click into place.





Image 3.1: The Hoover H-Free 200 vacuum cleaner fully assembled in stick mode, ready for use.

3.2 Charging the Battery

The Hoover H-Free 200 features a removable lithium-ion battery. For optimal performance, fully charge the battery before first use.

1. **Remove Battery:** Press the battery release button and slide the battery out of the main unit.
2. **Connect Charger:** Plug the charger into a wall outlet. Connect the charger cable to the charging port on the battery.
3. **Charging Indicator:** The battery indicator lights will illuminate to show charging status. A full charge typically takes 5-6 hours.
4. **Reinsert Battery:** Once fully charged, disconnect the charger and slide the battery back into the main unit until it clicks.



Image 3.2: Close-up of the removable battery pack for the Hoover H-Free 200, showing its design and charging port.

4. Operation

4.1 Powering On/Off and Suction Modes

- **Power On/Off:** Press the ON/OFF button located on the handle to start or stop the vacuum.
- **Continuous Mode:** The vacuum features a lock mechanism to keep it running without continuously holding the trigger. Engage the lock for continuous operation.

- **Standard Mode:** Provides up to 40 minutes of runtime for general cleaning tasks.
- **Turbo Mode:** Press the "TURBO" button for maximum suction power, ideal for stubborn dirt and pet hair. This mode reduces battery runtime.





Image 4.1: Top view of the main unit's handle, showing the power button, continuous mode switch, and the "TURBO" button for enhanced suction.

4.2 Using Attachments

- **Main Motorized Floor Nozzle:**
  Equipped with front LED lights to illuminate dark areas and under furniture, ensuring no dust is missed. Suitable for hard floors and carpets. The nozzle pivots 90° to 180° for easy maneuverability.



Image 4.2: The main floor nozzle with LED lights illuminating dirt under a coffee table, demonstrating its maneuverability and visibility feature.

- **Mini Turbo Pet Nozzle:**
  Designed specifically for picking up pet hair from upholstery, stairs, and car interiors. Attach directly to the handheld unit.



Image 4.3: The mini turbo pet nozzle being used on a sofa, highlighting its effectiveness for pet hair removal.

- **2-in-1 Crevice and Dusting Tool:**
  Use the crevice tool for tight spaces, corners, and edges. Slide the brush down for dusting delicate surfaces like shelves and keyboards.



Image 4.4: The 2-in-1 crevice and dusting tool being used to clean dust from a bookshelf, demonstrating its versatility.

- **Long 2-in-1 Dusting and Furniture Tool:**

Ideal for larger surfaces, upholstery, and curtains. The brush can be retracted for wider suction.



Image 4.5: The long 2-in-1 dusting and furniture tool cleaning a sofa, showing its effectiveness on fabric surfaces.

5. Maintenance

Regular maintenance ensures optimal performance and extends the life of your Hoover H-Free 200 vacuum cleaner.

5.1 Emptying the Dustbin

Empty the dustbin after each use or when the MAX fill line is reached.

1. **Detach Dustbin:** Press the dustbin release button and remove the dustbin from the main unit.
2. **Open Lid:** Position the dustbin over a trash can and press the release latch on the bottom to open the lid and empty contents.
3. **Close and Reattach:** Close the dustbin lid securely and reattach the dustbin to the main unit until it clicks.



Image 5.1: The dustbin of the Hoover H-Free 200 with its bottom flap open, demonstrating the quick and hygienic emptying process.

5.2 Cleaning the Filters

The H-Free 200 uses a cyclonic separation system with washable filters. Clean filters regularly for consistent suction.

1. **Access Filters:** With the dustbin detached, twist and pull out the filter assembly (pre-motor filter and mesh screen).
2. **Wash Filters:** Rinse the filters under cold running water until the water runs clear. Do not use detergents.
3. **Dry Filters:** Allow filters to air dry completely for at least 24 hours before reinserting. Do not use a hairdryer or other heating devices.
4. **Reassemble:** Once dry, reassemble the filters and place them back into the dustbin.



Image 5.2: Exploded view of the dustbin and its internal cyclonic filter components, illustrating how to access them for cleaning.

5.3 Cleaning the Brush Roll

Periodically check the main floor nozzle's brush roll for tangled hair or debris.

1. **Remove Brush Roll:** Turn the floor nozzle upside down. Locate the brush roll release tab or screw (if applicable) and remove the brush roll.
2. **Clean Debris:** Use scissors to carefully cut away any tangled hair or threads. Remove any accumulated debris.
3. **Reinsert Brush Roll:** Place the clean brush roll back into the nozzle and secure it.

6. Troubleshooting

If you encounter issues with your Hoover H-Free 200, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged or not properly inserted.	Ensure battery is fully charged and securely inserted.
Low suction power.	Dustbin is full, filters are clogged, or blockage in nozzle/hose.	Empty dustbin. Clean or replace filters. Check for and remove any blockages.
Brush roll not spinning.	Brush roll is jammed with debris or motor protection activated.	Turn off vacuum and remove any tangled hair or debris from brush roll.
Short battery runtime.	Battery not fully charged or frequently using Turbo mode.	Ensure battery is fully charged. Use Standard mode for longer runtime. Battery life naturally degrades over time.

7. Specifications

Brand	Hoover
Model Name	H-FREE 200 HF222UPT
Model Number	39400926
Power Source	Battery Powered
Battery Type	Lithium-Ion

Voltage	22 Volts
Runtime	Up to 40 Minutes
Dustbin Capacity	0.7 Liters
Filter Type	Cyclonic, Washable
Weight	2.3 Kilograms
Dimensions (LxWxH)	25.2 x 23.3 x 115.5 cm
Special Features	Cordless, LED Lights, Pet Hair Brush, 2 Speed Modes

8. Warranty and Support

This Hoover H-Free 200 vacuum cleaner comes with a**2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For technical assistance, spare parts, or warranty service, please contact Hoover customer support. Refer to the official Hoover website or your purchase documentation for contact details specific to your region.
Online Resources: For additional support, FAQs, and product registration, visit the officialHoover website.

© 2023 Hoover. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VF57YJN

More documents and user manuals: **https://manuals.plus/**