Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom T04S

Joyroom T04S Wireless Bluetooth Earbuds User Manual

Model: T04S | Brand: Joyroom

1. Introduction

Thank you for choosing the Joyroom T04S Wireless Bluetooth Earbuds. These earbuds are designed to provide a high-quality audio experience with the convenience of wireless connectivity. Featuring Bluetooth V5.0, a built-in microphone for hands-free calls, and a portable charging case, the T04S offers comfort and functionality for daily use, whether for music, calls, or gaming.

Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

2. Package Contents

Ensure all items are present in your package:

- Joyroom T04S Wireless Bluetooth Earbuds (Left and Right)
- Portable Charging Case
- Micro USB Charging Cable
- User Manual (this document)

3. Product Overview

Familiarize yourself with the components of your Joyroom T04S earbuds and charging case.



Figure 3.1: The Joyroom T04S wireless earbuds securely placed within their charging case. The case is white with the Joyroom logo on the front, and the earbuds are also white, featuring an in-ear design with a stem.



Figure 3.2: The white Joyroom T04S charging case and both earbuds are shown resting on a light wooden table. The earbuds are removed from the case, highlighting their individual design.



Figure 3.3: A diagram illustrating the dimensions of the Joyroom T04S charging case and a single earbud. The charging case measures 60mm in height and 49mm in width. Each earbud measures 45mm in height and 17.6mm in width.

4. Setup

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the Micro USB charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The indicator lights on the case will show the charging status. Once fully charged, the lights will indicate completion or turn off.

The charging case has a 500mAh battery and can recharge the earbuds multiple times (up to 7 times depending on usage). Each earbud has a 45mAh battery.

4.2 Bluetooth Pairing

To connect your Joyroom T04S earbuds to your device:

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their indicator lights will flash.
3. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices. You should see "JR-T04S" in the list.
5. Select "JR-T04S" to connect. Once connected, the earbud indicator lights will stop flashing, and your device may confirm the connection.

The earbuds support connecting to two Bluetooth devices simultaneously.



Figure 4.1: A smartphone screen displaying the Bluetooth settings, showing "JR-T04S" as a connected device. This illustrates the successful pairing process.

5. Operating Instructions

5.1 Basic Controls

The Joyroom T04S earbuds feature touch-sensitive controls for easy management of your audio and calls. Specific functions are typically managed via taps or presses on the earbuds. Refer to the quick start guide included in the package for detailed touch control gestures (e.g., single tap for play/pause, double tap for next track, etc.).

5.2 Making and Receiving Calls

With the built-in microphone, you can make and receive calls hands-free.

- **Answer/End Call:** Tap the control area on either earbud.
- **Reject Call:** Press and hold the control area on either earbud.
- **Voice Assistant:** Activate your device's voice assistant (e.g., Siri, Google Assistant) by a specific tap gesture (refer to quick start guide).

5.3 Music Playback

Enjoy high-resolution stereo sound quality for your music.

- **Play/Pause:** Tap the control area on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.



Figure 5.1: A user holding a smartphone horizontally, seemingly engaged in a mobile game, illustrating the use of the earbuds for immersive audio experiences during gaming or media consumption.

6. Maintenance

To ensure the longevity and optimal performance of your Joyroom T04S earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Keep them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Water:** The earbuds are not waterproof. Avoid exposure to water, sweat, or high humidity.
- **Charging:** Use only the provided Micro USB cable or a certified equivalent for charging.

7. Troubleshooting

If you encounter issues with your Joyroom T04S earbuds, try the following solutions:

7.1 Earbuds Not Pairing

- Ensure both earbuds are fully charged.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid again to re-initiate pairing mode.
- Turn off and on your device's Bluetooth.
- Forget "JR-T04S" from your device's Bluetooth list and try pairing again.
- Ensure the earbuds are within the 10-meter Bluetooth range of your device.

7.2 No Sound or Low Volume

- Check the volume level on both your earbuds and your connected device.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speaker mesh.
- Try playing audio from a different application or source.

7.3 Charging Case Not Charging

- Ensure the Micro USB cable is securely connected to both the case and the power source.
- Try a different USB port or power adapter.
- Check the charging cable for any damage.

8. Specifications

Feature	Specification
Model	JR-T04S
Bluetooth Version	V5.0
Supported Protocols	A2DP, HFP, HSPN, SPP, A2SP, AVRCP
Wireless Range	Up to 10 meters
Microphone	Built-in
Headphone Battery Capacity	3.7V 45mAh Polymer Li-ion (per earbud)

Feature	Specification
Charging Case Battery Capacity	3.7V 500mAh Polymer Li-ion
Charging Input	5V DC 120mA
Output Power	2 x 3mW
SNR Isolation Value	S/N 95
Talk Time	Up to 3.5 hours
Music Playback Time	Up to 3.5 hours (earbuds only)
Total Music Playback Time (with case)	Approx. 49 hours
Charging Time	Approx. 1.5 hours
Standby Time	200 hours
Charging Interface	Micro USB
Dimensions (Case)	60mm (H) x 49mm (W)
Dimensions (Earbud)	45mm (H) x 17.6mm (W)

9. Warranty and Support

Joyroom products are designed and manufactured to the highest quality standards. For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Joyroom website. Keep your purchase receipt as proof of purchase.

For further assistance, you may contact Joyroom customer service through their official channels. Please note that the English language instruction manual may not be guaranteed to be included in all packages, but this digital version provides comprehensive guidance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VM4K1XR

More documents and user manuals: **https://manuals.plus/**