Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RP510FZ

LEXIBOOK Disney Frozen 2 Projector Alarm Clock User Manual

Model: RP510FZ

1. Product Overview

The LEXIBOOK Disney Frozen 2 Projector Alarm Clock is designed to provide time display, alarm functions, sound effects, and a night light feature. It projects the time onto the ceiling for easy viewing.



Image 1.1: Front view of the LEXIBOOK Disney Frozen 2 Projector Alarm Clock, showing Elsa and Anna figures, digital display, and control buttons.

2. Setup

2.1. Battery Installation

This device requires 4 LR6/AA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the underside of the alarm clock.
2. Using a screwdriver, carefully open the battery compartment.
3. Insert 4 new LR6/AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use new batteries of the same type. Do not mix old and new batteries or different types of batteries.

Remove batteries if the device will not be used for an extended period.

3. Operating Instructions

3.1. Setting the Time

Refer to the buttons on the front of the device:

- Press the **MODE** button to cycle through time setting, alarm setting, and normal display modes.
- When in time setting mode (usually indicated by flashing digits), use the**UP** and **DOWN** arrow buttons to adjust the hours and minutes.
- Press **MODE** again to confirm and move to the next setting or exit.

3.2. Time Projection

To project the current time onto the ceiling:

- Press the **PROJECT** button located on the top of the device.
- The time will be projected onto the ceiling. For optimal clarity, ensure the room is dark and the projector lens is clean.

3.3. Sound Effects

The alarm clock features 4 distinct sound effects:

- Press the Elsa & Anna character figures on the top of the device to activate the sound effects.

3.4. Night Light Function

For a soft, ambient light:

- Press the base of the alarm clock.
- The night light will illuminate and remain active for up to 15 minutes before automatically turning off.



Image 3.1: The alarm clock functioning as a night light in a child's bedroom.

3.5. Alarm and Snooze Function

To set and use the alarm:

- Press the **MODE** button until the alarm time setting appears (often indicated by an alarm icon).
- Use the **UP** and **DOWN** arrow buttons to set the desired alarm time.
- Press **MODE** to confirm.
- When the alarm sounds, press the **SNOOZE** button (often integrated with another button or a dedicated button) to temporarily silence it. The alarm will sound again after a few minutes.
- To turn off the alarm completely, locate the alarm ON/OFF switch or press the appropriate button as per the device's specific design.

3.6. Volume Control

To adjust the volume of sound effects and alarm:

- Use the **VOL** button (or similar labeled button) to increase or decrease the sound level.

Your browser does not support the video tag.

Video 3.2: An official product video demonstrating the features and operation of the Lexibook Disney Frozen 2 Projector Alarm Clock.

4. Maintenance

4.1. Cleaning

To maintain the appearance and functionality of your alarm clock:

- Wipe the device with a soft, slightly damp cloth.

- Do not use abrasive cleaners or solvents, as these may damage the surface.
- Ensure the projector lens is free of dust and smudges for clear time projection.

4.2. Battery Replacement

When the display dims or functions become erratic, it is time to replace the batteries. Follow the battery installation steps in Section 2.1.

5. Troubleshooting

- **No Power/Display:** Ensure batteries are correctly installed and are not depleted. Replace with new batteries if necessary.
- **Projection Unclear/Faint:** Check that the room is sufficiently dark. Clean the projector lens gently with a soft cloth. Ensure the device is placed at an appropriate distance from the projection surface.
- **Alarm Not Sounding:** Verify that the alarm time is set correctly and the alarm function is activated (not in OFF mode). Check volume settings.
- **Sound Effects Not Working:** Ensure batteries have sufficient power. Press the character figures firmly.
- **Night Light Not Activating:** Press the base firmly. Check battery level.

6. Specifications

Feature	Detail
Brand	LEXiBOOK
Model Number	RP510FZ
Display Type	Digital
Special Features	Alarm, Snooze, Time Projection, Night Light, Sound Effects
Product Dimensions	6.3"W x 6.69"H
Power Source	Battery Powered (4 LR6/AA batteries, not included)
Material	Plastic (Acrylonitrile Butadiene Styrene)
Item Weight	14.1 ounces
Mounting Type	Tabletop / Ceiling Mount (for projection)

7. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact LEXiBOOK customer service directly. Contact details can typically be found on the manufacturer's official website.

© 2023 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VWV8P95

More documents and user manuals: **https://manuals.plus/**