Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Power Craze 1344980

Power Craze Remote Control Car CT-2022 Blue

Model: 1344980

Introduction

Thank you for purchasing the Power Craze Remote Control Car CT-2022 Blue. This manual provides important information for the safe operation, setup, maintenance, and troubleshooting of your new vehicle. Please read it thoroughly before use and keep it for future reference.

Important Safety Information

- **CAUTION ELECTRIC TOY:** Not recommended for children under 8 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.
- **SUPERVISION ADVISED:** Adult supervision is recommended for younger users.
- Unplug the vehicle when not in use to prevent accidental operation and battery drain.
- Keep fingers, hair, and loose clothing away from moving wheels and gears.
- Do not operate near water or in wet conditions.
- Do not operate in crowded areas or near pedestrians.

Package Contents

Ensure all items listed below are present in your package:

- 1 x Power Craze Remote Control Car
- 1 x Remote Control
- 1 x USB Charger
- 1 x Screwdriver



Image: The Power Craze Remote Control Car CT-2022 Blue shown in its retail box, highlighting key features and accessories.

Setup

1. Controller Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Use the included screwdriver to open the battery cover.
3. Insert 2 x 'AA' batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery cover and secure it with the screw.



Image: The back of the product packaging, illustrating the remote control and various features of the car, including the controller's battery compartment.

2. Charging the Vehicle Battery

1. Ensure the vehicle's power switch is in the OFF position.
2. Connect the vehicle's battery to the included USB charger.
3. Plug the USB charger into a standard USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light on the USB charger will illuminate during charging and turn off or change color when fully charged.
5. Charging time may vary. Do not overcharge the battery.

3. Pairing the Controller

1. Turn on the remote control.

2. Turn on the power switch on the vehicle.
3. The controller and vehicle should automatically pair. If not, turn both off and repeat the steps.

Operating Your Vehicle

Basic Controls

- **Forward/Backward:** Push the throttle trigger forward to move the car forward. Pull it backward to reverse.
- **Steering:** Turn the steering wheel on the controller left or right to steer the car in the corresponding direction.

Speed Control and Headlights

- This vehicle features proportional speed control, allowing for precise acceleration.
- The functional headlights will illuminate when the vehicle is in operation, enhancing visibility and realism.



Image: The Power Craze Remote Control Car CT-2022 Blue in action, driving outdoors with its headlights on, showcasing its design and functionality.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe down the vehicle after use. Do not use water or chemical cleaners.
- **Storage:** Store the vehicle and controller in a cool, dry place away from direct sunlight when not in use. Remove batteries from the controller if storing for extended periods.
- **Battery Care:** Always allow the vehicle battery to cool down before recharging. Do not leave batteries charging unattended.

Troubleshooting

Problem	Possible Cause	Solution
Vehicle does not respond.	Vehicle or controller is off. Low battery in vehicle or controller. Not paired.	Ensure both are ON. Charge vehicle battery. Replace controller batteries. Re-pair the controller and vehicle.
Short operating time.	Battery not fully charged. Old battery.	Ensure battery is fully charged. Consider replacing the vehicle battery if it's old and not holding a charge.
Vehicle moves slowly.	Low battery. Obstruction in wheels/gears.	Charge vehicle battery. Check for and remove any debris from wheels and gears.
Loss of control/interference.	Operating too far from controller. Other 2.4 GHz devices nearby.	Operate within recommended range. Move to an area with less interference.

Specifications

Feature	Detail
Model Number	1344980
Control Frequency	2.4 GHz
Max Speed	Up to 28 km/h
Product Dimensions	22.86 x 15.24 x 7.62 cm
Product Weight	340.19 g
Manufacturer Recommended Age	8 months and up (Note: Safety warning advises 8 years and up)
Batteries Required	Yes (for controller, not included)
First Available Date	September 2, 2019

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Power Craze website. Keep your purchase receipt as proof of purchase.

© 2024 Power Craze. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07W638FJV

More documents and user manuals: **https://manuals.plus/**