Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard BB2530

Billboard Indoor/Outdoor Bluetooth Wireless Party Speaker User Manual

Model: BB2530

Product Overview

The Billboard Indoor/Outdoor Bluetooth Wireless Party Speaker with LED (Model BB2530) is designed to provide high-quality audio for various settings, both indoors and outdoors. It features Bluetooth connectivity, multiple input options, and integrated LED lighting to enhance your audio experience.



Figure 1: Angled view of the Billboard Party Speaker, highlighting its compact design and front speaker grille.

What's Included

- 1 x Billboard Indoor/Outdoor Bluetooth Wireless Party Speaker (Model BB2530)
- 1 x AC Power Cord

Key Features

- **Bluetooth Connectivity:** Seamlessly stream audio from your Android, Apple, or other Bluetooth-enabled devices.
- **Multiple Input Options:** Supports USB flash drives, TF (microSD) cards, and Auxiliary (AUX) input for versatile playback.
- **Integrated LED Lighting:** Built-in colorful LED lights enhance the party atmosphere.
- **Extended Range:** Maintain a stable Bluetooth connection up to 33 feet (10 meters).
- **Rechargeable Battery:** Enjoy up to 3 hours of continuous playtime on a full charge.
- **Compact and Portable Design:** Measures approximately 10.8" W x 8.7" D x 16.3" H, making it suitable for various indoor and outdoor spaces.
- **High Power Output:** Delivers up to 180 Watts of speaker maximum output power.

Component Identification



Figure 2: Rear control panel of the speaker.

1. **M.VOL (Master Volume) Knob:** Adjusts the overall volume of the speaker.
2. **ECHO Knob:** Controls the echo effect for microphone input.
3. **USB Port:** For playing audio from USB flash drives.
4. **TF Card Slot:** For playing audio from TF (microSD) cards.
5. **Digital Display:** Shows current mode, track number, or radio frequency.
6. **Power/Volume Knob:** Turns the speaker ON/OFF and adjusts the main volume.
7. **Mic. IN Port:** 6.35mm input for connecting a microphone.
8. **Audio Input (AUX) Port:** 3.5mm input for connecting external audio devices.
9. **Charge Indicator LED:** Blue indicates full charge, Red indicates charging.
10. **AC Power Input:** For connecting the AC power cord to charge the speaker or power it.

Setup

Initial Charging

Before first use, fully charge the speaker. Connect the supplied AC power cord to the speaker's AC Power Input and plug the other end into a standard wall outlet. The Charge Indicator LED will illuminate red during charging and turn blue when fully charged. A full charge provides up to 3 hours of playtime.

Placement

Place the speaker on a stable, flat surface. Ensure adequate ventilation around the unit. While designed for indoor/outdoor use, avoid direct exposure to rain or extreme weather conditions as the speaker is not waterproof.



Figure 3: Speaker dimensions for placement consideration.

Operating Instructions

Powering On/Off

To power on the speaker, rotate the **Power/Volume Knob** clockwise until you hear a click and the digital display illuminates. To power off, rotate the knob counter-clockwise until it clicks off.

Adjusting Volume

The overall volume is controlled by the **M.VOL (Master Volume) Knob**. For fine-tuning, the **Power/Volume Knob** also adjusts the main volume.

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated on the digital display). If not, press the Mode button (if available, not explicitly listed but implied by "digital display shows current mode") to cycle to Bluetooth mode.
2. On your smartphone or Bluetooth-enabled device, enable Bluetooth and search for available devices.
3. Select "Billboard BB2530" (or similar name) from the list of devices.
4. Once paired, the speaker will emit an audible confirmation, and you can begin streaming audio.

USB/TF Card Playback

1. Insert a USB flash drive into the **USB Port** or a TF (microSD) card into the **TF Card Slot**.
2. The speaker should automatically switch to USB or TF card mode and begin playing audio files. If not, press the Mode button to select the correct input.
3. Use the playback controls (e.g., Play/Pause, Next/Previous Track - not explicitly listed but standard for such devices) to manage your music.

Auxiliary Input (AUX)

1. Connect one end of a 3.5mm audio cable (not included) to the **Audio Input (AUX) Port** on the speaker.
2. Connect the other end of the cable to the audio output jack of your external device (e.g., MP3 player, laptop).
3. The speaker should automatically switch to AUX mode. If not, press the Mode button to select AUX input.
4. Control playback and volume from your connected external device.

Microphone Use

1. Plug a microphone (not included) into the **Mic. IN Port**.
2. Adjust the microphone volume and echo effect using the dedicated knobs on the control panel.

LED Lights

The speaker features built-in colorful LED lights that activate automatically when the speaker is powered on. There is no explicit control for the LED lights mentioned in the specifications, implying they are always on when the speaker is active.

Maintenance

Cleaning

Wipe the exterior of the speaker with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid spraying liquids directly onto the speaker.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to fully charge the battery before storing to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted. Power cable not connected properly.	Charge the speaker using the AC power cord. Ensure the AC power cord is securely connected to both the speaker and a working power outlet.

Problem	Possible Cause	Solution
No sound from speaker.	Volume is too low. Incorrect input mode selected. Device not properly connected/paired.	Increase the **M.VOL** and **Power/Volume** knobs. Press the Mode button to select the correct input (Bluetooth, USB, TF, AUX). For Bluetooth, ensure the device is paired. For AUX, ensure the cable is fully inserted.
Bluetooth connection is unstable or disconnects.	Device is out of range. Interference from other devices.	Move the Bluetooth device closer to the speaker (within 33 feet). Move the speaker away from other wireless devices or large metal objects.
USB/TF card not playing.	Incorrect file format. Card/drive not inserted correctly. Corrupted files.	Ensure audio files are in a compatible format (e.g., MP3). Re-insert the USB drive or TF card firmly. Try a different USB drive or TF card with known working files.

Specifications

Feature	Detail
Model Name	Billboard Indoor/Outdoor Bluetooth Wireless Party Speaker with LED, Black
Model Number	BB2530
Brand	Billboard
Speaker Type	Floorstanding
Speaker Maximum Output Power	180 Watts
Connectivity Technology	Auxiliary, Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	33 Feet (10 meters)
Power Source	Battery Powered (Rechargeable)
Battery Life	Up to 3 Hours
Product Dimensions (D x W x H)	8.7" x 10.8" x 16.3"
Item Weight	6.98 Pounds
Waterproof	No
UPC	680988245305
Manufacturer	ESI Cellular

Warranty Information

This product comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and claims procedures, please refer to the warranty card included in the product packaging or contact the manufacturer directly.

Support

For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact the manufacturer, ESI Cellular. Contact information may be found on the product packaging or their official website.
Manufacturer: ESI Cellular
Note: Specific contact details (phone, email, website) are not provided in this manual. Please refer to product packaging or manufacturer's official resources.

© 2024 Billboard. All rights reserved.
Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07WC9Z8QG

More documents and user manuals: **https://manuals.plus/**