Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER MD6461

PK Power AC DC Adapter User Manual for Memorex MD6461 Portable CD Player

Model: MD6461 Compatible Power Supply

1. Introduction

This manual provides essential instructions for the safe and efficient use of your PK Power AC DC Adapter, specifically designed for the Memorex MD6461 Portable Home CD Player. Please read this manual thoroughly before using the product to ensure proper operation and longevity.



Figure 1: PK Power AC DC Adapter. This image shows the main adapter unit with its attached power cable, coiled neatly.

2. Safety Information

- Ensure the adapter's input voltage (100-240V) matches your local power supply.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter yourself. Refer to qualified service personnel.
- Keep out of reach of children.
- Unplug the adapter from the wall outlet when not in use for extended periods.

3. Setup Instructions

1. **Verify Compatibility:** Confirm that your device is a Memorex MD6461 Portable Home CD Player. This adapter is

specifically designed for this model.

2. **Connect to Device:** Locate the power input port on your Memorex MD6461 CD Player. Carefully insert the adapter's output connector into this port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the adapter's AC plug into a standard wall power outlet (100-240V, 50/60Hz).
4. **Power On:** Once connected, your Memorex MD6461 CD Player should receive power. You can now power on your device as per its own operating instructions.



Figure 2: Close-up of the adapter's plug showing input specifications. This image displays the AC plug and a label with input voltage details.

4. Operating Instructions

The PK Power AC DC Adapter operates automatically once connected to a power source and your compatible device. It converts the AC wall power to the DC power required by your Memorex MD6461 CD Player.

- Ensure all connections are secure before powering on your CD player.
- The adapter is designed for continuous use, but it is recommended to unplug it when not in use for extended periods.

5. Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Inspection:** Periodically inspect the power cord and connectors for any signs of damage, fraying, or bending. If damage is observed, discontinue use and replace the adapter.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Adapter not properly plugged into wall outlet or device.	Ensure both ends of the adapter are securely connected. Try a different wall outlet.
Device still does not power on after checking connections.	Wall outlet is not supplying power.	Test the wall outlet with another device. Check circuit breaker.
Adapter feels unusually hot.	Overload or internal fault.	Immediately unplug the adapter. Discontinue use and contact customer support.
Adapter connector does not fit the device.	Incorrect adapter model or device model.	Verify that your device is indeed a Memorex MD6461. If not, this adapter is incompatible.

7. Specifications

- **Input:** 100-240V AC, 50-60Hz
- **Output:** DC (specific voltage/amperage determined by device requirements, designed for Memorex MD6461)
- **Certifications:** CE, FCC, RoHS compliant
- **Protection Features:** OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
- **Compatible Device:** Memorex MD6461 Portable Home CD Player
- **Manufacturer:** PKPOWER
- **Item Weight:** Approximately 4 ounces (113 grams)

8. Warranty and Support

PK Power products are manufactured to high standards. While specific warranty details are not provided in this manual, PK Power offers dedicated customer service.

- **Customer Service:** For any questions, concerns, or issues with your adapter, please contact PK Power customer service. Our friendly and reliable customer service team aims to respond within 24 hours.
- **Contact Information:** Please refer to the seller's information on the platform where you purchased the product for the most current contact details, or visit the official PKPOWER store page.
- **Online Store:** PKPOWER Amazon Store

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07X92JPXL

More documents and user manuals: **https://manuals.plus/**