Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Corsair CA-9011202-NA

Corsair VOID RGB ELITE Wireless Gaming Headset

Brand: Corsair | Model: CA-9011202-NA

Product Overview

Immerse yourself in the action with the Corsair VOID RGB ELITE Wireless Gaming Headset. Featuring custom-tuned 50mm neodymium audio drivers, this headset delivers immersive 7.1 surround sound on PC. Designed for lasting comfort, it includes microfiber mesh fabric and memory foam ear pads. Connect wirelessly to your PC or PS4 with a low-latency 2.4GHz wireless connection, offering a range of up to 40ft and up to 16 hours of battery life. An omnidirectional microphone with an LED mute indicator ensures clear vocal clarity. The headset boasts a distinctive design and durable construction with aluminum yokes, complemented by fully customizable RGB lighting on each ear cup. Powerful Corsair iCUE software provides comprehensive control over equalizer settings, 7.1 surround sound, and RGB lighting.



Figure 1: The Corsair VOID RGB ELITE Wireless Gaming Headset, showcasing its white and black design with the microphone extended.

Key Features

- **Stunning Sound:** Custom-tuned 50mm high-density neodymium audio drivers with an expanded frequency range of 20Hz-30,000Hz.
- **Enduring Comfort:** Breathable microfiber mesh fabric and plush memory foam earpads for long gaming sessions.
- **Low-Latency 2.4GHz Wireless:** Connect wirelessly to PC or PS4* with the included USB adapter.
- **Optimized Omnidirectional Microphone:** Picks up voice with exceptional clarity, featuring a flip-up mute function and a built-in LED mute indicator.
- **Durable Construction:** Built with aluminum yokes for long-lasting use.

What's Included

Your Corsair VOID RGB ELITE Wireless Gaming Headset package contains the following items:

- Corsair VOID RGB ELITE Wireless Headset

- USB Wireless Adapter



Figure 2: The Corsair VOID RGB ELITE Wireless Headset and its accompanying USB adapter, as typically found in the product packaging.

Setup Guide

Charging the Headset

Before initial use, fully charge your headset. Connect the headset to a USB port on your PC or a USB wall adapter using the provided charging cable. The headset's LED indicator will show charging status and turn solid when fully charged. A full charge provides up to 16 hours of battery life.

Wireless Connection (PC/PS4)

1. Plug the included USB Wireless Adapter into an available USB port on your PC or PlayStation 4 console.
2. Power on your Corsair VOID RGB ELITE Wireless Headset by pressing and holding the power button located on the left earcup.
3. The headset will automatically pair with the USB adapter. A solid LED indicator on both the headset and adapter confirms a

successful connection.

4. For PC users, ensure the headset is selected as the default audio output and input device in your operating system's sound settings.



Figure 3: Wireless connectivity in action, showing the headset being used during a gaming session with a PC setup.

Operating Your Headset

Headset Controls

The Corsair VOID RGB ELITE Wireless Headset features intuitive on-ear controls for quick adjustments:

- **Volume Wheel:** Located on the left earcup, rotate the wheel up or down to adjust the master volume.
- **Microphone Mute:** The omnidirectional microphone features a flip-up mute function. Flipping the microphone boom up will mute your microphone, and an LED indicator on the microphone tip will illuminate red when muted. Flipping it down will unmute.
- **Power Button:** Press and hold to power the headset on or off.



Figure 4: Detailed view of the headset's controls, including the volume wheel and microphone mute button for easy access during use.

Corsair iCUE Software Integration

For advanced customization and control, download and install the Corsair iCUE software on your PC. iCUE allows you to:

- Adjust equalizer settings for personalized audio profiles.
- Toggle 7.1 surround sound on or off for immersive audio experiences (PC only).
- Customize the dynamic RGB lighting on each ear cup with various effects and colors.
- Manage device settings and firmware updates.



Figure 5: The headset showcasing its dynamic RGB lighting, controlled via the Corsair iCUE software for personalized aesthetics.

Technical Specifications

Feature	Specification
Brand	Corsair
Model Name	VOID RGB ELITE
Item Model Number	CA-9011202-NA
Color	White
Connectivity Technology	Wireless (2.4GHz via USB Dongle)
Compatible Devices	PC, PS4
Audio Driver Size	50 Millimeters

Frequency Response	20 Hz - 30 kHz
Battery Life	Up to 16 Hours
Wireless Range	Up to 40ft (approx. 12m)
Microphone Type	Omnidirectional, Flip-up Mute
Material	Aluminum, Microfiber, Mesh, Memory Foam
Item Weight	14.1 ounces (approx. 399g)
Product Dimensions (LxWxH)	7.87 x 3.74 x 7.87 inches

Care and Maintenance

To ensure the longevity and optimal performance of your Corsair VOID RGB ELITE Wireless Headset, follow these care guidelines:

- **Cleaning Ear Pads:** The microfiber mesh fabric and memory foam ear pads can be gently wiped with a damp, lint-free cloth. Avoid using harsh chemicals or abrasive cleaners.
- **General Cleaning:** Use a soft, dry cloth to clean the exterior surfaces of the headset, including the aluminum yokes and plastic components.
- **Storage:** When not in use, store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the headset.
- **Cable Care:** Handle the charging cable and USB adapter with care. Avoid sharp bends or excessive pulling.

Troubleshooting

If you encounter issues with your headset, try the following solutions:

- **No Sound/Microphone Not Working:**
  - Ensure the headset is powered on and fully charged.
  - Verify the USB Wireless Adapter is securely plugged into your PC/PS4.
  - Check your system's sound settings to ensure the Corsair VOID RGB ELITE is selected as the default audio output and input device.
  - Confirm the microphone is not muted (LED on mic tip should not be red).
  - Restart your PC/PS4.
- **Connectivity Issues:**
  - Ensure the headset and adapter are within the 40ft wireless range.
  - Avoid obstructions between the headset and adapter that might interfere with the signal.
  - Try plugging the USB adapter into a different USB port.
  - If pairing is lost, refer to the full user manual for re-pairing instructions.
- **RGB Lighting Not Working:**
  - Ensure Corsair iCUE software is installed and running on your PC.
  - Check iCUE settings for RGB lighting customization and ensure effects are enabled.

Warranty and Support

For detailed warranty information, technical support, or further assistance, please refer to the official documents provided by Corsair:

- User Guide (PDF)
- Safety Information (PDF)
- User Manual (PDF)

You can also visit the official Corsair support website for the latest drivers, FAQs, and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XF2TGGK

More documents and user manuals: **https://manuals.plus/**