Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC Adapter

PK Power AC Adapter User Manual

Model: AC Adapter

1. Introduction

This manual provides essential information for the safe and effective use of your PK Power AC Adapter. This adapter is designed to provide power for the 5000 lumens Hyper Tough Rechargeable Work Light 7047.

2. Safety Information

Please read all safety instructions before using the adapter. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose to rain or moisture.
- **Proper Voltage:** Ensure the input voltage (100-240V 50-60Hz) matches your power supply.
- **Compatibility:** Use only with compatible devices, specifically the 5000 lumens Hyper Tough Rechargeable Work Light 7047. Using with incompatible devices may cause damage.
- **Ventilation:** Do not cover the adapter during operation. Ensure adequate ventilation to prevent overheating.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact support for replacement.
- **Children:** Keep out of reach of children.
- **Protection Features:** This adapter includes Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to ensure safe operation.

3. Product Overview



Figure 3.1: Front view of the PK Power AC Adapter with its attached power cord.



Figure 3.2: Dimensions of the AC Adapter, showing approximate measurements of 1.58 inches by 2.92 inches by 1.18 inches.



Figure 3.3: Angled view of the AC Adapter, highlighting the barrel connector and power prongs.

4. Setup

1. **Unpack:** Carefully remove the AC adapter from its packaging. Inspect for any visible damage.
2. **Identify Device:** Ensure the device you intend to power is the 5000 lumens Hyper Tough Rechargeable Work Light 7047.
3. **Connect to Device:** Insert the barrel connector end of the adapter cable into the charging port of your Hyper Tough Work Light. Ensure a snug fit.
4. **Connect to Power Outlet:** Plug the AC adapter's prongs into a standard 100-240V wall power outlet.
5. **Verify Connection:** Confirm that the work light begins charging (refer to your work light's manual for charging indicators).

5. Operating Instructions

The PK Power AC Adapter is designed for straightforward operation. Once connected, it automatically supplies power to the compatible device.

- **Charging:** When connected to the Hyper Tough Work Light, the adapter will provide the necessary power for charging its internal battery.
- **Direct Power:** If the work light supports direct operation while plugged in, the adapter will supply continuous power.
- **Disconnection:** To disconnect, first unplug the adapter from the wall outlet, then disconnect the barrel connector from the device.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your AC adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter, cable, and connector for any signs of wear, cuts, or damage. If damage is found, discontinue use and replace the adapter.

7. Troubleshooting

Problem	Possible Cause	Solution
Adapter not providing power.	No power from outlet. Loose connection. Incompatible device. Damaged adapter.	Test outlet with another device. Ensure all connections are secure. Verify device is the Hyper Tough Work Light 7047. Inspect adapter for damage; replace if necessary.
Adapter gets unusually hot.	Poor ventilation. Overload or short circuit. Internal fault.	Ensure adapter is not covered. Disconnect immediately. Do not use if overheating persists. Discontinue use and replace.
Device not charging.	Adapter not fully plugged in. Device charging port issue. Adapter fault.	Check all connections. Consult the work light's manual or support. Test with another compatible adapter if available.

8. Specifications

- **Input:** 100-240V AC, 50-60Hz
- **Output:** Matches OEM specification
- **Compatibility:** Designed for 5000 lumens Hyper Tough Rechargeable Work Light 7047
- **Safety Certifications:** CE / FCC / RoHS certified
- **Protection:** OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
- **Weight:** Approximately 3 ounces

- **Dimensions:** Approximately 1.58 in x 2.92 in x 1.18 in

9. Warranty and Support

PK-Power products are designed for reliability. For any issues or questions, please contact our customer service.

- **Customer Service:** Our friendly and reliable customer service will respond to you within 24 hours.
- **Returns:** The buybox winner indicates a 30-day return policy for refund/replacement. Please refer to your purchase platform for specific return instructions.
- **Manufacturer:** PKPOWER

For further assistance, please visit the PKPOWER Store on Amazon.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XNSCSGL

More documents and user manuals: **https://manuals.plus/**