**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Braun BT5240**

# Braun Beard Trimmer BT5240 User Manual

Model: BT5240

## Introduction

This manual provides comprehensive instructions for the safe and effective use of your Braun Beard Trimmer BT5240. Designed for precision and versatility, this cordless and rechargeable trimmer allows for effortless beard trimming and hair clipping. Please read all instructions carefully before first use and retain this manual for future reference.




This image displays the complete set of the Braun BT5240 beard trimmer. It includes the main trimmer unit, two comb attachments (1-10mm and 11-20mm), a small cleaning brush, and a Gillette ProGlide manual razor.

## Safety Information

**Warning:**

- Keep this appliance away from children.
- Do not immerse the main device in water. Only the trimmer head and combs are washable.
- Ensure the appliance is fully dry before charging.
- Do not use the appliance if it is damaged.

## Package Contents

Your Braun BT5240 package should contain the following items:

- 1 x Braun BT5240 Beard Trimmer & Hair Clipper
- 1 x Short Beard Comb (0.5-10mm)
- 1 x Long Beard Comb (11-20mm)
- 1 x Gillette Fusion5 ProGlide Razor
- 1 x Smart Plug Charger
- 1 x Cleaning Brush
- 1 x User Manual

## Setup

### 1. Charging the Trimmer

1. Connect the smart plug charger to the trimmer and then to a power outlet.
2. Allow approximately 1 hour for a full charge, which provides up to 100 minutes of cordless trimming time.
3. The charging indicator light will show the charging status.

### 2. Attaching Comb Attachments

1. Ensure the trimmer is turned off.
2. Select the desired comb attachment (0.5-10mm for short to medium beards, 11-20mm for longer beards or hair styles).
3. Align the comb with the trimmer head and push it down until it clicks securely into place.
4. To remove, gently pull the comb attachment upwards from the trimmer head.

## Operating Instructions

### 1. Trimming Beard and Hair

1. Attach the appropriate comb for your desired length.
2. Use the precision dial to select one of the 39 length settings in 0.5mm step sizes.
3. Turn on the trimmer by pressing the power button.
4. Move the trimmer against the direction of hair growth, ensuring even contact with the skin.
5. For precise lines and edges on the neck and cheeks, remove the comb attachment and use the main trimmer head directly.

### 2. Using the Gillette Fusion5 ProGlide Razor

The included Gillette Fusion5 ProGlide razor can be used for a clean shave on areas like the neck, cheeks, or for detailing edges after trimming.

- Apply shaving gel or foam to the area to be shaved.
- Shave with light, even strokes.
- Rinse the razor blade frequently during use.

## Maintenance

### 1. Cleaning the Trimmer

1. Turn off and unplug the trimmer before cleaning.

2. Remove the comb attachment and the trimmer head.
3. Rinse the trimmer head and comb attachments under running water.
4. Use the provided cleaning brush to remove any trapped hairs from the trimmer head and inside the main unit.
5. Allow all parts to air dry completely before reassembling or storing.

### 2. Blade Care

The Braun BT5240 features lifetime sharp blades. Regular cleaning helps maintain their performance. Oiling the blades is generally not required for this model, but refer to the specific instructions in your physical user manual for any additional recommendations.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Trimmer does not turn on. | Battery is discharged. | Charge the trimmer for at least 1 hour. |
| Reduced trimming performance. | Hair buildup in the trimmer head or dull blades. | Clean the trimmer head and comb attachments thoroughly. Ensure blades are free of debris. |
| Comb attachment slips off. | Comb not securely attached. | Ensure the comb clicks firmly into place. Exercise caution during use. |

## Specifications

- **Model:** BT5240 (Item model number: 63)
- **Brand:** Braun
- **Power Source:** Cordless & Rechargeable (Corded Electric for charging)
- **Battery:** 1 AAA battery (included)
- **Charge Time:** 1 hour for 100 minutes cordless use
- **Length Settings:** 39 precision length settings in 0.5mm steps
- **Product Dimensions:** 5.39 x 2.24 x 9.92 inches
- **Item Weight:** 0.7 Pounds (11.2 ounces)
- **Color:** Black/Blue
- **UPC:** 069055887998
- **Manufacturer:** Procter & Gamble

## Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Braun website. For customer support, contact Braun customer service through their official channels. Keep your purchase receipt as proof of purchase for warranty claims.

## Official Product Videos

No official product videos from the seller were available with sufficient metadata for embedding in this manual.

© 2023 Braun. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B07XQBZ3J8**

More documents and user manuals: **https://manuals.plus/**