Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BT7240

Braun BT7240 Beard Trimmer and Hair Clipper User Manual

Model: BT7240

Introduction

This user manual provides detailed instructions for the safe and effective use of your Braun BT7240 Beard Trimmer and Hair Clipper. Please read all instructions carefully before first use and retain for future reference. The BT7240 is designed for effortless styling, featuring a precision dial for length settings, lifetime sharp metal blades, and a Li-ion battery for cordless operation.



Image: Braun BT7240 Beard Trimmer and Hair Clipper with its complete set of accessories, including various combs, detail trimmer, mini foil shaver, charging stand, and Gillette Fusion5 ProGlide razor.

Safety Information

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following: Read all instructions before using this appliance. When disconnected, the hand-held part of this appliance may be cleaned under water.

DANGER: To reduce the risk of electric shock:

- Use only in dry condition.
- Do not submerge in water.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place, store or charge the appliance where it can fall or be pulled into a tub or sink. Do not place in or drop

into water or other liquid.

- Except when charging, always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning.
- This appliance is provided with a special cord set with integrated Safety Extra Low Voltage power supply. Do not exchange or manipulate any part of it.
- Do not use an extension cord with this appliance.

WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons:

- Close supervision is necessary when this appliance is used by, on, or near children or persons with disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if the power supply has been dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening of this appliance.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use this appliance with a damaged or broken cutter or comb, as serious skin injuries may occur.
- Always attach plug to appliance first, then to outlet. To disconnect, turn all controls off, then remove plug from outlet.
- When plugging to an electrical outlet outside North America, use a plug adapter to match the outlet's pin configuration.
- Caution: The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100 DegreeC (212 DegreeF) or incinerate.
- To recharge the battery, only use the detachable power supply provided with this appliance. If the appliance is marked 491 or 492, only use Braun power supplies coded 491-XXXX or 492-XXXX.

Setup

1. Charging the Trimmer

Before first use, fully charge the trimmer. Connect the smart plug charger to the charging stand, then place the trimmer onto the stand. The charging indicator light will illuminate. A full charge takes approximately 1 hour and provides up to 100 minutes of cordless trimming. A 5-minute quick charge is available for a single trim.

2. Attaching and Detaching Trimmer Heads and Combs

The BT7240 comes with multiple attachments for versatile styling:

- **Main Trimmer Head:** This is the primary head for general trimming.
- **Precision Beard & Hair Combs:** Two combs are included: one for short lengths (1-10mm) and one for longer lengths (11-20mm). These attach directly to the main trimmer head.
- **Detail Trimmer Head:** For precise lines and intricate styling.
- **Mini Foil Shaver:** For a clean shave in small, delicate areas.

To attach a head or comb, align it with the trimmer body and gently push until it clicks into place. To detach, pull the attachment away from the trimmer body.



Image: The Braun BT7240 trimmer showcasing its main head and two precision comb attachments, designed for different hair lengths.

Operating Instructions

1. Adjusting Trimming Length with the Precision Dial

The BT7240 features a precision dial that allows you to select from 39 length settings in 0.5 mm step sizes. Attach the desired comb (1-10mm or 11-20mm) to the main trimmer head. Rotate the precision dial to select your preferred length setting. The comb will adjust its position accordingly.



Image: A close-up view of the Braun BT7240's precision dial, highlighting the 39 length settings available in 0.5mm increments for precise control.

2. Trimming Your Beard or Hair

With the desired comb and length setting, turn on the trimmer. Hold the trimmer against your skin with the comb flat against the surface. Move the trimmer against the direction of hair growth for an even trim. For best results, ensure your hair is dry.



Image: A man demonstrating the use of the Braun BT7240 trimmer to maintain his beard, showing the ergonomic design and ease of use.

3. Edging and Detailing

For precise lines and edges, remove the comb attachment and use the main trimmer head directly against the skin. For very fine detailing or shaping, attach the dedicated detail trimmer head. Use gentle, controlled strokes to achieve desired lines.

4. Clean Shave for Small Areas

For a completely clean shave in small areas, such as around the edges of your beard or mustache, attach the mini foil shaver head. Use light pressure and move the shaver in short, circular motions.

5. Official Product Video Demonstration

Your browser does not support the video tag.

Video: An official Braun demonstration of the BT7240 Beard Trimmer, showcasing its features including trimming, edging, detailing, washing, and charging capabilities.

Maintenance

1. Cleaning the Trimmer

The Braun BT7240 is fully washable. After each use, remove the trimmer head and rinse it, along with the comb attachments, under running water. Use the included cleaning brush to remove any trapped hairs from the blades and inside the trimmer head. Ensure all parts are dry before reassembling or storing.

2. Blade Care

The trimmer features lifetime sharp metal blades designed for durability and consistent performance. No oiling or special maintenance is required for the blades.



Image: A detailed view of the Braun BT7240's lifetime sharp metal blades, emphasizing their robust construction for long-lasting sharpness.

Troubleshooting

If you encounter any issues with your Braun BT7240, please consider the following general advice:

- **Trimmer not turning on:** Ensure the battery is fully charged. Connect the trimmer to the charger and allow it to charge for at least 5 minutes before attempting to turn it on again.
- **Poor trimming performance:** Check if the blades are clean and free of hair. Rinse the trimmer head and comb under running water and use the cleaning brush. Ensure the comb attachment is securely fitted and the desired length setting is selected.
- **Battery not holding charge:** Ensure you are using the original Braun smart plug charger and charging stand. If the issue persists, contact Braun customer support.

For more specific troubleshooting or persistent issues, refer to the full user manual included in your product packaging or contact Braun customer service.

Specifications

Feature	Detail
Model Number	BT7240
Brand	Braun
Power Source	Battery Powered (Li-ion)
Battery Type	1 AA batteries required (included)
Cordless Trimming Time	Up to 100 minutes on 1 hour charge
Quick Charge	5 minutes for one trim
Length Settings	39 (0.5 mm increments)
Blades	Lifetime Sharp Metal Blades
Washable	Fully washable
Color	Silver
Item Weight	14.56 ounces
Product Dimensions	8.86 x 2.42 x 8.74 inches
UPC	069055888902



Image: The Braun BT7240 product packaging, illustrating key features such as 39 length settings, precision wheel, Li-ion battery, and lifetime sharp metal blades.

Warranty and Support

Your Braun BT7240 Beard Trimmer and Hair Clipper comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For customer support, service, or to inquire about protection plans, please visit the official Braun website or contact their customer service line. Keep your proof of purchase for warranty claims.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XQK6PNH

More documents and user manuals: **https://manuals.plus/**