Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRIXIE 203211

TRIXIE Premium Dog Harness Instruction Manual

Model: 203211, Size: XS-S

1. Product Overview

The TRIXIE Premium Dog Harness is designed for comfort and security, featuring continuously adjustable straps and a flexible belly strap. This harness is suitable for small dogs, specifically in size XS-S.



Image: TRIXIE Premium Dog Harness in coral, size XS-S. This image displays the harness laid flat, showing its adjustable straps and buckles.

Key Features:

- Continuously adjustable chest strap.
- Flexible and adjustable belly strap.
- Two buckles on the belly strap for sizes XS-S.
- Made from durable Nylon material.
- Color: Coral.

2. Setup and Fitting

Proper fitting of the harness is crucial for your pet's comfort and safety. Follow these steps to correctly adjust the TRIXIE Premium Dog Harness:

1. **Unbuckle the Harness:** Open the two buckles located on the belly strap.

2. **Position the Harness:** Gently place the harness over your dog's head, ensuring the chest strap is positioned across the chest and the back strap runs along the spine.
3. **Secure the Belly Straps:** Guide your dog's front legs through the loops, then bring the belly straps around the torso and fasten the two buckles.
4. **Adjust for Comfort:** Adjust both the continuously adjustable chest strap and the flexible belly strap. Ensure that you can comfortably fit two fingers between the harness and your dog's body at all points. The harness should be snug but not tight, allowing for full range of motion without chafing.
5. **Check Movement:** Observe your dog's movement. The harness should not restrict breathing, walking, or running.

Important: Always ensure the harness is securely fastened and properly adjusted before each use to prevent your pet from slipping out or experiencing discomfort.

3. Operating Instructions

Once the harness is properly fitted, it is ready for use with a leash.

- **Attaching a Leash:** Locate the metal D-ring on the back of the harness, typically positioned between the shoulder blades. Attach your dog's leash to this D-ring.
- **Supervision:** Always supervise your dog while they are wearing the harness, especially during walks or outdoor activities.
- **Regular Checks:** Periodically check the harness for wear and tear, and ensure all buckles and straps remain secure.

4. Maintenance and Care

To ensure the longevity and hygiene of your TRIXIE Premium Dog Harness, follow these care instructions:

- **Cleaning:** The harness should be removed and hand washed. Use mild soap and cool water.
- **Drying:** Air dry the harness completely. Do not tumble dry or use direct heat, as this can damage the material.
- **Storage:** Store the harness in a clean, dry place when not in use.
- **Inspection:** Regularly inspect the harness for any signs of damage, fraying, or weakened buckles. Replace the harness if any significant wear is observed to ensure your pet's safety.

5. Troubleshooting

If you encounter issues with your TRIXIE Premium Dog Harness, consider the following:

- **Harness is too tight or too loose:** Re-adjust both the chest and belly straps. Refer to the "Setup and Fitting" section to ensure proper adjustment. Remember the two-finger rule.
- **Dog is chafing or uncomfortable:** This often indicates an improper fit. Ensure no straps are digging into your dog's skin or armpits. The harness might need further adjustment, or a different size might be more appropriate if the current size cannot be adjusted to fit comfortably.
- **Dog is slipping out of the harness:** The harness is likely too loose. Tighten the straps, ensuring they are snug but not restrictive. If the dog can still escape, the harness size may be incorrect for your dog's body shape.
- **Buckles are difficult to fasten/unfasten:** Check for any debris or damage in the buckles. Clean them if necessary. If damaged, the harness should be replaced.

6. Specifications

Feature	Detail
Brand	TRIXIE
Model Number	203211
Size	XS-S
Color	Coral
Material	Nylon
Product Dimensions	4.5 x 8 x 36 cm
Item Weight	40 grams
First Available Date	October 5, 2019

7. Warranty and Support

Warranty Information:

For information regarding product warranty and return policies, please refer to the purchase platform's guidelines. For items purchased on Amazon, the standard return policy allows for returns within 30 days of receipt if you change your mind. For defective or damaged products, please consult the specific help pages on the Amazon website.

For detailed information on warranty and returns, please visit the relevant help sections onAmazon.it.

Customer Support:

If you require further assistance or have questions not covered in this manual, please contact TRIXIE customer support through their official website or the retailer from whom you purchased the product. For Amazon purchases, you can also contact Amazon Customer Service for support.

© 2026 TRIXIE. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07XQM2S94

More documents and user manuals: **https://manuals.plus/**