Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GMO1898

Geepas GMO1898 40L Digital Microwave Oven User Manual

Model: GMO1898

1. Introduction

This manual provides essential information for the safe and efficient operation of your Geepas GMO1898 40L Digital Microwave Oven. Please read these instructions carefully before using the appliance and retain them for future reference. This microwave oven is designed for heating, reheating, and defrosting various food items.

2. Safety Instructions

To prevent potential hazards and ensure proper operation, observe the following safety precautions:

- Do not attempt to operate this oven with the door open, as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door, or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the door, hinges, latches, or door seals.
- Only qualified service personnel should adjust or repair the oven.
- Ensure the appliance is properly grounded.
- Do not use corrosive chemicals or vapors in this appliance.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Always use microwave-safe cookware.
- Supervise children closely when the microwave is in use, especially with the Child Lock feature engaged.

3. Product Overview

The Geepas GMO1898 microwave oven features a digital control panel, a spacious interior, and a rotating turntable for even cooking.



This image shows the front of the Geepas GMO1898 microwave oven, featuring its sleek black and silver design, digital control panel, and handle door.

Components:

- **Control Panel:** Digital display with touch controls for various functions and settings.
- **Door with Handle:** Easy-pull handle for opening and closing the oven door.
- **Oven Cavity:** The interior cooking space.
- **Glass Turntable:** Rotates during operation to ensure uniform heating.
- **Turntable Support and Ring:** Supports the glass turntable.



The microwave oven with its door open, revealing the spacious 40-liter interior and the glass turntable, indicating its large capacity for various dishes.

4. Setup

Placement:

- Place the oven on a flat, stable surface that can support its weight and the heaviest food item likely to be cooked in the oven.
- Ensure adequate ventilation by leaving at least 20 cm of space above the oven, 10 cm at the rear, and 5 cm on each side.
- Do not block air vents.
- Keep the oven away from heat sources and strong magnetic fields.

Power Connection:

- Plug the power cord into a standard 230V AC, 50Hz grounded electrical outlet.

- Do not use extension cords or adapters.

Initial Use:

- Before first use, clean the oven interior and accessories with a damp cloth.
- Place the turntable and turntable support correctly inside the oven cavity.

5. Operating Instructions

Basic Microwave Cooking:

1. Place food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. Press the 'Micro' button to select microwave cooking.
4. Use the 'Power Level' button to adjust the desired power level (1 to 10).
5. Use the 'Minute' and 'Second' buttons to set the cooking time.
6. Press 'Start' to begin cooking.

Defrost Function:

The defrost function allows for efficient thawing of frozen foods.

- Place frozen food on the turntable.
- Press the 'Defrost' button.
- Enter the weight of the food using the number buttons.
- Press 'Start'. The oven will automatically calculate the defrosting time.

Multifunctional Cooking Menus:

The oven includes pre-programmed auto-cook menus for common dishes like pizza, fish, and popcorn.



An image of a baked item inside the microwave, demonstrating the appliance's capability to handle various dishes using its pre-programmed multifunctional cooking menus.

- Press the 'Auto Menu' button repeatedly to cycle through the available options.
- Select the desired menu and quantity.
- Press 'Start' to begin cooking.

Power Levels:

The microwave offers 10 power levels for precise cooking control.



A close-up of the digital control panel, with a finger pressing a button, illustrating the ease of selecting one of the ten available power levels for precise cooking.

Child Lock Function:

The child lock feature prevents unintended operation, enhancing safety.



A hand is shown closing the microwave door, emphasizing the secure handle and the child lock safety feature designed to prevent accidental operation.

- To activate: Press and hold the 'Cancel' button for 3 seconds. A lock indicator will appear on the display.
- To deactivate: Press and hold the 'Cancel' button again for 3 seconds. The lock indicator will disappear.

6. Maintenance and Cleaning

Regular cleaning helps maintain the performance and longevity of your microwave oven.

- **Exterior:** Wipe the exterior surface with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Interior:** Clean the oven cavity after each use. For stubborn stains, place a bowl of water with lemon juice inside and heat for a few minutes to loosen residue, then wipe clean.
- **Door Seals:** Regularly clean the door seals and adjacent parts to ensure proper closure and prevent microwave leakage.
- **Turntable:** The glass turntable and support can be removed and washed in warm soapy water or a dishwasher.

- Always ensure the oven is unplugged before cleaning.

7. Troubleshooting

If you encounter issues with your microwave oven, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close door firmly; Check household fuse or reset circuit breaker.
Food not heating	Incorrect power level or cooking time set; Microwave-safe cookware not used.	Adjust power level and cooking time; Use appropriate microwave-safe dishes.
Turntable not rotating	Turntable not properly placed; Debris under turntable.	Ensure turntable and support are correctly positioned; Clean any debris from under the turntable.
Oven light not working	Bulb needs replacement.	Contact qualified service personnel for bulb replacement.

8. Specifications

Detailed technical specifications for the Geepas GMO1898 Microwave Oven:

Feature	Specification
Brand Name	Geepas
Model Info	GMO1898
Product Dimensions	55.3 x 48.8 x 31.1 cm
Energy Use	1500 Watts
Capacity	40 Liters
Installation Type	Countertop
Part Number	RIV001
Special Features	Defrost, Turntable
Oven Cooking Mode	Electric
Color	Black
Voltage	230 Volts (AC)
Wattage (Microwave Output)	1000 watts
Door Hinges	Left
Material Type	Glass

Feature	Specification
Inner Material Type	Metal
Included Components	User Manual
Batteries Required?	No
Item Weight	2 Kilograms



This image provides the physical dimensions of the Geepas GMO1898 microwave oven: 55cm width, 48.1cm depth, and 31cm height, useful for placement planning.

9. Warranty and Support

The Geepas GMO1898 Microwave Oven comes with a**2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.
For technical support, service, or warranty inquiries, please contact Geepas customer service through their official website or the contact information provided with your purchase documentation.

© 2025 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YBJ2DWC

More documents and user manuals: **https://manuals.plus/**