Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GIC6131

Geepas GIC6131 3000W Digital Infrared Cooker User Manual

Model: GIC6131 | Brand: Geepas

1. Introduction

This manual provides essential information for the safe and efficient operation of your Geepas GIC6131 Digital Infrared Cooker. Please read all instructions carefully before first use and retain this manual for future reference.
The Geepas GIC6131 is a 3000W dual-zone infrared cooker designed for versatile cooking. It features touch controls, an LED display, and multiple safety mechanisms to ensure a secure cooking experience.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.

- Do not use appliance for other than intended household use.
- This appliance is equipped with multiple safety devices, including over-heating protection, auto shutdown, hot surface indicator, and a child safety lock.

3. Product Overview

The Geepas GIC6131 infrared cooker features a sleek design with a crystal top plate and two independent cooking zones. It is equipped with user-friendly controls and integrated handles for safe portability.



Figure 3.1: Top-down view of the Geepas GIC6131 Digital Infrared Cooker, showcasing its two cooking zones and control panels.



Figure 3.2: Detailed view of the cooker's features, including touch controls, rotary knobs, and integrated handles for portability.

4. Setup

1. **Unpacking:** Carefully remove the cooker from its packaging. Retain packaging for storage or return if necessary.
2. **Placement:** Place the cooker on a stable, flat, heat-resistant surface. Ensure there is adequate ventilation around the appliance (at least 10-15 cm clearance from walls or other objects).
3. **Power Connection:** Ensure the power supply matches the voltage specified on the appliance's rating label. Plug the power cord into a grounded electrical outlet.
4. **Initial Cleaning:** Before first use, wipe the ceramic surface with a damp cloth. Do not use abrasive cleaners.

5. Operating Instructions

5.1 Powering On/Off

- To turn on, press the **ON/OFF** button on the control panel. The LED display will illuminate.
- To turn off, press the **ON/OFF** button again. The cooker will enter standby mode.

5.2 Selecting Cooking Zone and Power Level

- Each cooking zone has its own control panel and rotary knob.
- After turning on the cooker, select the desired cooking zone by touching its respective control area.
- Use the rotary knob or the **+** and **-** touch buttons to adjust the power level. The cooker offers 9 power settings.
- The LED display will show the selected power level.

5.3 Timer Function

- To set a timer, press the **Timer** button.
- Use the **+** and **-** buttons to adjust the cooking duration.
- Once the set time expires, the cooking zone will automatically turn off.

5.4 Child Safety Lock

- To activate the child safety lock, press and hold the **Lock** button for a few seconds. An indicator will appear on the display.
- When activated, the control panel will be locked, preventing accidental changes to settings.
- To deactivate, press and hold the **Lock** button again until the indicator disappears.



Figure 5.1: Close-up of the intuitive touch control panel and LED display for precise cooking adjustments.



Figure 5.2: The cooker in use with a pot, demonstrating the flexibility of 9 distinct temperature or power levels.

6. Cooking Functions

The Geepas GIC6131 offers a variety of cooking functions to suit different culinary needs:

- **General Cooking:** Use the 9 power settings for simmering, slow cooking, boiling, and grilling.
- **Specialized Functions:** Dedicated settings for Hot Pot, BBQ, Fry, and Soup functions are available via the touch control panel.
- **Dual Zone Cooking:** Cook two different dishes simultaneously with independent temperature and timer settings for each hob.



Figure 6.1: The cooker demonstrating its dual cooking zones, allowing for simultaneous preparation of multiple dishes.



Figure 6.2: The cooker's versatility for various cooking methods, including hotpot, barbecue, and soup.

7. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your Geepas GIC6131 cooker.

- **Before Cleaning:** Always unplug the cooker from the power outlet and allow it to cool completely. The thermo-insulated handles allow for safe movement after cooking to a cooling area.
- **Surface Cleaning:** Wipe the ceramic glass surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive ceramic hob cleaner. Avoid using abrasive pads, scourers, or harsh chemicals.
- **Control Panel:** Wipe the control panel gently with a damp cloth. Ensure no liquid enters the control area.
- **Exterior:** Clean the exterior housing with a damp cloth.
- **Storage:** Store the cooker in a dry place when not in use. Its compact size makes it convenient for storage.

8. Troubleshooting

If you encounter issues with your Geepas GIC6131 cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power supply; try a different outlet.
Cooking zone not heating.	Incorrect power level selected; child lock activated; internal fault.	Ensure power level is set; deactivate child lock; if problem persists, contact support.
Burning smell during use.	Food residue on heating surface; new appliance smell.	Clean the cooking surface thoroughly; new appliances may emit a slight odor initially, which should dissipate.
Control panel unresponsive.	Child lock activated; moisture on panel.	Deactivate child lock; ensure control panel is dry.

If the problem persists after attempting these solutions, please contact customer support.

9. Specifications

- **Brand:** Geepas

- **Model Number:** GIC6131
- **Color:** Black
- **Product Dimensions:** 56 x 28 x 26 cm
- **Power / Wattage:** 3000 watts (1800W + 1200W)
- **Material:** Ceramic, Stainless Steel
- **Special Features:** Programmable, Temperature Control, Child Safety Lock, Timer Function, Hot Surface Indicator
- **Item Weight:** 7.28 Kilograms
- **Heating Elements:** 2
- **Type of Controls:** Knob and Touch
- **Burner Type:** Ceramic Infrared
- **Included Components:** Warranty Card, User Manual

10. Warranty and Support

Your Geepas GIC6131 Digital Infrared Cooker comes with a**2-year warranty** from the date of purchase. Please refer to the included Warranty Card for detailed terms and conditions.
For installation assistance or technical support, please contact the Geepas service centers:

- **Riyadh:** +966 -11- 4094006 Ext – 113
- **Jeddah:** +966- 12- 6577714
- **Dammam:** +966-13- 8343691
- **Qassim:** +966 581044198
- **Abha:** +966 593322785

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YBVN3C8

More documents and user manuals: **https://manuals.plus/**