Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard BB-S49982

Billboard Obelisk Wireless Bluetooth Sound Tower BB-S49982 User Manual

Model: BB-S49982

Introduction

Thank you for purchasing the Billboard Obelisk Wireless Bluetooth Sound Tower. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

Package Contents

Ensure all items listed below are present in the package:

- 1 x Billboard Obelisk Wireless Bluetooth Sound Tower
- 1 x Power Adapter
- 1 x Remote Control
- 1 x User Manual (this document)



Image: The Billboard Obelisk Wireless Bluetooth Sound Tower, a tall black speaker with four visible speaker cones and a top control panel.

Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the device to water or excessive moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the provided power adapter.
- Keep the device away from children and pets.

Product Overview

The Billboard Obelisk Sound Tower features a sleek design with multiple connectivity options. It includes a top panel for controls and various input ports.



Image: A close-up view of the top control panel, showing buttons and input ports for USB and Micro SD.



Image: The sound tower displayed with icons representing its key features: wireless audio, remote control, USB connection, 3.5mm connector, wireless connection, Micro SD, FM Radio, and 20W RMS power.

Setup

1. **Unpacking:** Carefully remove the sound tower and all accessories from the packaging. Retain the packaging for future transport or storage.
2. **Placement:** Place the sound tower on a stable, flat surface. Ensure there is adequate ventilation around the unit. The tower is designed for floor placement.
3. **Power Connection:** Connect the provided power adapter to the DC IN port on the back of the sound tower. Plug the other end of the adapter into a standard electrical outlet.



Image: The Billboard Obelisk Sound Tower positioned upright in a room, demonstrating its floor-standing design.

Operating Instructions

Power On/Off

Press the Power button on the top panel or the remote control to turn the sound tower on or off.

Bluetooth Pairing (Wireless Connection)

1. Turn on the sound tower. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED indicator.
2. Enable Bluetooth on your smartphone, tablet, or other compatible device.
3. Search for "Obelisk" or "Billboard BB-S49982" in your device's Bluetooth list and select it to pair.
4. Once paired, the LED indicator will stop flashing, and you can begin playing audio wirelessly.



Image: A user interacting with the sound tower, placing a smartphone into the integrated slot on top, demonstrating its compatibility with mobile devices.

USB Playback

Insert a USB flash drive containing MP3 audio files into the USB port on the top panel. The sound tower will automatically switch to USB mode and begin playing the audio files.

Micro SD Playback

Insert a Micro SD card containing MP3 audio files into the Micro SD card slot on the top panel. The sound tower will automatically switch to Micro SD mode and begin playing the audio files.

Auxiliary Input

Connect an external audio device (e.g., MP3 player, laptop) to the 3.5mm AUX IN port using a 3.5mm audio cable (not included). Use the Mode button to switch to AUX mode.

FM Radio Operation

1. Press the Mode button to switch to FM Radio mode.

2. Press the Play/Pause button to initiate an automatic scan for available FM stations. The sound tower will save detected stations.
3. Use the Previous/Next buttons to navigate through the saved stations.

Using the Remote Control

The included remote control allows you to manage playback, volume, mode selection, and other functions from a distance. Ensure the remote control has working batteries and is pointed towards the sound tower's sensor.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the sound tower. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Power Adapter:** Always unplug the power adapter from the wall outlet when not in use or during electrical storms.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power adapter not connected; power outlet not working.	Ensure the power adapter is securely connected to both the sound tower and a working power outlet.
No sound	Volume too low; incorrect input mode; device not paired (Bluetooth).	Increase volume. Select the correct input mode (Bluetooth, USB, SD, AUX). Re-pair Bluetooth device.
Bluetooth pairing fails	Device too far; Bluetooth not enabled on source; already paired to another device.	Move device closer to the sound tower. Ensure Bluetooth is enabled on your source device. Disconnect from other Bluetooth devices.
Remote control not working	Batteries depleted; obstruction between remote and sensor.	Replace remote control batteries. Ensure no obstructions are blocking the signal.

Specifications

Model Name	Obelisk
Model Number	BB-S49982
Brand	Billboard
Speaker Type	Tower
Mounting Type	Floor Standing
Connectivity Technology	Bluetooth, USB, Auxiliary
Bluetooth Version	4.2
Wireless Range	Up to 10 meters (33 feet)

Output Wattage	20 Watts
Speaker Size	4 Inches
Supported Media	USB, Micro SD, FM Radio, AUX
Compatible Devices	Smartphone, Tablet, Laptop, MP3 Player
Power Source	Electric Cable
Color	Black
Product Weight	9 kg

Warranty Information

This product comes with a one-year warranty against manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Support

For further assistance or inquiries, please refer to the contact information provided on the product packaging or the official Billboard website.

© 2024 Billboard. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YF1MZ9Z

More documents and user manuals: **https://manuals.plus/**