Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GCR6057

GEEPAS 60x60 Cooking Range GCR6057-4 User Manual

Model: GCR6057

1. Important Safety Information

Read all instructions carefully before using the appliance. Keep this manual for future reference.

- **Gas Safety:** Ensure proper ventilation. Do not store flammable materials near the appliance. In case of gas leak, turn off gas supply, open windows, and do not operate electrical switches.
- **Electrical Safety:** Ensure the appliance is properly grounded. Do not use extension cords. Disconnect power before cleaning or servicing.
- **Burn Hazard:** Surfaces become hot during use. Use oven mitts. Keep children away from the appliance.
- **General Use:** Do not use the appliance for space heating. Do not line oven walls with aluminum foil.
- **Installation:** Installation and service must be performed by a qualified installer, service agency, or gas supplier.

2. Product Overview

The Geepas GCR6057-4 is a 60x60 cm freestanding gas cooking range featuring four gas burners and a convection single oven. It is designed for cooking, baking, and grilling.



Figure 2.1: Front view of the Geepas GCR6057-4 Cooking Range.

Key Features:

- **Four Gas Burners:** Euro pool-type burners with 3mm flat burner caps and wide enamel pan supports.
- **Convection Single Oven:** Large capacity oven suitable for baking, broiling, and grilling.
- **Auto Ignition:** Push-button ignition for all burners, oven, and grill.
- **Full Safety Auto Gas Cut Off:** Automatically cuts off gas supply in emergencies.
- **Top Glass Lid:** Protective glass lid for the cooktop.
- **Oven Lamp:** Internal light for monitoring cooking progress.
- **Rotisserie Function:** For even roasting.
- **Stainless Steel Finish:** Durable and easy-to-clean exterior.

3. Setup and Installation

Proper installation is crucial for safe and efficient operation. It is recommended that installation be performed by a qualified professional.

3.1 Unpacking

- Carefully remove all packaging materials.
- Inspect the appliance for any damage. Do not install if damaged.
- Ensure all components listed in the packing list are present.

3.2 Placement

- Place the cooking range on a stable, level surface.
- Ensure adequate clearance from adjacent walls and cabinets for ventilation. Refer to local building codes for specific requirements.
- Do not install near flammable materials.



Figure 3.1: Appliance dimensions for installation planning (approx. 87.8 cm H x 63.5 cm W x 57.5 cm D).

3.3 Gas Connection

- This appliance must be connected to the gas supply by a qualified and licensed gas fitter.
- Ensure the gas type (LPG or Natural Gas) matches the appliance's specifications.
- Check for gas leaks using a soapy water solution, never an open flame.

3.4 Electrical Connection

- Connect the appliance to a properly grounded electrical outlet.
- Ensure the voltage and frequency match the appliance's requirements (220-240V, 50Hz-60Hz).

4. Operating Instructions

Familiarize yourself with the control knobs before operating the appliance.



Figure 4.1: Control knobs and auto-ignition button.

4.1 Using the Gas Burners

1. Place your cookware centrally on the pan support over the desired burner.
2. Push and turn the corresponding burner knob counter-clockwise to the maximum flame setting.
3. Press the auto-ignition button (usually located on the control panel) until the burner ignites.
4. Once ignited, hold the knob for a few seconds to allow the thermocouple to heat up and prevent the flame from extinguishing.
5. Adjust the flame size by turning the knob between the maximum and minimum settings.
6. To turn off, turn the knob clockwise to the 'OFF' position.

4.2 Using the Oven

1. Open the oven door.
2. Push and turn the oven control knob to the desired temperature setting.

3. Press the auto-ignition button to ignite the oven burner. Hold for a few seconds after ignition.
4. Close the oven door. The oven lamp can be turned on to monitor cooking.
5. For convection cooking, ensure the convection fan is activated (if a separate control exists, otherwise it may be automatic).
6. To use the grill function, select the grill setting on the oven knob and ignite as above. Ensure the oven door is slightly ajar for grilling (refer to specific model instructions).
7. To turn off, turn the oven knob to the 'OFF' position.



Figure 4.2: Oven interior showing racks and grill function.

4.3 Using the Rotisserie (if applicable)

- Secure the food (e.g., chicken) onto the rotisserie spit.
- Insert the spit into the rotisserie motor in the oven.
- Select the rotisserie function on the oven control panel and set the desired temperature.
- Monitor cooking through the oven door.



Figure 4.3: Rotisserie function in the oven.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your cooking range.

5.1 General Cleaning

- Always ensure the appliance is cool and disconnected from the power supply before cleaning.
- Use mild detergents and soft cloths. Avoid abrasive cleaners, scouring pads, or harsh chemicals.

5.2 Cooktop and Burners

- Remove pan supports and burner caps. Wash them in warm soapy water, rinse, and dry thoroughly.
- Wipe the stainless steel cooktop surface with a damp cloth and mild detergent. Dry immediately to prevent water spots.

- Ensure burner ports are not clogged. Use a small brush or needle if necessary.

5.3 Oven Interior

- Remove oven racks. Clean with warm soapy water or an oven cleaner suitable for gas ovens.
- Wipe the interior with a damp cloth. For stubborn stains, use a non-abrasive oven cleaner, following product instructions.

5.4 Exterior Surfaces

- Clean stainless steel surfaces with a soft cloth and a stainless steel cleaner, wiping in the direction of the grain.
- Clean glass surfaces (oven door, top lid) with a glass cleaner.



Figure 5.1: Example of cleaning the cooktop.

6. Troubleshooting

Before contacting service, review the following common issues and solutions:

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply, power outage, clogged burner port, ignition electrode dirty.	Check gas valve. Check power supply. Clean burner ports and electrode.
Oven not heating.	Gas supply off, oven burner not ignited, temperature setting incorrect.	Check gas supply. Re-ignite oven burner. Verify temperature setting.
Uneven cooking in oven.	Improper rack placement, oven door not sealed, food blocking vents.	Adjust rack position. Check door seal. Ensure proper air circulation.
Gas smell.	Gas leak.	Immediately turn off gas supply, open windows, do not operate electrical switches. Contact a qualified gas technician.

If the problem persists after attempting these solutions, contact qualified service personnel.

7. Specifications

Technical specifications for the Geepas GCR6057-4 Cooking Range:



Figure 7.1: Detailed product specifications.

Feature	Detail

Feature	Detail
Brand	Geepas
Model Name	GCR6057
Product Dimensions (W x D x H)	Approx. 63.5 cm x 57.5 cm x 87.8 cm
Item Weight	31.1 Kilograms
Installation Type	Freestanding
Burner Type	Gas (4 Euro Pool Type Burners)
Oven Type	Convection Single Oven
Control Console	Knob
Material Type	Stainless Steel, Aluminum
Rated Voltage	220-240V
Rated Frequency	50Hz-60Hz
UPC	6294010886622

8. Warranty and Support

This Geepas Cooking Range GCR6057-4 comes with a**1-year manufacturer warranty**.

- Retain your purchase receipt and the warranty card included with the product for any warranty claims.
- For technical support, service, or warranty inquiries, please refer to the contact information provided on your warranty card or visit the official Geepas website.
- Unauthorized repairs or modifications will void the warranty.

© 2023 Geepas. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The Geepas GCR6057 cooking range has no temperature markings on the dial; how can I set the oven to bake at 180 degrees?

The Geepas GCR6057 is a gas oven, and many gas ranges in this category use a graduated flame symbol or numbers (1-5 or 1-8) rather than specific degree markings on the knob. To bake...

Read full answer

Open the live page

https://manuals.plus/asin/B07YJ8FRMR

More documents and user manuals: **https://manuals.plus/**