Manuals+
Q & A | Deep Search | Upload

PlayStation 3004138

PlayStation 4 Pro Console with Call of Duty: Modern Warfare Bundle User Manual

Introduction

Welcome to the world of enhanced gaming with your new PlayStation 4 Pro console, bundled with Call of Duty: Modern Warfare. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your console to ensure an optimal gaming experience. Please read through these instructions carefully before using your system.

Setup

1. Unboxing and Component Check

Carefully unpack all items from the box. Ensure the following components are present:

- PlayStation 4 Pro Console (Model: 3004138)
- DualShock 4 Wireless Controller
- HDMI Cable
- Power Cable
- USB Cable (for controller charging)
- Mono Headset
- Call of Duty: Modern Warfare Game Disc

Image: The PlayStation 4 Pro console, DualShock 4 controller, and Call of Duty: Modern Warfare game disc, alongside the product packaging.

2. Connecting the Console

1. **Power Connection:** Connect the power cable to the AC IN connector on the back of the PS4 Pro console, then plug the other end into an electrical outlet.
2. **HDMI Connection:** Connect one end of the HDMI cable to the HDMI OUT port on the PS4 Pro console and the other end to an HDMI input on your TV or display. For 4K/HDR output, ensure your display supports these features and use a High-Speed HDMI cable.
3. **Internet Connection (Optional but Recommended):** For optimal online gaming and system updates, connect an Ethernet cable to the LAN port on the back of the console and to your router, or configure a Wi-Fi connection during initial setup.

3. Connecting the DualShock 4 Wireless Controller

Connect the DualShock 4 controller to the PS4 Pro console using the supplied USB cable. Press the PS button on the controller to pair it with the console. Once paired, you can disconnect the USB cable for wireless play.

4. Initial System Setup

Follow the on-screen instructions to complete the initial setup, including language selection, internet connection, time zone, and user profile creation. It is recommended to update the system software to the latest version during this process.

5. Installing Call of Duty: Modern Warfare

Insert the Call of Duty: Modern Warfare game disc into the disc slot on the front of the PS4 Pro console. The game will begin installing automatically. Follow any on-screen prompts to complete the installation and download necessary updates.

Operating the Console

1. Power On/Off

- **To Power On:** Press the power button on the console or the PS button on a paired controller.
- **To Power Off:** Hold the PS button on the controller to bring up the Quick Menu, then select 'Power' > 'Turn Off PS4'. Alternatively, press and hold the power button on the console for at least 7 seconds until it beeps twice.
- **Rest Mode:** From the Quick Menu, select 'Power' > 'Enter Rest Mode'. In Rest Mode, the console can charge controllers, download updates, and keep games suspended.

2. Navigating the User Interface

Use the DualShock 4 controller's directional buttons or left stick to navigate the PS4 Home Screen. The X button confirms selections, and the O button cancels or goes back. The PS button returns to the Home Screen or opens the Quick Menu.

3. Playing Games

- **Disc-based Games:** Insert the game disc into the disc slot. Select the game icon from the Home Screen to start playing.
- **Digital Games:** Download games from the PlayStation Store. Once downloaded and installed, select the game icon from the Home Screen to launch.

Image: A close-up view of the PlayStation 4 Pro console, showcasing its sleek design and vertical orientation.

4. DualShock 4 Wireless Controller Functions

The DualShock 4 controller features:

- **Touch Pad:** For unique in-game interactions and menu navigation.
- **Light Bar:** Changes color to indicate player number, health status, or other in-game information.
- **SHARE Button:** Capture screenshots, record video clips, or broadcast gameplay.
- **OPTIONS Button:** Access in-game menus or system options.
- **Built-in Speaker and Headset Jack:** For immersive audio and communication.

Image: A DualShock 4 wireless controller with its light bar illuminated in blue, indicating it is powered on and connected.

5. PlayStation Network (PSN)

Create a PlayStation Network account to access online multiplayer, the PlayStation Store for digital games and content, and other online services. A PlayStation Plus subscription is required for most online multiplayer features.

6. System Software Updates

Regularly update your PS4 Pro system software to ensure optimal performance, security, and access to new features. Updates can be downloaded automatically or manually via the System Software Update option in the Settings menu.

Maintenance

1. Cleaning the Console

Keep the console clean by regularly wiping it with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials. Ensure ventilation ports are free from dust and obstructions to prevent overheating.

2. Proper Ventilation

Place your PS4 Pro in a well-ventilated area, away from direct sunlight or heat sources. Do not block the console's ventilation openings. Adequate airflow is crucial for maintaining performance and longevity.

3. Data Backup

Regularly back up your saved game data and other important information to a USB storage device or to PlayStation Plus cloud storage (subscription required) to prevent data loss.

4. Disc Care

Handle game discs by the edges to avoid fingerprints and scratches. Store discs in their cases when not in use. Clean dirty discs with a soft, lint-free cloth, wiping from the center outwards.

Troubleshooting

If you encounter issues with your PlayStation 4 Pro, try the following basic troubleshooting steps:

- **No Power:** Ensure all power cables are securely connected to both the console and the electrical outlet. Try a different outlet.
- **No Display:** Verify the HDMI cable is firmly connected to both the console and the TV. Try a different HDMI port on your TV or a different HDMI cable. Ensure your TV is set to the correct HDMI input.
- **Controller Not Connecting:** Re-pair the controller using the USB cable as described in the Setup section. Ensure the controller is charged.
- **Game Disc Not Reading:** Ensure the disc is clean and free of scratches. Try inserting another game disc to determine if the issue is with the console or the specific disc.
- **System Freezes/Crashes:** Try restarting the console. If the issue persists, consider rebuilding the database from Safe Mode (turn off the console, then press and hold the power button until you hear two beeps).

For more complex issues or persistent problems, refer to the official PlayStation support website or contact customer service.

Specifications

Feature	Detail
Model Number	3004138
Platform	PlayStation 4
Color	Jet Black
Dimensions (Product)	1 x 2 x 2 inches (approximate)
Item Weight	10.03 pounds
Storage Capacity	1 TB (Terabyte) - *Based on product image information*
Input Device	Gamepad (DualShock 4)
Manufacturer	Sony Interactive Entertainment LLC

Official Product Videos

No official seller videos were found for this product. For additional information, please refer to the official PlayStation website or authorized retailers.

Warranty and Support

Your PlayStation 4 Pro console is covered by a limited manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the documentation included with your product or visit the official PlayStation support website. For technical assistance, troubleshooting guides, and customer service contact

information, please visit playstation.com/support.