Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic NN-SN975S

Panasonic NN-SN975S Genius Sensor Microwave Oven User Manual

Model: NN-SN975S

Safety Information Product
Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

Introduction

This manual provides essential instructions for the safe and efficient operation of your Panasonic NN-SN975S Genius Sensor Microwave Oven. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Information

To reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy when using your appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not operate the oven if the door is damaged, or if the oven is malfunctioning.
- Do not heat liquids or other foods in closed containers as they are liable to explode.
- Do not use corrosive chemicals or vapors in this appliance.
- Only use utensils suitable for microwave ovens.
- Do not overcook food.
- Always supervise children when the microwave is in use.
- Ensure proper grounding.

Product Overview

The Panasonic NN-SN975S is a 2.2 cubic foot, 1250W countertop microwave oven featuring Inverter Technology for even cooking and a Genius Sensor for automatic adjustments. Its stainless steel finish provides a modern aesthetic.

Key Features:

- **Inverter Technology:** Delivers a continuous stream of cooking power for even heating without overcooking.
- **Genius Sensor:** Automatically adjusts power and cooking time for optimal results.
- **1250 Watts High Power:** Ensures fast and efficient cooking.
- **2.2 Cu. Ft. Capacity:** Spacious interior accommodates various dish sizes.
- **14 Auto-Cook Settings:** Pre-programmed options for common foods.
- **Keep Warm Function:** Maintains food temperature without overcooking.
- **Auto Defrost:** Efficiently defrosts food by weight.

Components:

- Oven Cavity
- Glass Turntable
- Roller Ring
- Control Panel
- Oven Door with Handle



Figure 1: Front view of the Panasonic NN-SN975S Genius Sensor Microwave Oven. This image displays the sleek stainless steel exterior and the dark glass door.



Figure 2: Interior view of the microwave oven with the door open, showing the glass turntable and roller ring. The interior is designed for easy cleaning.



Figure 3: Close-up of the control panel, highlighting the digital display, number pad, and various function buttons such as Popcorn, Sensor Reheat, Sensor Cook, Power Level, Auto Defrost, Quick 30, and Keep Warm.



Figure 4: Diagram illustrating the dimensions of the Panasonic NN-SN975S microwave oven: 22 inches wide, 12 inches deep, and 20 inches high.

Setup Instructions

1. **Unpacking:** Carefully remove the microwave oven and all packing materials from the carton. Remove any protective film from the exterior surfaces.
2. **Placement:** Place the oven on a flat, stable surface strong enough to hold its weight plus the heaviest food item likely to be cooked. Ensure there is adequate ventilation space: at least 4 inches (10 cm) of space on the top, sides, and rear for proper airflow. Do not block air vents.
3. **Power Connection:** Plug the power cord into a grounded 3-prong outlet. Ensure the voltage matches the rating label on the oven. Do not use an extension cord.
4. **Turntable Installation:** Place the roller ring in the center of the oven cavity floor. Position the glass turntable securely on the roller ring. Ensure it rotates freely.
5. **Setting the Clock:**
    - Press the **Clock Set** button.
    - Enter the current time using the number pad (e.g., 1-2-3-0 for 12:30).
    - Press the **Clock Set** button again to confirm.

Operating Instructions

Basic Cooking (Time Cook):

1. Place food in a microwave-safe container on the turntable. Close the oven door.
2. Enter the desired cooking time using the number pad (e.g., 1-0-0 for 1 minute).
3. Press the **Start** button. The oven will begin cooking at full power (1250W).

Adjusting Power Level:

1. Enter the desired cooking time.
2. Press the **Power Level** button.
3. Select the desired power level from 1 to 10 using the number pad (10 is full power, 1 is lowest).
4. Press the **Start** button.

Quick 30:

This feature allows for quick cooking at full power for 30-second intervals.

- Press the **Quick 30** button repeatedly to add 30-second increments (up to 5 minutes).
- The oven will start immediately.

Genius Sensor Cook/Reheat:

The Genius Sensor automatically detects humidity levels and adjusts cooking time and power for optimal results.

- For Sensor Reheat: Press the **Sensor Reheat** button.
- For Sensor Cook: Press the **Sensor Cook** button and select the desired food category (1-7) using the number pad.
- Press the **Start** button. The oven will automatically determine the cooking time.

Auto Defrost:

Defrosts food based on weight.

1. Place frozen food in the oven.
2. Press the **Auto Defrost (lb/kg)** button.
3. Enter the weight of the food using the number pad.
4. Press the **Start** button.

Keep Warm:

This function keeps food warm without overcooking.

- Press the **Keep Warm** button.
- Enter the desired warming time.
- Press the **Start** button.

Child Lock:

To prevent unintended operation, activate the child lock feature.

- To activate: Press and hold the **Stop/Reset** button for 3 seconds until "LOCK" appears on the display.
- To deactivate: Press and hold the **Stop/Reset** button for 3 seconds until "LOCK" disappears.

Care and Maintenance

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your microwave oven.

Cleaning the Interior:

- Wipe the oven cavity after each use with a damp cloth to prevent food buildup.
- For stubborn stains, place a bowl of water with lemon slices inside and microwave for 2-3 minutes. The steam will

loosen food particles, making them easier to wipe away.

- Do not use abrasive cleaners or scouring pads.

Cleaning the Exterior:

- Wipe the exterior surfaces with a soft, damp cloth.
- For stainless steel surfaces, use a specialized stainless steel cleaner and polish in the direction of the grain.
- Clean the control panel with a soft, damp cloth. Avoid excessive moisture.

Turntable and Roller Ring:

- The glass turntable and roller ring can be removed for cleaning. Wash them in warm, soapy water or in the dishwasher.
- Ensure they are completely dry before placing them back in the oven.

Troubleshooting Guide

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Oven does not start.	Power cord not plugged in; Door not closed properly; Child lock activated.	Ensure power cord is securely plugged in; Close door firmly; Deactivate child lock (see Operating Instructions).
Food is not heating evenly.	Food not stirred or rearranged; Incorrect power level or time; Turntable not rotating.	Stir or rearrange food during cooking; Adjust power level and time as needed; Ensure turntable and roller ring are correctly placed and clean.
Display shows "E" or error code.	Internal malfunction.	Unplug the oven for 30 seconds, then plug it back in. If the error persists, contact customer support.
Light bulb is out.	Light bulb needs replacement.	Contact a qualified service technician for bulb replacement. Do not attempt to replace it yourself.

Product Specifications

Feature	Detail
Brand	Panasonic
Model Number	NN-SN975S
Capacity	2.2 Cubic Feet
Wattage	1250 Watts
Voltage	120 Volts
Product Dimensions (D x W x H)	12" x 22" x 20"
Item Weight	42 Pounds
Color	Silver
Material Type	Glass, Stainless Steel

Feature	Detail
Installation Type	Built-In (Countertop)
Special Feature	Defrost, Inverter Technology, Genius Sensor

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product packaging. Keep your purchase receipt as proof of purchase for any warranty claims.
For technical assistance, troubleshooting beyond this guide, or to inquire about service, please contact Panasonic Customer Support. Contact details can typically be found on the Panasonic official website or in the included user manual documentation.

© 2024 Panasonic Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YLZD9JN

More documents and user manuals: **https://manuals.plus/**