Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic FRESH OILER

Panasonic Fresh Oiler Spray for Hair Clippers

Model: FRESH OILER

1. Product Overview

The Panasonic Fresh Oiler Spray is specifically formulated for the cleaning and maintenance of Panasonic hair clipper blades. Regular use ensures optimal performance, reduces friction, and extends the lifespan of your clipper blades by preventing rust and wear.



Image 1: Panasonic Fresh Oiler Spray bottle, 200ml.

2. Safety Instructions

Please read and adhere to the following safety precautions before using the Panasonic Fresh Oiler Spray:

- **Keep out of reach of children and pets.**
- **Use in a well-ventilated area** to avoid inhalation of fumes.
- **Avoid contact with eyes.** In case of contact, rinse immediately and thoroughly with plenty of water for several minutes. If irritation persists, seek medical attention.
- **Do not ingest.** If swallowed, do not induce vomiting. Seek medical advice immediately and show this container or label.
- **Flammable:** Keep away from heat, hot surfaces, sparks, open flames, and other ignition sources. No smoking.
- **Store in a cool, dry place,** away from direct sunlight and extreme temperatures.
- Ensure the cap is securely fastened after each use to prevent leakage and evaporation.
- Dispose of the container according to local regulations.

3. Setup

The Panasonic Fresh Oiler Spray is designed for immediate use. No assembly or special preparation is required before application.

4. Operating Instructions

Follow these steps for effective cleaning and lubrication of your clipper blades:

1. **Prepare the Clipper:** Ensure your hair clipper is **turned off and unplugged** from the power source before applying the spray.
2. **Clean Blades:** Use a small cleaning brush (often supplied with your clipper) to remove any loose hair, dust, or debris from the clipper blades.
3. **Apply Spray:** Hold the Fresh Oiler spray bottle upright, approximately 15-20 cm (6-8 inches) away from the clipper blades. Spray a small, even amount directly onto the top and sides of the blades.
4. **Distribute Lubricant:** Turn the clipper on for a few seconds (approximately 5-10 seconds) to allow the spray to distribute evenly across the moving parts of the blades.
5. **Wipe Excess:** Turn the clipper off and unplug it. Use a clean, soft, dry cloth to wipe off any excess spray from the blades and clipper body. This prevents residue buildup.
6. **Frequency:** For best results and to maintain optimal blade performance and hygiene, apply the Fresh Oiler spray after each use or as needed, especially if you notice reduced cutting efficiency or increased friction.

5. Maintenance

Proper storage of the Fresh Oiler spray ensures its effectiveness and safety:

- Store the spray bottle upright in a cool, dry, and well-ventilated area.
- Keep the cap securely fastened when not in use.
- Do not expose to temperatures exceeding 50°C (122°F).

6. Troubleshooting

The Panasonic Fresh Oiler Spray is a maintenance product designed to improve clipper blade performance. If you experience issues with your clipper after proper application, consider the following:

- **Blades still dull or pulling hair:** Even with proper lubrication, clipper blades can become dull over time with regular use. They may require sharpening or replacement. Refer to your specific Panasonic clipper model's instruction manual for blade replacement procedures.

- **Clipper making unusual noise or vibrating excessively:** Ensure the blades are correctly aligned and securely attached to the clipper. Check for any foreign objects or excessive hair buildup that might be obstructing the blade movement. If the issue persists, consult your clipper's instruction manual or contact Panasonic customer support.
- **Spray nozzle clogged:** If the spray nozzle becomes clogged, gently clean it with a small pin or rinse under warm water. Ensure it is completely dry before reattaching and using.

7. Specifications

Feature	Detail
Product Name	Fresh Oiler Spray
Brand	Panasonic
Model Number	FRESH OILER (Reference: ER-FRESH)
Volume	200 ml
Approximate Dimensions (H x W x D)	17.4 x 4.7 x 4.7 cm (6.85 x 1.85 x 1.85 inches)
Approximate Weight	118 grams (4.16 ounces)
Purpose	Cleaning and lubrication of hair clipper blades

Note: Specifications are subject to change without notice.

8. Warranty and Support

The Panasonic Fresh Oiler Spray is a consumable maintenance item. Specific warranty information for this product may vary. For details regarding your Panasonic hair clipper's warranty, please refer to the documentation included with your clipper or visit the official Panasonic website.

For product support, technical assistance, or any inquiries, please contact Panasonic customer service through their official channels. You can find contact information and frequently asked questions on the official Panasonic website.

Official Panasonic Website: www.panasonic.com

© 2024 Panasonic Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YX2JGRS

More documents and user manuals: **https://manuals.plus/**