Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nedis KAEB120EAL

Nedis KAEB120EAL Egg Cooker Instruction Manual

Model: KAEB120EAL

Introduction

This instruction manual provides essential information for the safe and efficient operation of your Nedis KAEB120EAL Egg Cooker. Please read these instructions carefully before first use and retain them for future reference. This appliance is designed for cooking eggs to various consistencies, from soft-boiled to hard-boiled.

Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the appliance base, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Always unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use the appliance on a stable, flat, heat-resistant surface.
- Avoid contact with hot surfaces. Use handles or knobs.
- Do not use the appliance for purposes other than its intended use.
- Exercise extreme caution when moving an appliance containing hot oil or other hot liquids.

Product Components

The Nedis KAEB120EAL Egg Cooker consists of the following parts:

- Main Base Unit (stainless steel) with heating plate and power switch.
- Egg Tray (white plastic) for holding up to three eggs.
- Transparent Lid with steam vents.
- Measuring Cup with water level markings and an integrated egg piercer.



Image: All components of the Nedis KAEB120EAL Egg Cooker, including the base unit, egg tray, transparent lid, measuring cup with egg piercer, and power cord.



Image: The Nedis KAEB120EAL Egg Cooker fully assembled with three eggs placed in the tray, ready for cooking.

Setup

1. Unpack all components and remove any packaging materials.
2. Clean the transparent lid, egg tray, and measuring cup with warm soapy water. Rinse thoroughly and dry.
3. Place the main base unit on a stable, flat, and heat-resistant surface.
4. Ensure the power cord is not tangled and is positioned safely.

Operating Instructions

Follow these steps to cook eggs using your Nedis KAEB120EAL Egg Cooker:

1. **Add Water:** Use the provided measuring cup to add the correct amount of water to the heating plate in the base unit. The amount of water determines the egg's consistency (soft, medium, or hard-boiled). Refer to the cooking guide below.
2. **Pierce Eggs:** Carefully pierce the large end of each egg with the egg piercer located at the bottom of the measuring cup. This prevents the eggs from cracking during cooking.
3. **Place Eggs:** Place the pierced eggs onto the egg tray. The egg tray can hold up to three eggs.
4. **Assemble:** Place the egg tray onto the base unit, then cover it with the transparent lid.
5. **Start Cooking:** Plug the appliance into a suitable power outlet. Press the power switch to turn on the egg cooker. An indicator light will illuminate.
6. **Monitor:** The appliance will automatically cook the eggs. Once the water has evaporated and the eggs are cooked, an audible alarm will sound, and the appliance will automatically switch off.
7. **Serve:** Carefully remove the lid and egg tray (use oven mitts as steam will be hot). Transfer the cooked eggs to a

bowl of cold water to stop the cooking process and make them easier to peel.

8. **Unplug:** Always unplug the appliance from the power outlet after use.

Cooking Guide

The following table provides estimated water quantities and cooking times for different egg consistencies. Adjust water quantity slightly based on personal preference and egg size.



Image: A table detailing water amounts and estimated cooking times for 1, 2, or 3 eggs to achieve soft, medium, or hard-boiled consistency.

Estimated Cooking Times and Water Quantities

Number of Eggs	Consistency	Water Amount (ml)	Estimated Cooking Time (min)
1 Egg	Soft boiled	20 ml	7 min
	Medium boiled	30 ml	10 min
	Hard boiled	45 ml	13 min

Number of Eggs	Consistency	Water Amount (ml)	Estimated Cooking Time (min)
2 Eggs	Soft boiled	20 ml	8 min
	Medium boiled	30 ml	11 min
	Hard boiled	35 ml	13 min
3 Eggs	Soft boiled	15 ml	6 min
	Medium boiled	25 ml	11 min
	Hard boiled	35 ml	15 min

Cleaning and Maintenance

Proper cleaning and maintenance ensure the longevity and optimal performance of your egg cooker.

- Always unplug the appliance and allow it to cool completely before cleaning.
- The transparent lid and egg tray are dishwasher-safe. Alternatively, wash them with warm soapy water, rinse, and dry thoroughly.
- Wipe the main base unit with a damp cloth. Do not immerse the base unit in water or any other liquid.
- To remove mineral deposits (limescale) from the heating plate, add a small amount of vinegar and water mixture to the heating plate and let it sit for a few minutes. Then, gently scrub with a non-abrasive sponge and wipe clean.
- Do not use abrasive cleaners or scouring pads, as they may damage the surfaces.
- Store the appliance in a dry place when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Eggs are not cooked to desired consistency.	Incorrect water amount used.	Refer to the "Cooking Guide" table and adjust the water quantity accordingly for future use. Ensure the egg piercer was used.
Eggs crack during cooking.	Eggs not pierced before cooking.	Always pierce the large end of each egg with the integrated egg piercer on the measuring cup before placing them in the cooker.
Appliance does not turn on.	Not plugged in, or power switch not pressed.	Ensure the appliance is securely plugged into a working power outlet and the power switch is in the "ON" position.
White residue on heating plate.	Mineral deposits from water (limescale).	Clean the heating plate with a vinegar and water solution as described in the "Cleaning and Maintenance" section.

Specifications

Brand: Nedis

Model Number: KAEB120EAL

Color: Black (Note: Product images show a stainless steel/silver finish, but specifications list 'Noir' which is Black. Please refer to your specific product for exact color.)

Material: Stainless Steel

Dimensions (L x W x H): 20.2 x 8.5 x 13.5 cm

Weight: 444 g

Capacity: Up to 3 eggs (Water capacity: 70 Milliliters)

Automatic Shut-off: Yes

Dishwasher Safe Parts: Lid and egg tray

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact Nedis customer service directly. Keep your proof of purchase for warranty claims.

© 2023 Nedis. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z3PYW8K

More documents and user manuals: **https://manuals.plus/**