Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hama DIR3200SBT

Hama DIR3200SBT Digital Radio Instruction Manual

Model: DIR3200SBT

1. Introduction

Thank you for choosing the Hama DIR3200SBT Digital Radio. This versatile device offers a wide range of audio entertainment options, including Internet radio, DAB/DAB+ digital radio, FM radio, Bluetooth streaming, and Spotify Connect. This manual provides essential information for the safe and efficient operation of your radio. Please read it thoroughly before use and keep it for future reference.



Image: The Hama DIR3200SBT Digital Radio, white, positioned on a kitchen counter, demonstrating its compact and elegant design.

2. Safety Information

- Do not open the device. Incorrect assembly can lead to electric shocks.
- Do not use the device in damp environments or expose it to splashes of water.
- Only use the provided power adapter.
- Protect the device from extreme temperatures, direct sunlight, and strong vibrations.
- Keep the device away from children.

3. Package Contents

Please check that all items are present and in good condition:

- 1 Hama DIR3200SBT Digital Radio
- 1 Power Adapter

- 1 Remote Control
- 2 AAA Micro Batteries (for remote control)
- 1 Quick Start Guide
- 1 User Manual (multilingual)

4. Product Overview

4.1 Front and Side View



Image: Front and side view of the Hama DIR3200SBT Digital Radio, highlighting the display, control knob, and preset buttons.

The front panel features a 2.8-inch color display, a large control knob for navigation and selection, and several buttons for direct access to functions and presets. The compact design integrates a speaker for clear audio output.

4.2 Rear Panel and Connections



Image: Rear view of the Hama DIR3200SBT Digital Radio, showing the antenna, power input, auxiliary input, headphone jack, line out, and USB charging port.

The rear of the radio provides various connection options:

- **DC IN (12V==2A):** For connecting the external power adapter.
- **AUX IN (3.5 mm):** For connecting external audio sources.
- **Headphone Jack (3.5 mm):** For private listening.
- **LINE OUT (3.5 mm):** For connecting to an external amplifier or speaker system.
- **USB CHARGE (USB-A):** For charging external devices.
- **LAN Port:** For wired network connection (Ethernet).
- **Telescopic Antenna:** For DAB/DAB+ and FM reception.



Image: A detailed close-up of the rear connection ports on the Hama DIR3200SBT Digital Radio, clearly labeling DC IN, AUX IN, Headphone, and LINE OUT.

5. Setup

5.1 Power Connection

1. Connect the supplied power adapter to the **DC IN** port on the rear of the radio.
2. Plug the power adapter into a suitable power outlet.
3. The radio will power on or enter standby mode.

5.2 Antenna

Extend the telescopic antenna fully for optimal DAB/DAB+ and FM radio reception. For improved reception, position the radio near a window.

5.3 Initial Setup Wizard

Upon first power-on, the radio will guide you through an initial setup wizard. Follow the on-screen instructions to set the language, time, and network connection.

5.4 Network Connection (Wi-Fi / LAN)

A stable internet connection is required for Internet radio, Spotify Connect, and software updates.

- **Wi-Fi:** During the setup wizard or via the system settings, select your Wi-Fi network (supports dual-band 2.4/5 GHz) and enter the password.
- **LAN:** Connect an Ethernet cable from your router to the LAN port on the rear of the radio. The radio will automatically detect the wired connection.

6. Operating

6.1 Basic Controls

- **Power Button:** Press to turn the radio on/off or enter standby.
- **Control Knob:** Rotate to navigate menus or adjust volume. Press to confirm selections.
- **Preset Buttons:** Use the dedicated preset buttons or save/recall stations from the memory slots.
- **Remote Control:** Use the included remote control for convenient operation from a distance. Insert the 2 AAA batteries into the remote control before first use.

6.2 Radio Modes

Navigate through the main menu to select your desired radio mode:

- **Internet Radio:** Access thousands of radio stations worldwide. Browse by genre, location, or search for specific stations.

- **DAB/DAB+:** Enjoy high-quality digital radio broadcasts. The radio will automatically scan for available stations.
- **FM Radio:** Tune into traditional analog FM broadcasts.

6.3 Bluetooth Streaming

Stream audio wirelessly from your smartphone, tablet, or other Bluetooth-enabled devices.

1. Select **Bluetooth** mode on the radio.
2. Enable Bluetooth on your mobile device and search for available devices.
3. Select "Hama DIR3200SBT" from the list to pair.

6.4 Spotify Connect

Control your music directly from the Spotify app on your smartphone or tablet.

- Ensure your radio and mobile device are connected to the same Wi-Fi network.
- Open the Spotify app on your device.
- Play a song and select the "Devices Available" icon.
- Choose "Hama DIR3200SBT" from the list to stream audio to your radio.
- A Spotify Premium account and high-speed internet access are required for this feature.

6.5 USB Playback

Connect a USB storage device to the USB port to play audio files. The radio supports navigation through folders and file selection.

6.6 Alarm and Sleep Timer

The radio features two programmable alarms and a sleep timer function.

- **Alarm:** Set up to two independent alarms with customizable sources (buzzer, Internet radio, DAB, FM) and volume.
- **Sleep Timer:** Set a timer for the radio to automatically turn off after a specified duration.

6.7 App Control (UNDOK)

Control your Hama DIR3200SBT using the free UNDOK app on your smartphone or tablet.

- Download the "UNDOK" app from the Google Play Store or Apple App Store.
- Ensure your radio and mobile device are connected to the same network.
- Launch the app and follow the instructions to connect to your radio.

7. Maintenance

7.1 Cleaning

To clean the radio, disconnect it from the power supply. Use a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.

7.2 Software Updates

The radio may receive software updates to improve performance and add new features. Check for updates periodically through the system settings menu.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power	Power adapter not connected or faulty outlet.	Check power adapter connection and try a different outlet.
Poor radio reception (DAB/FM)	Antenna not extended, weak signal.	Extend the telescopic antenna fully. Reposition the radio, ideally near a window.
Cannot connect to Wi-Fi	Incorrect password, out of range, network issue.	Verify Wi-Fi password. Move radio closer to router. Restart router.
Bluetooth pairing fails	Device not in pairing mode, radio not discoverable.	Ensure radio is in Bluetooth mode. Make sure no other device is connected. Restart both devices.
Spotify Connect not working	Not on same network, no Spotify Premium, internet issue.	Confirm both devices are on the same Wi-Fi network. Ensure you have a Spotify Premium account and active internet connection.

9. Specifications

- **Model:** DIR3200SBT
- **Brand:** Hama
- **Color:** White
- **Connectivity:** Wi-Fi (2.4/5 GHz), Bluetooth 4.2, Ethernet (LAN)
- **Radio Reception:** Internet Radio, DAB, DAB+, FM
- **Output Power (RMS):** 10 W
- **Display:** 2.8-inch Color Display
- **Connections:** DC IN (12V==2A), AUX IN (3.5 mm), Headphone Out (3.5 mm), LINE OUT (3.5 mm), USB-A (Charge Port)
- **Power Source:** External Power Adapter (Cable Electric)
- **Dimensions (L x W x H):** 17.5 x 15.5 x 15.5 cm
- **Weight:** 1450 g
- **Power Cable Length:** 180 cm
- **Special Features:** Automatic Dimmer, 2 Alarm Functions, Sleep Timer, Spotify Connect, UNDOK App Control
- **Included Batteries:** 2 x AAA (for remote control)

10. Support

For further assistance, detailed information, or to download the full manual, please visit the official Hama support page: **www.hama.com/054229**

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z3T3G4W

More documents and user manuals: **https://manuals.plus/**