Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom G200

Langsdom G200 In-Ear Gaming Headset User Manual

Brand: Langsdom

Model: G200

1. Product Overview

The Langsdom G200 In-Ear Gaming Headset is designed to provide an immersive audio experience for gamers. Featuring a dual microphone system, including a detachable 360° rotatable boom microphone, and an ergonomic L-shaped 3.5mm connector, these headphones offer clear communication and comfortable use across various platforms. Enjoy high-resolution stereo sound that allows you to detect every subtle movement of your opponents.



Image: The Langsdom G200 In-Ear Gaming Headset, showcasing its main components including the earbuds, detachable boom microphone, in-line control unit, L-shaped 3.5mm audio jack, and a small carrying pouch.

2. Package Contents

Your Langsdom G200 In-Ear Gaming Headset package includes the following items:

- Langsdom G200 In-Ear Gaming Headset with integrated microphone and in-line control.
- Detachable boom microphone.
- Multiple pairs of silicone ear tips for customizable comfort.
- Multiple pairs of silicone ear fins for a secure fit.
- Protective carrying pouch.



Image: A flat lay of all items included in the Langsdom G200 package, showing the headset, detachable microphone, various sizes of ear tips and fins, and the carrying pouch.

3. Setup

3.1 Connecting the Headset

Insert the L-shaped 3.5mm audio jack into your device's headphone port. The L-shaped design is specifically engineered to prevent obstruction during mobile gaming, ensuring a comfortable grip on your device.



Image: A close-up demonstrating the ergonomic L-shaped 3.5mm audio connector plugged into a smartphone, designed to avoid interference with hand placement during gaming.

3.2 Attaching the Detachable Microphone

The Langsdom G200 comes with a detachable boom microphone. To attach, align the microphone's connector with the port on the left earbud and gently push until it clicks into place. This microphone is 360° rotatable for optimal positioning. To remove, gently pull the microphone away from the earbud.

3.3 Customizing Fit

For optimal comfort and sound isolation, select the appropriate size of silicone ear tips and ear fins. Gently remove the pre-installed tips/fins and replace them with the size that provides a snug yet comfortable fit in your ear canal.



Image: An illustration showing the earbud design, the detachable boom microphone, and how the silicone ear tips and fins provide a secure and comfortable fit within the ear.

4. Operating Instructions

4.1 In-line Control Functions

The in-line control unit provides easy access to audio and call management:

- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Multi-function Button:**
  - Single Press: Play/Pause music; Answer/End calls.
  - Double Press: Skip to the next track.
  - Triple Press: Skip to the previous track.
  - Long Press: Reject incoming calls.



Image: A detailed view of the in-line control unit, highlighting the volume buttons, HD microphone, and the multi-function button with its various actions for music playback and call management.

4.2 Microphone Usage

The G200 features two microphones: an integrated HD microphone on the in-line control and a detachable boom microphone. The detachable microphone is ideal for gaming, providing clear voice transmission with noise reduction. The integrated microphone can be used when the boom mic is detached. *Note: The detachable microphone is not compatible with Nintendo Switch for voice chat.*



Image: A user wearing the Langsdom G200 headset while gaming, illustrating the position of both the detachable boom microphone and the in-line control with its integrated microphone and volume control.

4.3 Compatibility

The Langsdom G200 headset is widely compatible with devices featuring a 3.5mm audio jack, including mobile phones, tablets, PCs, PS4, and Xbox One. Please note that the detachable microphone's voice chat function is not supported on Nintendo Switch.

5. Maintenance

- **Cleaning:** Regularly clean the ear tips and ear fins with a soft, damp cloth. Ensure the ear tips are completely dry before reattaching them to the earbuds. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store your headset in the provided carrying pouch to protect it from dust, dirt, and tangles. Avoid wrapping the cable too tightly.
- **Cable Care:** Handle the cable gently. Avoid sharp bends or excessive pulling, which can damage the internal wiring. The tangle-free cable design helps prevent knots.

6. Troubleshooting

- **No Sound:**
  - Ensure the 3.5mm jack is fully inserted into the device's audio port.
  - Check the volume levels on both the in-line control and your connected device.
  - Test the headset with another device to rule out device-specific issues.
- **Microphone Not Working:**
  - Ensure the detachable microphone is securely attached if you are using it.
  - Verify that the microphone is not muted on your device or within the application you are using.
  - Remember that the detachable microphone is not compatible with Nintendo Switch for voice chat.
  - Test the microphone on another device to confirm functionality.
- **Poor Sound Quality / Static:**
  - Ensure the 3.5mm jack is clean and free of debris.
  - Try adjusting the position of the jack in the port.
  - Test with another audio source to determine if the issue is with the headset or the source device.
- **Discomfort During Use:**
  - Experiment with different sizes of silicone ear tips and ear fins to find the most comfortable and secure fit.
  - Ensure the earbuds are correctly oriented in your ears.

7. Specifications

Feature	Description
Model Name	G200
Brand	Langsdom
Connectivity Technology	Wired
Headphone Connector	3.5mm Jack
Ear Placement	In-Ear
Form Factor	In-Ear
Noise Control	Acoustic Isolation
Microphone Form Factor	Detachable
Microphone Technology	Omnidirectional
Control Type	Volume Control
Cable Feature	Tangle-free
Material	Silicone
Impedance	32 Ohm

Feature	Description
Compatible Devices	Nintendo Switch, PC, Sony PlayStation 4, Mobile Phones, Tablets
Special Features	Gaming, Extra Microphone
Operating System Compatibility	Android, iOS
Batteries Required	No
Package Dimensions	12.2 x 9.8 x 2.8 cm; 70 g
Part Number	MXG200-BK

8. Warranty and Support

Langsdom products typically come with a manufacturer's warranty. For specific warranty details, support, or service inquiries, please refer to the documentation included with your purchase or visit the official Langsdom website or their Amazon brand store for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z537NCC

More documents and user manuals: **https://manuals.plus/**