Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 7027cs

Braun Electric Razor Series 7 7027cs User Manual

Model: 7027cs

1. Introduction

1.1 Product Overview

The Braun Series 7 7027cs electric shaver is designed for men, offering a smooth and efficient shave. It features a 360-degree adaptive system and AutoSense technology to adjust to beard density. This shaver is 100% waterproof, allowing for wet or dry use, and includes a Li-Ion battery for extended cordless operation.



Image: The Braun Series 7 7027cs electric razor, its packaging, charging stand, and travel case.

1.2 What's in the Box

Your Braun Series 7 7027cs package includes the following components:

- 1x Series 7 Electric razor (Silver Black)
- 1x Beard Trimmer attachment
- 1x Charging Stand
- 1x Travel case
- 1x Smart plug for automatic 100-240 voltage adjustment
- 1x Cleaning Brush
- User Manual (this document)



Image: A visual representation of all items included in the product box: the electric shaver, travel case, charging cable, beard combs, precision trimmer, charging stand, and cleaning brush.

2. Safety Information

Please read all instructions carefully before using this appliance. Failure to follow these safety instructions may result in electric shock, fire, burns, or injury.

2.1 General Safety Precautions

- This appliance can only be operated cordless for safety reasons.
- The charger unit is not designed for immersion in water or for use in the shower.
- Do not reach for a charger that has fallen into water; unplug immediately.
- Do not place, store, or charge the appliance where it can fall or be pulled into a tub or sink.
- Always unplug the appliance from the electrical outlet immediately after using, except when charging.
- Use only the special cord set with integrated Safety Extra Low Voltage power supply provided. Do not modify it.

- Do not use an extension cord with this appliance.
- Unplug the appliance before cleaning.

2.2 Risk of Burns, Fire, Electric Shock, or Injury

- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless supervised or instructed by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if the power supply has been dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening of the appliance.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use this appliance with a damaged or broken foil, as serious skin injuries may occur.
- Always attach the plug to the appliance first, then to the outlet. To disconnect, turn all controls off, then remove the plug from the outlet.
- When plugging into an electrical outlet outside North America, use a plug adapter to match the outlet's pin configuration.
- **Caution:** The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F), or incinerate.
- To recharge the battery, only use the detachable power supply provided with this appliance. If the appliance is marked 492, only use Braun power supplies coded 492-XXXX.

3. Setup

3.1 Initial Charging

Before first use, fully charge your Braun Series 7 shaver. The Li-Ion battery provides up to 50 minutes of shaving time on a full charge, which typically takes 1 hour. A 5-minute quick charge provides enough power for one shave.

- Connect the smart plug to the charging stand.
- Place the shaver onto the charging stand.
- Plug the smart plug into an electrical outlet.
- The charging indicator lights on the shaver will show the charging status.



Image: The Braun Series 7 electric shaver positioned on its dedicated charging stand, illustrating the charging process.



Image: Information graphic highlighting the Li-ion battery's 50 minutes runtime, equivalent to up to 3 weeks of shaving on a single full charge.

4. Operating Instructions

4.1 Shaving Your Face

The Braun Series 7 features a 360° Flex adaptive system and AutoSense technology for an efficient and comfortable shave.

- Ensure the shaver is charged.
- Press the power button to turn on the shaver.
- Hold the shaver at a right angle (90°) to your skin.
- Stretch your skin and shave against the direction of beard growth.
- The AutoSense technology will automatically adapt the shaver's power to your beard density, removing more hairs in every stroke.

- The 360° Flex head adapts to the contours of your face, providing a smooth shave even in tricky areas like the neck and jawline.



Image: A detailed view of the shaver head, illustrating its 360-degree flex capability for adapting to facial contours.



Image: A man shaving with the Braun Series 7, demonstrating how AutoSense technology adapts to beard density for an effective shave.

4.2 Wet & Dry Shaving

This shaver is 100% waterproof, allowing for versatile use:

- **Dry Shave:** For a quick and convenient shave.
- **Wet Shave:** Use with foam, gel, or even under the shower for a refreshing and smoother skin feel.

4.3 Using EasyClick Attachments

The EasyClick system allows you to quickly change attachments for various grooming needs.

- To remove the shaver head, press the release buttons on the sides and pull the head upwards.
- To attach the beard trimmer or other EasyClick accessories, simply click them onto the shaver body until they lock into place.
- The included beard trimmer attachment is ideal for maintaining moustaches, sideburns, and for pre-trimming

longer hairs before shaving.

5. Maintenance

5.1 Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

- After each use, turn off the shaver and rinse the shaver head under warm running water.
- For a more thorough cleaning, you can remove the shaver head and use the included cleaning brush to remove any trapped hairs.
- Since the shaver is 100% waterproof, it can be rinsed completely under water.
- Allow the shaver head to air dry before reattaching or storing.

5.2 Replacing the Shaver Head

For continued optimal shaving performance, it is recommended to replace the shaver head (foil and cutter block) every 18 months.

- A foil cassette indicator light on the shaver will remind you when replacement is due.
- To replace, remove the old shaver head by pressing the release buttons and pulling it off.
- Align the new shaver head with the shaver body and press it down until it clicks into place.



Image: An illustration showing the recommendation to replace the shaver head every 18 months for best performance.



Image: The Braun Series 7 shaver with text emphasizing its durability, stating the shaver handle is built to last up to 7 years.

6. Troubleshooting

If you encounter any issues with your Braun Series 7 shaver, please refer to the following common solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes for a quick shave, or 1 hour for a full charge.
Shaver does not provide a close shave.	Shaver head is worn out or dirty.	Clean the shaver head thoroughly. If performance does not improve, replace the shaver head (foil and cutter block).

Problem	Possible Cause	Solution
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure you are shaving against the direction of hair growth and stretching the skin. Consider using the shaver wet with foam or gel. Allow skin to adapt to the new shaver.
Shaver stops working unexpectedly.	Internal malfunction or damage.	Refer to the warranty information for service options. Do not attempt to repair yourself.

7. Specifications

Feature	Detail
Model Number	7027cs
Product Dimensions	5.39 x 2.64 x 9.92 inches
Weight	15.36 ounces
Battery Type	1 Lithium Ion battery (included)
Power Source	Battery Powered
Special Features	Cordless, Waterproof (100%), 360° Flex Head, AutoSense Technology
Recommended Use	Beard Shaving
Manufacturer	Procter & Gamble
UPC	069055888407

8. Warranty and Support

Braun offers a 2-year warranty on this product. Additionally, a repair service is available for up to 10 years from the date of purchase.
For further assistance, please visit the official Braun website or contact their customer support. Keep your proof of purchase for warranty claims.
For more information, you can visit the Braun Store on Amazon.

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Z8P11Y5

More documents and user manuals: **https://manuals.plus/**