Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 Easytry8656

Easytry123 Replacement Remote Control User Manual

For Mitsubishi Air Conditioners (Model: Easytry8656)

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Easytry123 replacement remote control. This remote is designed to be compatible with various Mitsubishi air conditioner models, including MSZ-GA22VA-A1, MSY-A24NA-1, KM07J, KM07K, KM07L, MSZ-GA22VA, MSZ-GA25VA, MSZ-GA35VA, MSY-GE09NA, MSY-GE12NA, KM06F, KM06G, and MFZ-KA25VA.
Please note that as a replacement unit, some advanced or specific functions of your original air conditioner remote may not be fully supported. The remote is designed for ease of use and basic control of your air conditioning unit.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image 1: Back view of the remote control showing the open battery compartment and the 'RESET CLOCK' button.

2.2 Initial Use

This replacement remote control is designed for immediate use with compatible Mitsubishi air conditioner models. No complex programming or pairing is typically required. Once batteries are installed, point the remote towards your air conditioner unit and begin operation.

3. Operating Instructions

The remote control provides standard functions for your air conditioner. While specific button labels may vary, common functions include:

- **Power On/Off:** Typically a prominent button to turn the unit on or off.
- **Mode Selection:** Cycle through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **Temperature Adjustment:** Buttons (usually Up/Down arrows) to increase or decrease the desired temperature.
- **Fan Speed:** Adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Swing/Vane Control:** Adjust the direction of the airflow.
- **Timer Functions:** Set the unit to turn on or off after a specified period.
- **Reset Clock:** A dedicated button is available for resetting the clock function, as shown in Image 1. Press this button to adjust the internal clock if your unit supports this feature.

For detailed operation of specific features, refer to your Mitsubishi air conditioner's original user manual, as this replacement remote aims to replicate primary functions.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's range decreases or if the unit becomes unresponsive. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed and not depleted. Replace if necessary.
  - Check for any obstructions between the remote control and the air conditioner's receiver.
  - Ensure you are within the effective operating range of the air conditioner.
- **Certain functions do not work:**
  - As a replacement remote, it may not support all advanced or specific functions of your original air conditioner unit. This is normal for universal or replacement remotes.
  - Verify that your air conditioner model is listed as compatible in the introduction section.

6. Specifications

Model Number	Easytry8656
Brand	Easytry123
Compatible Devices	Mitsubishi Air Conditioners (various models)
Connectivity Technology	Infrared
Power Source	2 x AAA Batteries (not included)
Item Weight	3.84 ounces
Package Dimensions	3 x 2 x 1 inches
Special Feature	Ergonomic design

7. Warranty and Support

Information regarding specific warranty terms for the Easytry123 replacement remote control is not available in this manual. For warranty inquiries or technical support, please contact the manufacturer, Easytry123, directly through their official channels or the retailer from whom the product was purchased.
For further assistance, you may refer to the product listing on the retailer's website or contact Easytry123 customer service.

© 2024 Easytry123. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZG9VZ6J

More documents and user manuals: **https://manuals.plus/**