Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Deco Gear E1DG5CASE

Deco Gear GPS Essentials Bundle Instruction Manual

Model: E1DG5CASE

Introduction

This manual provides instructions for the Deco Gear GPS Essentials Bundle. This bundle includes a 5-inch Hard EVA Case, a Dual DC12V/24V Electronic Multi-functions Car Socket Cigarette Lighter, and a Universal Weighted GPS Dash-Mount. Please read these instructions carefully before using the products to ensure proper function and longevity.

Product Components

The Deco Gear GPS Essentials Bundle includes the following items:

- **Deco Gear 5" Hard EVA Case:** Designed to protect your GPS unit and accessories.
- **Dual DC12V/24V Electronic Multi-functions Car Socket Cigarette Lighter:** Provides power and charging capabilities for multiple devices in your vehicle.
- **Deco Gear Universal Weighted GPS Dash-Mount:** Offers a stable and secure base for your GPS device on the dashboard.
- **Windshield Mount:** An alternative mounting option for your GPS device.



Image: The complete Deco Gear GPS Essentials Bundle, showcasing the hard EVA case, car charger, and weighted dash-mount.

Setup Instructions

1. Hard EVA Case

1. **Open the Case:** Unzip the case to reveal the main compartment and mesh pocket.
2. **Insert GPS Unit:** Place your 5-inch or smaller GPS unit into the main compartment. The soft internal fabric protects the screen from scratches.
3. **Store Accessories:** Utilize the mesh internal compartment to store chargers, cables, memory cards, or other small accessories.
4. **Secure Closure:** Zip the case closed to protect contents from dust and impacts.



Image: Interior view of the Deco Gear 5-inch Hard EVA Case, showing the main compartment and mesh pocket for accessories.

2. Universal Weighted GPS Dash-Mount

1. **Choose Placement:** Select a flat, stable area on your vehicle's dashboard that does not obstruct your view or interfere with airbags.
2. **Position the Mount:** Place the weighted dash-mount directly on the chosen dashboard area. No adhesive or installation is required. The bean bag body adjusts to uneven surfaces.
3. **Attach GPS Device:** Secure your GPS device to the mounting plate of the dash-mount. Ensure it is firmly attached.



Image: The weighted dash-mount positioned on a car dashboard, providing a secure and easy view of a GPS device.

3. Dual DC12V/24V Car Charger

1. **Insert into Socket:** Plug the car charger into your vehicle's 12V or 24V cigarette lighter socket.
2. **Connect Devices:** Use the available DC sockets or USB ports to connect and power your electronic devices, such as GPS units, smartphones, or tablets.



Image: The Deco Gear Dual DC12V/24V Car Charger, featuring multiple power outlets and USB ports.

Operating Instructions

Using the Hard EVA Case

The hard EVA case is designed for portable protection. When transporting your GPS unit or storing it, ensure it is securely placed inside the case. The mesh pocket helps organize smaller items, preventing them from scratching the main device.

Using the Universal Weighted GPS Dash-Mount

Once positioned on your dashboard, the weighted base provides stability for your GPS device. Adjust the angle of your GPS unit on the mount for optimal viewing without obstructing your driving visibility. The mount allows for quick placement and removal.

Using the Dual DC12V/24V Car Charger

After plugging the charger into your vehicle's power socket, the indicator light (if present) will illuminate. You can then plug in up to two 12V/24V devices into the DC sockets and multiple USB-powered devices into the USB ports. Ensure your devices are compatible with the charger's output specifications.

Maintenance

- **Hard EVA Case:** Wipe the exterior with a damp cloth if it becomes dirty. Avoid harsh chemicals. Ensure the case is dry before storing electronics.
- **Weighted GPS Dash-Mount:** Periodically clean the base and mounting surface with a soft, dry cloth to maintain grip and prevent dust buildup.
- **Car Charger:** Keep the charger's ports free from dust and debris. Do not expose to moisture. If the fuse blows, replace it with a fuse of the same rating.
- **General:** Store all components in a cool, dry place when not in use.

Troubleshooting

- **Car Charger Not Powering Devices:**
  - Ensure the charger is fully inserted into the vehicle's cigarette lighter socket.
  - Check if the vehicle's power socket is active (some vehicles require the ignition to be on).
  - Verify that the connected devices are functioning correctly and their cables are not damaged.
  - Inspect the charger's fuse (if accessible) and replace if blown.
- **Dash-Mount Not Stable:**
  - Ensure the dashboard surface is clean and dry.
  - Reposition the mount to a flatter section of the dashboard.
  - Confirm the GPS device is securely attached to the mount's plate.
- **Hard Case Zipper Stuck:**
  - Do not force the zipper. Gently try to move it back and forth.
  - Check for any fabric or debris caught in the zipper teeth.

Specifications

Feature	Detail
Model Number	E1DG5CASE
Product Dimensions	2 x 2 x 2 inches
Item Weight	2 pounds
Hard Case Size	Fits most 5-inch and smaller electronics
Car Charger Input	DC 12V/24V
Mounting Type	Weighted Dash-Mount, Windshield Mount
Manufacturer	Deco Gear

Warranty and Support

Deco Gear provides a Full 1 Year Manufacturer's Limited Protection Plan for this product. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official Deco Gear website.
For additional information and support, you may visit the Deco Gear Brand Store.

© 2024 Deco Gear. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZWJZ6D9

More documents and user manuals: **https://manuals.plus/**