**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Bushnell 119875C

# Bushnell 119875C 24MP Trophy Cam HD Low Glow Trail Camera User Manual

Model: 119875C

## 1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Bushnell 119875C 24MP Trophy Cam HD Low Glow Trail Camera. This camera is designed to capture crisp and clear images and videos with a super-fast 0.1-second trigger speed, Hyper0.5S recovery rate, and extended nighttime photo range. Please read this manual thoroughly before using your camera to ensure proper function and longevity.

## 2. Product Overview

The Bushnell 119875C Trophy Cam HD Low Glow is a high-performance trail camera featuring 24MP still image resolution and 720p video capture. Its low-glow infrared technology provides discreet illumination for night photography, while the integrated color viewer allows for immediate review of captured media. The camera is built for durability and designed for outdoor use.




Figure 2.1: Front view of the Bushnell 119875C Trophy Cam HD Low Glow Trail Camera, showcasing its camouflage design and sensor layout.




Figure 2.2: Back view of the camera, showing the mounting points and regulatory labels.

## 3. Setup

### 3.1 Battery Installation

The camera operates on 8 AA batteries (not included). For optimal performance and a true 1-year battery life, it is recommended

to use high-quality alkaline or lithium batteries.

1. Open the camera housing by unlatching the side clips.
2. Locate the battery compartment.
3. Insert 8 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment securely.

### 3.2 SD Card Insertion

The camera accepts up to a 32GB SD Card (not included) for storing photos and videos.

1. With the camera housing open, locate the SD card slot.
2. Insert the SD card into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.
3. To remove, press the card gently to release it.




Figure 3.1: The camera with its housing open, revealing the battery compartment and the SD card slot.

### 3.3 Mounting the Camera

The camera comes with a mounting strap for easy installation on trees or posts.

1. Thread the included mounting strap through the slots on the back of the camera.
2. Secure the camera to a tree or post at the desired height and angle. Ensure the camera is stable and pointed towards the area you wish to monitor.
3. Adjust the strap for a snug fit to prevent camera movement.



Figure 3.2: The Bushnell Trophy Cam HD Low Glow mounted on a tree using the provided strap.

## 4. Operating Instructions

### 4.1 Powering On/Off

To power on the camera, slide the power switch to the ON position. To power off, slide the switch to the OFF position.

### 4.2 Basic Operation

Once powered on, the camera will enter a setup mode or begin monitoring based on your configured settings. Use the internal color viewer and navigation buttons to access the menu and adjust settings such as photo resolution, video length, trigger interval, and more.




Figure 4.1: The camera's internal color viewer displaying a captured image, accessible when the housing is open.

## 4.3 Capturing Images and Videos

The camera is equipped with a passive infrared (PIR) sensor that detects motion and heat. When triggered, it captures either still images or video clips based on your settings.

- **Still Images:** Captures high-resolution 24MP photos.
- **Video:** Records 720p video with audio.
- **Trigger Speed:** Ultra-fast 0.1-second trigger speed ensures minimal delay in capturing moving subjects.
- **Recovery Rate:** Hyper0.5S recovery rate allows for quick subsequent captures.
- **Night Vision:** Low-glow infrared LEDs provide illumination for clear nighttime photos and videos up to 100 feet without startling wildlife.




Figure 4.2: Example of a daytime image captured by the camera, demonstrating clarity and color reproduction.




Figure 4.3: Example of a night vision image captured by the camera, showcasing its low-glow infrared capabilities.

## 5. Maintenance

### 5.1 Battery Life

The camera is designed for true 1-year battery life under typical usage conditions. Battery performance may vary based on environmental factors and frequency of captures.

### 5.2 Cleaning

Regularly clean the camera lens, PIR sensor window, and infrared LEDs with a soft, lint-free cloth. Avoid using abrasive cleaners or solvents. Ensure the camera housing is free of dirt and debris, especially around the seals, to maintain its IP54 weather resistance.

### 5.3 SD Card Management

Periodically check the SD card capacity and transfer captured media to a computer or external storage device. Format the SD card within the camera periodically to maintain optimal performance and prevent data corruption.

## 6. Troubleshooting

- **Camera not powering on:** Ensure batteries are inserted correctly with proper polarity and are fully charged. Check that the power switch is in the ON position.
- **No images/videos captured:** Verify the SD card is inserted correctly and has sufficient free space. Check camera settings for proper mode (photo/video) and trigger sensitivity. Ensure the PIR sensor is not obstructed.
- **Poor image/video quality:** Clean the lens and sensor window. Check for condensation inside the camera. Ensure the

camera is stable and not subject to excessive movement. For night images, ensure subjects are within the 100-foot night vision range.

- **Short battery life:** Use high-quality alkaline or lithium batteries. Frequent captures, especially at night, can reduce battery life. Consider reducing trigger frequency or video length settings.
- **Date/Time incorrect:** Access the camera's menu to set the correct date and time.

## 7. Specifications

| Feature | Specification |
|---|---|
| Model Number | 119875C |
| Effective Still Resolution | 24 MP |
| Video Capture Resolution | 720p |
| Trigger Speed | 0.1 seconds |
| Recovery Rate | 0.5 seconds |
| Night Vision Range | 100 feet |
| Flash Memory Type | SD (up to 32GB) |
| Power Source | 8 AA Batteries (not included) |
| Connectivity Technology | Wi-Fi (for certain features/models, check product for specifics) |
| International Protection Rating | IP54 |
| Item Dimensions (LxWxH) | 8 x 6 x 3 inches |
| Item Weight | 1 Pound |
| Included Components | Camera, manual, mounting strap |

## 8. Warranty and Support

For detailed warranty information and technical support, please refer to the documentation included with your product or visit the official Bushnell website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2023 Bushnell. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07ZWQM1RR**

More documents and user manuals: **https://manuals.plus/**