Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Motorola Moto E6 NA

Motorola Moto E6 User Manual

Model: Moto E6 NA

Introduction

This manual provides essential information for the proper use, setup, and maintenance of your Motorola Moto E6 smartphone. Please read this manual thoroughly before using your device to ensure optimal performance and longevity.





Figure 1: Front view of the Motorola Moto E6 smartphone, displaying its screen and overall design.

Package Contents

Ensure all items are present in your product package:

- Motorola Moto E6 Smartphone
- USB Charging Cable
- USB Charger Block
- Quick Start Guide (not included in this manual)

Setup

1. Inserting the SIM Card and microSD Card

Locate the SIM/microSD card tray on the side of the phone. Use the provided SIM ejector tool (if applicable) or a small paperclip to open the tray. Insert your nano-SIM card and an optional microSD card into their respective slots, ensuring correct orientation. Close the tray securely.



Figure 2: Side and back view of the Motorola Moto E6, showing the camera and textured back panel, indicative of where the SIM tray might be located.

2. Charging the Battery

Before first use, fully charge the phone's battery. Connect the USB charging cable to the phone's charging port and the USB charger block. Plug the charger block into a power outlet. The battery indicator on the screen will show charging progress. A full charge can provide up to 29 hours of talk time.

3. Initial Power On and Setup Wizard

Press and hold the power button until the Motorola logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account sign-in, and security settings.

Operating Instructions

Basic Navigation

- **Power Button:** Press to turn the screen on/off. Press and hold to power on/off or restart.
- **Volume Buttons:** Adjust media volume, call volume, or notification volume.
- **Touchscreen:** Navigate by tapping, swiping, pinching, and spreading.

Camera Usage

The Moto E6 features a 13 MP PDAF fast-focus rear camera and a 5 MP selfie camera. To open the camera, tap the camera icon on the home screen or lock screen. Tap the shutter button to take a photo. Swipe left or right to switch between photo and video modes. Tap the camera switch icon to toggle between front and rear cameras.

Connectivity

Access Wi-Fi settings from the Quick Settings panel (swipe down from the top of the screen) or through the main Settings app. Tap on "Wi-Fi" to enable/disable and connect to available networks. The device supports standard Wi-Fi connectivity.

Display Features

The 5.5-inch HD+ display with an 18:9 aspect ratio provides an immersive viewing experience. Adjust brightness, font size, and display timeout in the Display settings menu.

Maintenance

Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using abrasive cleaners, solvents, or aerosol sprays. Do not immerse the phone in water.

Battery Care

To prolong battery life, avoid exposing the phone to extreme temperatures. It is recommended to keep the battery charge between 20% and 80% for optimal long-term health. Use only the provided or certified charging accessories.

Software Updates

Regularly check for and install software updates to ensure your phone has the latest features, security patches, and performance improvements. Go to *Settings > System > System updates*to check for updates.

Troubleshooting

Problem	Possible Solution
Phone not turning on	Ensure the battery is charged. Press and hold the power button for at least 10-15 seconds to force a restart.
Cannot connect to Wi-Fi	Check if Wi-Fi is enabled. Restart your router. Forget the network and reconnect.
Apps crashing or freezing	Close and reopen the app. Clear the app's cache (*Settings > Apps > [App Name] > Storage > Clear cache*). Restart the phone.
Poor battery life	Reduce screen brightness. Close unused apps. Disable unnecessary background processes. Check battery usage in settings to identify draining apps.
SIM card not recognized	Ensure the SIM card is correctly inserted. Restart the phone. Verify that the phone is compatible with your carrier's network.

Specifications

Feature	Detail
Model Name	Moto E6 NA
Dimensions	5.89 x 2.85 x 0.34 inches
Weight	5.6 ounces

Feature	Detail
Display	5.5-inch HD+ (2340 x 1080 resolution)
Operating System	Android
Processor	Qualcomm Snapdragon octa-core processor (CPU Speed: 2.2 GHz)
RAM	2 GB
Internal Storage	16 GB
Rear Camera	13 MP PDAF
Front Camera	5 MP
Battery Capacity	3000 mAh (up to 29 hours talk time)
Connectivity	Wi-Fi
Audio Jack	No headphone jack
Color	Black

Warranty and Support

This Motorola Moto E6 is a renewed product. It is backed by theAmazon Renewed Guarantee. If you are not satisfied with your purchase, renewed products are eligible for replacement or refund under this guarantee. Please refer to the Amazon Renewed program terms for full details regarding returns and support for renewed devices.
For technical support or further assistance, please contact the seller or Amazon customer service directly.

© 2024 Motorola. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081BDYL4H

More documents and user manuals: **https://manuals.plus/**