Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SINGER 26-inch Steam Press

SINGER Intelligent Steam Press 26-inch User Manual

Model: 26-inch Steam Press

Introduction

This manual provides instructions for the safe and efficient operation of your SINGER Intelligent Steam Press. Please read all instructions carefully before use and retain this manual for future reference.



Image: The SINGER Intelligent Steam Press, showing its compact design and pressing surface.

Important Safety Instructions

- Always unplug the steam press when filling with water, cleaning, or when not in use.
- Do not operate the steam press with a damaged cord or plug.
- Keep the appliance out of reach of children.

- Use the steam press only for its intended purpose as described in this manual.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the steam press in water or other liquids.
- The steam press features an automatic shutoff for safety when left unattended.

Product Components

Familiarize yourself with the parts of your SINGER Intelligent Steam Press:



Image: Labeled diagram showing the Locking Knob, Steam Burst Buttons, Ironing Board, and Pressing Plate.

- **Pressing Plate:** The heated upper surface that presses against fabric.
- **Ironing Board:** The lower surface where fabric is placed.
- **Locking Knob:** Secures the pressing plate in a closed position for storage or transport.
- **Steam Burst Buttons:** Activates a burst of steam for stubborn wrinkles.
- **Digital Controls:** For selecting fabric type and monitoring status.
- **Water Tank:** Removable reservoir for water, capacity 800ml.

Setup

1. **Unpack:** Carefully remove the steam press from its packaging.
2. **Placement:** Place the unit on a flat, stable, and heat-resistant surface. Ensure adequate ventilation.
3. **Fill Water Tank:**
    - Ensure the unit is unplugged.
    - Remove the water tank (800ml capacity).
    - Fill with distilled water to prevent mineral buildup. Do not overfill.
    - Securely reinsert the water tank.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Image: The steam press showing its large 800ml water tank capacity and 1500W power rating.

The SINGER Intelligent Steam Press can be used with a compatible stand (model ST-07H) for added convenience. The stand is sold separately.

Compatible Stand: ST-07H



Image: The SINGER Intelligent Steam Press mounted on a compatible stand, model ST-07H.

Operating Instructions

1. **Power On:** Turn on the steam press using the power button. The digital display will illuminate.
2. **Select Fabric Setting:** Use the digital controls to select the appropriate fabric type (e.g., Silk, Wool, Cotton, Linen, Denim). The unit will begin to heat up.
3. **Preheating:** The steam press heats up rapidly, typically within 96 seconds. Wait for the indicator light or display to show it has reached the selected temperature.
4. **Position Fabric:** Place the garment or fabric smoothly on the ironing board. Ensure it is flat and free of creases.
5. **Pressing:** Gently lower the pressing plate onto the fabric. Hold for a few seconds. For stubborn wrinkles, press the steam burst buttons.

6. **Repeat:** Lift the pressing plate, reposition the fabric, and repeat the pressing process until the desired result is achieved.
7. **Continuous Steam:** The unit provides continuous steam for efficient wrinkle removal.



Image: The SINGER Intelligent Steam Press actively steaming a shirt, demonstrating its non-stick pressing surface and steam output.

The 26" x 11" non-stick pressing surface allows for efficient pressing of larger items.



Image: A close-up view of the 26" x 11" non-stick pressing surface of the SINGER Intelligent Steam Press.

The steam press is designed for portability, allowing for easy use and storage.



Image: A person carrying the SINGER Intelligent Steam Press, highlighting its portable design.

Maintenance and Care

- **Cleaning the Pressing Plate:** Allow the unit to cool completely. Wipe the non-stick pressing plate with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Draining Water Tank:** Regularly empty any remaining water from the tank after each use to prevent mineral buildup and odors.
- **Descaling:** If you notice reduced steam output or mineral residue, descale the unit according to the instructions in a separate descaling guide (if provided by manufacturer). Generally, this involves using a vinegar solution.
- **Storage:** Ensure the unit is cool and dry before storing. Use the locking knob to secure the pressing plate. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
No steam output	Water tank empty; Unit not heated; Mineral buildup.	Refill water tank; Allow unit to preheat; Descale the unit.

Problem	Possible Cause	Solution
Unit not heating	Not plugged in; Power switch off; Faulty outlet.	Check power connection; Turn power switch on; Test outlet with another appliance.
Water leaking	Water tank not properly seated; Overfilled tank.	Ensure tank is securely in place; Do not overfill the tank.
Automatic shutoff activates too soon	Unit left unattended for too long.	This is a safety feature. Resume operation by moving the handle or pressing a button.

Specifications

- **Model:** 26-inch Steam Press
- **Power:** 1500W
- **Pressing Surface:** 26" x 11" Non-stick
- **Water Tank Capacity:** 800ml
- **Heat-up Time:** Approximately 96 seconds
- **Fabric Settings:** 5 Digital Fabric Settings
- **Safety Features:** Auto Shutoff, Alert Notifications
- **Product Dimensions (Base):** 21.2"L x 8.2"W
- **Color:** Grey

Warranty and Support

For warranty information, product registration, or technical support, please refer to the official SINGER website or contact SINGER customer service. Keep your purchase receipt as proof of purchase.
Visit the official SINGER store for more products and support:SINGER Store on Amazon

© 2023 SINGER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081ZPP1M3

More documents and user manuals: **https://manuals.plus/**