Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 81702940

Braun Series 3 300 Electric Shaver

User Manual

1. Product Overview

The Braun Series 3 300 electric shaver is designed to provide an efficient and gentle shaving experience. It features three pressure-sensitive shaving elements that adapt to your facial contours, ensuring a close and comfortable shave. This shaver is engineered in Germany for durability and performance, offering both wet and dry functionality for versatile use.





Key Features:

- 3 pressure-sensitive shaving elements for efficiency and skin comfort.
- Durable cordless electric shaver, fully washable under water.
- Long-lasting rechargeable Ni-MH batteries.
- Designed and produced in Germany by Braun.

2. What's in the Box

Your Braun Series 3 300 package includes the following components:

- Braun Series 3 electric shaver
- Protective cap
- Smart plug charger (100-240V, 2-pin European plug)




BRAUN
Series 3
Protective cap
Clean & Close
Adapts to every facial contour.
3-FLEX SHAVER
2-way use
8x faster*
Quick Charge
DE Schutzkappe
FR Capot de protection
ES Capuchón protector
IT Cappuccio di protezione
PT Tampa protetora
NL Beschermkapje
RU Защитная крышка
EN *Versus Braun 150s
DE *ggü. Braun 150s
FR * Comparé à Braun 150s
ES * En comparación con la Braun 150s
IT *rispetto a Braun 150s
PT *Comparada com a Braun 150s
NL *t.o.v. Braun 150s
RU * По сравнению с бритвой Braun 150s
Model: 300s
German Technology
Waterproof 5 meters
Powerful NiMH battery
Ergonomic grip



3. Safety Instructions

Please read all safety instructions carefully before using the shaver to prevent injury or damage.

- To ensure safe operation, avoid applying excessive pressure during shaving.
- Always dry the shaver thoroughly before recharging to prevent electrical hazards.
- Follow all recommended cleaning and maintenance instructions provided in this manual.
- The product packaging may contain additional information or warnings. Always read the label, warnings, and instructions provided with the product before use.

4. Charging and Battery

The Braun Series 3 300 is equipped with two long-lasting Ni-MH rechargeable batteries. Ensure the shaver is dry before connecting it to the charger.

1. Connect the smart plug charger to the shaver and a power outlet.
2. A full charge takes approximately 1 hour and provides up to 30 minutes of cordless shaving.
3. A quick 5-minute charge can provide enough power for one shave.



Braun Series 3 300 electric shaver connected to its charger.



Battery indicator and NiMH battery information.

▶ **Watch video online**

Video highlighting the key features of the Braun Series 3 300, including its flexible shaving elements and battery life.

5. Operating the Shaver

For optimal results, follow these guidelines when using your Braun Series 3 300 shaver:

1. Turn on the shaver.
2. Hold the shaver at a 90-degree angle to your skin.
3. Shave against the direction of hair growth using straight, even strokes.
4. The 3-Flex shaving head adapts to facial contours, making it easy to shave areas like under the nose, neck, and jawline.
5. The Wet&Dry functionality allows for comfortable dry shaving or refreshing wet shaving with foam or gel for an even smoother glide.



Man using Braun Series 3 300 electric shaver on his cheek.



Close-up of the Braun Series 3 300 3-Flex shaving head.

▶ **Watch video online**

Video demonstrating the proper technique for shaving with the Braun Series 3 300 electric shaver.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and hygiene for your shaver. The Braun Series 3 300 is waterproof up to 5 meters, allowing for easy cleaning under running water.

1. After each use, turn off the shaver.
2. Rinse the shaver head and foils thoroughly under warm running water.
3. You can also use a mild soap for a more thorough cleaning.
4. Shake off excess water and allow the shaver to air dry completely before storing or recharging.
5. Periodically, you may want to apply a drop of light machine oil to the shaver foils for continued smooth operation.



Cleaning the Braun Series 3 300 electric shaver under running water.

7. Troubleshooting

If you encounter any issues with your Braun Series 3 300 shaver, refer to the common problems and solutions below:

- **Shaver not turning on or charging:** Ensure the charger is properly connected to both the shaver and a working power outlet. Check if the charging indicator light is active. If the battery is completely drained, it might take a few minutes for the indicator to appear.
- **Poor shaving performance or irritation:** Ensure the shaver head and foils are clean and free from debris. Replace the shaver head and foils if they are worn or damaged (typically every 18 months). Apply light pressure and shave against the direction of hair growth. Consider using the shaver with foam or gel for sensitive skin.
- **Battery not holding charge:** Over time, rechargeable batteries can lose capacity. If the shaver's battery life significantly decreases, it may be time to replace the battery or consider a new shaver. Ensure the shaver is fully charged for the recommended duration.

8. Technical Specifications

9. Warranty and Support

Braun products are manufactured to the highest quality standards. This product is covered by a manufacturer's warranty. For detailed warranty information, product registration, or customer support, please refer to the warranty card included in your product packaging or visit the official Braun website. Keep your proof of purchase for warranty claims.

▶ **Watch video online**

Video demonstrating the Braun Series 3 300 electric shaver and its included charger.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0822YBGK3

More documents and user manuals: **https://manuals.plus/**

Feature	Specification
Brand	Braun
Model Number	81702940
Product Name	Men's Electric Beard Shaver with 3 Flexible Blades
Head Type	Foil heads

Blade Material	Stainless Steel
Power Source	Battery powered (Rechargeable Ni-MH)
Battery Life	Up to 30 minutes
Charging Time	1 hour for full charge, 5 minutes for quick charge
Waterproof	Yes, up to 5 meters (Wet&Dry)
Product Dimensions	11.1 x 5.6 x 20.3 cm
Weight	326 grams
Color	Green/Black