Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 RAV363 Universal Remote Control

Easytry123 Universal Remote Control User Manual

Compatible with JVC LCD LED HDTV TV Models

Introduction

This manual provides detailed instructions for the Easytry123 RAV363 Universal Remote Control. This remote is designed as a direct replacement for various JVC LCD LED HDTV TV models, including RM-C325G1A, RM-C3921A, RM-C18501C, RM-C18551C, RM-C1860, RM-C346, RM-C3462A, RM-C3841A, and RM-C3101A. Please read this manual thoroughly before use to ensure proper operation and to maximize your viewing experience.

Setup

Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, illustrating correct battery insertion.

Initial Setup and Compatibility

This Easytry123 remote control is a replacement unit pre-programmed for the specified JVC TV models. In most cases, no additional programming is required. Simply insert the batteries and begin using it with your compatible JVC television.
If your original remote had a specific part number like RAV272, RAV273, RAV353, RAV352, RAV323, RAV361, RAV362, RAV358, or RAV359, this remote is designed to replace those as well. While it aims to replicate full functionality, some advanced or specific features of your original remote may not be fully supported.

Operating Instructions

Familiarize yourself with the buttons on your Easytry123 Universal Remote Control. The layout is designed for intuitive operation of your JVC television.



Image: Front view of the remote control, displaying all functional buttons.

Key Functions

- **POWER:** Turns the TV on or off.
- **INPUT:** Selects video input sources (e.g., HDMI, AV, Component).
- **CH +/-:** Changes channels up or down.
- **VOL +/-:** Adjusts the volume level.
- **MUTE:** Mutes or unmutes the TV audio.
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigates menus and confirms selections.
- **MENU:** Accesses the TV's main menu.
- **EXIT/BACK:** Exits menus or returns to the previous screen.
- **NUMBER BUTTONS (0-9):** Directly enters channel numbers.
- **MEDIA/USB:** Accesses media playback functions or USB content.
- **HDMI/PC/TV/COMP:** Direct selection for specific input types.
- **CC:** Activates or deactivates Closed Captions.
- **INFO:** Displays program information.

Maintenance

Cleaning

To clean your remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Dispose of old batteries responsibly according to local regulations.

Troubleshooting

Remote Not Responding

- **Check battery orientation:** Ensure AAA batteries are inserted correctly with positive (+) and negative (-) terminals aligned.
- **Replace batteries:** If batteries are old or depleted, replace them with fresh ones.
- **Clear line of sight:** Ensure there are no obstructions between the remote control and the TV's infrared sensor.
- **Test remote:** Point the remote at a digital camera (like a smartphone camera) and press a button. If you see a light flashing from the remote's IR emitter on the camera screen, the remote is sending a signal. If not, the remote may be faulty or batteries are completely dead.

Limited Functionality

- This remote is a replacement and may not support all advanced or smart TV features of your specific JVC model. Verify if the missing function is a standard TV control or a specialized smart feature.
- Ensure your TV model is listed as compatible. While universal, specific model compatibility is key for full function.

Specifications

- **Brand:** Easytry123
- **Model:** RAV363 Universal Remote Control
- **Compatible Devices:** JVC LCD LED HDTV TVs (e.g., RM-C325G1A, RM-C3921A, RM-C18501C, RM-C18551C, RM-C1860, RM-C346, RM-C3462A, RM-C3841A, RM-C3101A)
- **Power Source:** 2 x AAA Batteries (not included)
- **Connectivity Technology:** Infrared (IR)
- **Material:** New ABS Plastic
- **Special Feature:** Ergonomic, Replacement remote

Customer Support

For further assistance or inquiries regarding your Easytry123 Universal Remote Control, please contact the seller directly through the platform where the purchase was made. Provide your order details and a clear description of the issue for prompt support.
Please note that this product does not include a separate warranty card or manual beyond this digital guide.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0825QK4WG

More documents and user manuals: **https://manuals.plus/**