Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FFGH2422US

Frigidaire 24-inch 1.9 Cu. Ft. Gas Range (Model FFGH2422US) Instruction Manual

Brand: Frigidaire | **Model:** FFGH2422US

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new Frigidaire 24-inch 1.9 Cu. Ft. Gas Range. Please read all instructions carefully before using the appliance to ensure proper function and safety.

Important Safety Information

- Always follow local codes and ordinances for gas and electrical connections.
- Ensure proper ventilation during operation.
- Do not store flammable materials near the appliance.
- Keep children and pets away from the appliance during operation.
- This appliance is ADA Compliant.

2. Setup and Installation

Unpacking

Carefully remove all packaging materials, tape, and protective film from the range. Retain packaging for future transport if needed.

Location Requirements

The range must be installed in a location that meets all local codes and ordinances. Ensure adequate clearance from combustible surfaces. The appliance requires a 120 Volts electrical connection and a gas supply.

Gas Connection

A qualified technician must connect the range to the gas supply. Ensure all connections are leak-tested before use. This range is designed for natural gas or can be converted to LP gas by a qualified technician using an LP conversion kit (if included or purchased separately).

Electrical Connection

The range requires a properly grounded 120 Volt electrical outlet. A power cord is included. Do not use an extension cord with this appliance.

Leveling the Range

Adjust the leveling legs at the bottom of the range to ensure it is stable and level. This prevents spills and ensures even cooking.



Image: Front view of the Frigidaire 24-inch Gas Range in Stainless Steel, showing its compact design suitable for smaller

kitchens.



Image: The Frigidaire 24-inch Gas Range integrated into a kitchen setting, demonstrating its compact footprint alongside other appliances.

3. Operating Instructions

Cooktop Operation

Your range features four gas burners with continuous cast iron grates. Each burner is controlled by a dedicated knob on the front panel.

1. **To Ignite a Burner:** Push the desired burner knob in and turn it counter-clockwise to the LITE position. You will hear a clicking sound as the igniter sparks. Once the burner ignites, continue to hold the knob in for a few seconds, then turn it to the desired flame size (HI to LO).
2. **Flame Adjustment:** Adjust the flame size according to your cooking needs. A stable blue flame is ideal.
3. **Continuous Grates:** The continuous cast iron grates allow for easy movement of pots and pans between burners without lifting.



Image: Overhead view of the cooktop, highlighting the four burners and continuous cast iron grates for easy pot movement.

Oven Operation

The 1.9 Cu. Ft. oven offers ample space for various cooking tasks, including fitting a 10 lb. turkey. It features 2 racks and 4 rack positions.

1. **Setting Oven Temperature:** Use the oven temperature knob to select the desired temperature. The oven indicator light will illuminate until the set temperature is reached.
2. **Baking:** Place food on the appropriate rack position. For best results, preheat the oven before placing food inside.
3. **Broiling:** Use the broiler function for browning or searing. Follow recipe instructions for proper rack placement and cooking times.
4. **Oven Racks:** The oven includes 2 racks that can be placed in any of the 4 available positions to accommodate different dish sizes.



Image: The oven interior with the door open, showing the two adjustable racks and multiple rack positions.



Image: A 10 lb. turkey roasting inside the oven, demonstrating the oven's capacity.

Storage Drawer

A convenient storage drawer is located beneath the oven. This drawer provides extra space for storing cookware, baking sheets, or other kitchen essentials.



Image: The open storage drawer, illustrating its use for storing various cookware items.

4. Maintenance and Cleaning

General Cleaning

Regular cleaning helps maintain the appearance and performance of your range. Always ensure the appliance is cool before cleaning.

- **Exterior Surfaces:** Use a soft cloth with mild soap and water. For stainless steel surfaces, use a stainless steel cleaner and polish, wiping in the direction of the grain.
- **Control Knobs:** Remove knobs by pulling them straight off. Wash with soap and water, then dry thoroughly before replacing.

Cooktop and Grates

- **Cast Iron Grates:** Remove grates and wash with warm, soapy water. For stubborn stains, a non-abrasive cleaner can be used. Ensure they are completely dry before placing them back on the cooktop.
- **Burner Caps and Bases:** Clean with warm, soapy water. Ensure burner ports are not clogged.

- **Cooktop Surface:** Wipe spills immediately. Use a damp cloth and mild detergent.

Oven Interior

The oven features a self-clean option. Refer to the full user manual for detailed instructions on using the self-clean cycle.

- **Oven Racks:** Remove racks before a self-clean cycle. They can be cleaned manually with warm, soapy water or a mild abrasive cleaner.
- **Oven Door:** Clean the interior and exterior of the oven door with mild soap and water. Avoid harsh abrasives on the glass.

5. Troubleshooting

Before contacting service, review the following common issues and solutions:

Problem	Possible Cause	Solution
Burner does not ignite.	Gas supply off, igniter clogged, power outage.	Check gas valve, clean igniter ports, check power supply.
Oven not heating.	Incorrect temperature setting, power issue, gas supply.	Verify settings, check circuit breaker, ensure gas supply is on.
Uneven cooking in oven.	Improper rack placement, warped bakeware.	Adjust rack position, use flat bakeware.
Storage drawer not closing smoothly.	Obstruction, misaligned.	Remove any items blocking the drawer, check alignment.

6. Specifications

Brand: Frigidaire

Model: FFGH2422US

Installation Type: Freestanding

Fuel Type: Gas

Color: Stainless Steel

Oven Capacity: 1.9 Cubic Feet

Number of Burners: 4

Burner BTU (Right Front): 11,000 BTU

Burner BTU (Right Rear): 5,000 BTU

Burner BTU (Left Front): 9,000 BTU

Burner BTU (Left Rear): 9,000 BTU

Grates: Continuous Cast Iron

Oven Racks: 2 (4 positions)

Control Console: Knob

Voltage: 120 Volts

Item Weight: 123.5 pounds

Product Dimensions (W x D x H): 23.63 x 23.5 x 35.88 inches

Depth with Oven Door Opened 90 degrees: 41.5 inches

Special Features: ADA Compliant, Compact Design, UL Listed

Included Components: Power cord

7. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your appliance or visit the official Frigidaire website. Keep your purchase receipt as proof of purchase for warranty claims.
Protection Plans: Extended protection plans are available for purchase. Options include 3-Year, 4-Year, and Complete Protect plans. Refer to your retailer for details.
Customer Support: For assistance, contact Frigidaire customer service. Contact details can be found in your product documentation.

8. Product Videos

The following videos provide additional information and visual guides for your Frigidaire Gas Range:

Frigidaire 24 in. 1.9 Cu. Ft. Gas Range in Stainless Steel

▶ **Watch video online**
Frigidaire 24 in. 1.9 Cu. Ft. Gas Range in Stainless Steel

Video: An official product video from Frigidaire showcasing the features and benefits of the 24-inch 1.9 Cu. Ft. Gas Range in Stainless Steel.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B082WV4PCN

More documents and user manuals: **https://manuals.plus/**