Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka NEU10AE4

Eureka Airspeed Ultra-Lightweight Compact Bagless Upright Vacuum Cleaner Instruction Manual

Model: NEU10AE4

1. Introduction

Thank you for choosing the Eureka Airspeed Ultra-Lightweight Compact Bagless Upright Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read it thoroughly before first use and keep it for future reference.

The Eureka Airspeed is designed for powerful and effortless cleaning on various surfaces, including hard floors and carpets. Its lightweight and compact design ensures easy maneuverability and convenient storage.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this vacuum cleaner.

- Always unplug the vacuum cleaner from the electrical outlet before cleaning or servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust cup and/or filters in place.
- Store your vacuum cleaner indoors in a cool, dry area.
- Warning: When using the vacuum cleaner, the floor brush may be clogged by hairs and dirt. We recommend cleaning the roller brush and the belt every 2 weeks. Long-term failure to clean may cause malfunction, or even risk of smoke and belt broken.

3. Product Overview

The Eureka Airspeed Ultra-Lightweight Compact Bagless Upright Vacuum Cleaner (Model NEU10AE4) is designed for efficient and convenient home cleaning. Below are the key components and features:

- **Lightweight Design:** Weighs only 7.7 pounds for easy portability and maneuverability.
- **Bagless System:** Features a large-capacity 1.7-liter dust cup for easy emptying and no bag replacement.
- **Washable Filter:** Includes a foam filter that can be rinsed and dried, reducing maintenance costs.
- **Quick Release Handle:** Detachable handle for effortless above-floor cleaning.
- **On-Board Tools:** Comes with a crevice tool and dusting brush that snap onto the vacuum for convenient access.
- **Powerful Suction:** 720-watt motor provides strong suction for dirt and hair on hard floors and carpets.
- **Versatile Cleaning:** Suitable for both hard floors and carpets with a 10.5-inch wide cleaning path.

What's in the Box:



Vacuum Cleaner: The main unit of the Eureka Airspeed.



Dusting Brush & Crevice Tool: Attachments for detailed cleaning.



Washable Foam Filter: A reusable filter for the dust cup.

4. Setup and Assembly

The Eureka Airspeed vacuum cleaner comes mostly pre-assembled. Follow these steps for quick setup:

1. **Attach the Handle:** Insert the handle into the main body of the vacuum until it clicks securely into place. Ensure it is firmly seated.
2. **Connect the Hose:** Attach the flexible hose to the suction inlet on the main body. Make sure both ends of the hose are securely connected to prevent loss of suction.
3. **Store Accessories:** Place the crevice tool and dusting brush onto their designated on-board storage clips on the vacuum.
4. **Power Cord Management:** Wrap the power cord around the cord hooks for neat storage. Release only the necessary length of cord for cleaning.



Image: Eureka Airspeed with crevice tool and dusting brush stored on board.

5. Operating Instructions

General Operation:

1. **Plug In:** Insert the power plug into a suitable electrical outlet.
2. **Power On:** Press the power button located on the vacuum's body to turn it on.
3. **Recline:** Step on the floor nozzle and pull the handle back to recline the vacuum for cleaning.
4. **Vacuuming:** Move the vacuum slowly forward and backward over the area to be cleaned. For heavily soiled areas, repeat the passes.

Above-Floor Cleaning with Attachments:

1. **Detach Handle:** Press the quick-release button on the handle and pull it upwards to detach it from the main unit.
2. **Attach Tool:** Connect the desired attachment (crevice tool or dusting brush) directly to the end of the detached handle or the flexible hose.
3. **Clean:** Use the attached tool to clean upholstery, stairs, corners, or other hard-to-reach areas.
4. **Reattach:** Once finished, remove the attachment and reinsert the handle back into the main unit until it clicks.



Image: Detachable handle used for extended reach cleaning.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your Eureka Airspeed vacuum cleaner. Always unplug the vacuum before performing any maintenance.

Emptying the Dust Cup:

1. **Remove Dust Cup:** Press the release button on the dust cup handle and lift it away from the vacuum.
2. **Empty Contents:** Position the dust cup over a trash can and press the bottom release button to open the lid and empty dirt and debris.
3. **Reattach:** Close the bottom lid securely and place the dust cup back onto the vacuum until it clicks into place.



Image: Demonstrates the easy emptying process of the dust cup.

Cleaning the Washable Filter:

The foam filter should be cleaned regularly, or when suction power decreases. It is recommended to clean the filter every 2 weeks.

1. **Remove Filter:** Open the dust cup and remove the foam filter.
2. **Wash:** Rinse the filter under cold running water until the water runs clear.
3. **Dry:** Allow the filter to air dry completely for at least 24 hours before reinserting it into the dust cup. Do not use a dryer or other heating methods.
4. **Reinstall:** Once completely dry, place the filter back into the dust cup and close it.



Image: Washable filter being rinsed under running water.

Cleaning the Roller Brush and Belt:

It is recommended to clean the roller brush and belt every 2 weeks to prevent clogging and maintain performance. Long-term failure to clean may cause malfunction, or even risk of smoke and belt broken.

1. **Unplug:** Ensure the vacuum is unplugged.
2. **Access Brush Roll:** Turn the vacuum over and locate the brush roll cover. Remove any screws or clips holding it in place.
3. **Clean:** Carefully remove any hair, string, or debris wrapped around the brush roll or belt. Use scissors if necessary.
4. **Reassemble:** Replace the brush roll cover and secure it with screws or clips.

7. Troubleshooting

Before performing any troubleshooting, ensure the vacuum is unplugged from the power outlet.

Problem	Possible Cause	Solution
Vacuum cleaner will not run.	No power supply.	Check power cord, plug into working outlet.
Low suction.	Dust cup full.	Empty dust cup.
Low suction.	Filter clogged.	Clean or replace filter.
Low suction.	Hose or nozzle clogged.	Remove obstruction from hose or nozzle.
Brush roll not turning.	Hair or debris wrapped around brush roll.	Clean brush roll and belt.
Vacuum smells like burning.	Brush roll or belt clogged/damaged.	Immediately unplug. Clean brush roll and belt. If smell persists, contact customer service.

8. Specifications

Feature	Detail
Brand	Eureka
Model Name	Powerful Bagless Upright Vacuum Cleaner Carpet and Floor
Model Number	NEU10AE4
Color	Green
Form Factor	Upright
Special Features	Lightweight, Compact, Bagless, Washable Filter
Filter Type	Foam
Included Components	AirSpeed Vacuum, Dusting Brush, Replacement Filter, Crevice Tool
Is Cordless?	No
Capacity	1.7 Liters
Wattage	720 watts
Hose Length	1.5 Feet

Feature	Detail
Recommended Uses	Hard Floor, Carpet
Product Dimensions	11"L x 11"W x 41"H
Item Weight	7.7 pounds
UPC	810004818668

9. Warranty and Support

For any questions, assistance, or warranty inquiries regarding your Eureka Airspeed vacuum cleaner, please contact our customer service team.

Customer Service: 1-800-282-2886

You can also refer to the officialUser Guide (PDF) for additional information.

© 2025 Eureka. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B083JBZXYS

More documents and user manuals: **https://manuals.plus/**