Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MN67Z

Minolta MN67Z Bridge Camera User Manual

Model: MN67Z

1. Introduction

Thank you for choosing the Minolta MN67Z 20MP FHD Wi-Fi Bridge Camera. This manual provides essential information for setting up, operating, and maintaining your camera to ensure optimal performance and longevity. Please read this manual thoroughly before using your camera.

2. What's Included

Your Minolta MN67Z camera package includes the following items:

- Minolta MN67Z Camera Body
- 16GB SDHC Card (initial inclusion)
- 32GB SDHC Card (bundle inclusion)
- USB Cable
- AC Adapter
- Neck Strap
- Lens Cap
- Rechargeable Lithium-Ion Battery
- CD-ROM (Software/Drivers)
- Camera Case
- Cleaning Kit
- Card Reader



Figure 2.1: Minolta MN67Z Camera and included accessories.

This image displays the Minolta MN67Z camera along with its essential accessories, including the camera body, lens, neck strap, and various bundled items like memory cards, cleaning kit, and card reader.



Figure 2.2: Minolta MN67Z Camera front view.

A front view of the Minolta MN67Z camera, highlighting its prominent lens and compact design.



Figure 2.3: Camera carrying case.

The included black camera carrying case, designed to protect your camera and accessories during transport.



Figure 2.4: SanDisk Ultra 32GB SDHC Memory Card.

A SanDisk Ultra 32GB SDHC memory card, providing ample storage for your photos and videos.



Figure 2.5: Pro Optic Cleaning Kit.

The Pro Optic cleaning kit, containing tools such as a lens brush, air blower, and cleaning solution for maintaining your camera's optics.



Figure 2.6: All-in-one USB Memory Card Reader.

A compact USB memory card reader, allowing for easy transfer of files from your SD card to a computer.

3. Product Overview

The Minolta MN67Z is a versatile bridge camera designed for both amateur and enthusiast photographers. It combines the ease of use of a point-and-shoot with advanced features typically found in DSLR cameras.

Key Features:

- **20 Megapixel CMOS Sensor:** Delivers high-resolution images with excellent detail and color reproduction.
- **67x Optical Zoom:** Provides incredible reach for capturing distant subjects with clarity.
- **Full HD (1080p) Video Recording:** Capture smooth, detailed videos at 30 or 60 frames per second.
- **Optical Image Stabilization:** Minimizes camera shake for sharper photos and steadier videos, especially at high zoom levels.
- **Built-in Wi-Fi:** Enables wireless transfer of photos and videos to smart devices and remote camera control.

- **3-inch Articulating LCD Screen:** Offers flexible viewing angles for various shooting situations.
- **User-Friendly Features:** Includes face, smile, and blink detection, along with multiple scene modes (e.g., Night Portrait, Panorama).

4. Setup Guide

4.1. Battery Installation and Charging

1. Locate the battery compartment cover on the bottom of the camera.
2. Slide the latch to open the cover.
3. Insert the supplied Lithium-Ion battery, ensuring the correct orientation as indicated inside the compartment.
4. Close the battery compartment cover until it clicks securely into place.
5. Connect the camera to the AC adapter using the USB cable. Plug the AC adapter into a power outlet to charge the battery. The charging indicator light will show the charging status.

4.2. Memory Card Insertion

1. Open the battery/memory card compartment cover.
2. Insert the SDHC memory card (32GB recommended) into the card slot with the label facing the correct direction, until it clicks into place.
3. Close the compartment cover.

4.3. Attaching the Neck Strap

Thread the neck strap through the strap lugs on both sides of the camera and secure it according to the instructions provided with the strap. Ensure it is firmly attached to prevent accidental drops.

5. Operating Instructions

5.1. Powering On/Off

Press the **POWER** button located on the top of the camera to turn it on or off.

5.2. Basic Photography

1. **Holding the Camera:** Hold the camera firmly with both hands to minimize shake.
2. **Zooming:** Use the zoom lever around the shutter button to adjust the optical zoom (67x) and digital zoom.
3. **Focusing:** The camera uses Contrast Detection Autofocus. Half-press the shutter button to focus on your subject. The focus frame will turn green when focus is achieved.
4. **Taking a Photo:** Fully press the shutter button to capture the image.

5.3. Video Recording

To record video, switch to video mode (if applicable) or press the dedicated video recording button. Press again to stop recording. The camera records in Full HD (1080p) resolution.

5.4. Wi-Fi Connectivity

The built-in Wi-Fi allows for seamless photo transfer and remote control. Refer to the camera's on-screen menu for Wi-Fi setup instructions. You can connect to a smartphone or tablet using the dedicated Minolta app (if available) to transfer images or use your device as a remote shutter.

6. Maintenance

6.1. Cleaning the Camera

- **Lens:** Use a lens brush or a blower to remove dust. For smudges, use a clean, soft microfiber cloth specifically designed for lenses, along with a small amount of lens cleaning solution. Wipe gently in a circular motion from the center outwards.
- **Camera Body:** Wipe the camera body with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use strong cleaning agents or solvents.
- **LCD Screen:** Use a soft, dry cloth to gently wipe the screen. Avoid pressing too hard.

6.2. Battery Care

- Store batteries in a cool, dry place when not in use.
- Avoid fully discharging the battery frequently to prolong its lifespan.
- If the camera will not be used for an extended period, remove the battery.

6.3. Storage

When not in use, store the camera in its case in a dry, dust-free environment away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Camera does not turn on.	Battery is depleted or not inserted correctly.	Charge the battery fully. Ensure the battery is inserted with correct polarity.
Images are blurry.	Camera shake, incorrect focus, or low light.	Hold the camera steady. Ensure autofocus locks before shooting. Use flash or increase ISO in low light.
Lens does not retract.	Possible obstruction or internal error.	Ensure no debris is blocking the lens. Turn the camera off and on again. If problem persists, contact support.
Wi-Fi connection fails.	Incorrect password, out of range, or app issue.	Verify Wi-Fi password. Move closer to the connected device. Restart camera and smart device.
Battery drains quickly.	Frequent use of Wi-Fi, flash, or continuous shooting.	Reduce use of power-intensive features. Carry a spare charged battery.

8. Specifications

Feature	Specification
Model Name	MN67Z
Photo Sensor Resolution	20 MP
Optical Zoom	67x
Video Resolution	1080p (Full HD)

Feature	Specification
Image Stabilization	Optical
Display Type	3-inch Articulating LCD
Connectivity Technology	USB, Wi-Fi
Supported File Format	JPEG, RAW
Memory Storage Capacity	32 GB (SDHC)
Battery Type	Lithium Ion
Item Weight	3.98 Pounds
Dimensions (approx.)	6.4 inches (Height)

9. Warranty and Support

9.1. Warranty Information

The Minolta MN67Z camera comes with a Limited 1-Year Manufacturer Warranty. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

9.2. Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Minolta customer support. Refer to the contact information provided in your product packaging or visit the official Minolta website for the most up-to-date support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B083JKH8NF

More documents and user manuals: **https://manuals.plus/**