Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

66 Audio Sport2 Wireless

66 Audio Sport2 Wireless Headphones User Manual

Model: Sport2 Wireless

Introduction

Thank you for choosing the 66 Audio Sport2 Wireless Headphones. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it thoroughly to ensure optimal performance and longevity of your headphones.
The Sport2 Wireless Headphones feature Bluetooth 5.0 technology, HD stereo sound, a noise-cancelling microphone, and a lightweight, foldable design optimized for sports and active lifestyles. Enjoy up to 25 hours of continuous music playback.

What's in the Box

- 66 Audio Sport2 Wireless Headphones
- USB Charging Cable

Setup

1. Charging the Headphones

Before first use, fully charge your Sport2 Wireless Headphones. Connect the supplied USB charging cable to the charging port on the headphones and to a USB power source (e.g., computer, wall adapter).



Image: Side view of the Sport2 Wireless Headphones, highlighting the charging port and control buttons.

The LED indicator will show charging status. Once fully charged, the indicator will change (refer to the LED indicator section for details).

2. Powering On/Off

- **To Power On:** Press and hold the Power button until the LED indicator lights up and you hear an audible prompt.
- **To Power Off:** Press and hold the Power button until the LED indicator turns off and you hear an audible prompt.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "66 Audio Sport2 Wireless" from the list of found devices.
5. Once paired, the LED indicator will flash blue slowly, and you will hear a confirmation tone.



Image: Close-up of the right ear cup, showing the main control panel with the 66 Audio logo and surrounding buttons.

Note: If pairing fails, power off the headphones and repeat the steps. The headphones will automatically attempt to reconnect to the last paired device when powered on.

Operating Instructions

Controls Overview



Image: Detailed view of the right ear cup, illustrating the layout of the control buttons for playback, volume, and calls.

- **Power/Multi-function Button (Center 66 Logo):** Power on/off, Play/Pause, Answer/End Call.
- **Volume Up (+):** Increase volume.
- **Volume Down (-):** Decrease volume.
- **Next Track (>|):** Skip to the next song.
- **Previous Track (|<<):** Go to the beginning of the current song or previous song.

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press the Next Track button once.
- **Previous Track:** Press the Previous Track button once.
- **Volume Adjustment:** Press the Volume Up (+) or Volume Down (-) buttons.

Phone Calls

- **Answer Call:** Press the Multi-function button once when a call comes in.
- **End Call:** Press the Multi-function button once during a call.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the Multi-function button.

Wearing the Headphones

The Sport2 Wireless Headphones are designed for a secure and comfortable fit, especially during physical activity. Place the ear cups over your ears and adjust the neckband for a snug fit around the back of your head.



Image: A person wearing the Sport2 Wireless Headphones, demonstrating the over-ear and neckband design during an outdoor activity.



Image: A woman smiling while wearing the Sport2 Wireless Headphones, showcasing their comfortable and discreet fit.

Maintenance and Care

- **Cleaning:** Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.
- **Water Resistance:** The headphones are water-resistant. Avoid submerging them in water or exposing them to heavy rain for extended periods. Dry thoroughly if they get wet.
- **Battery Care:** To preserve battery life, charge the headphones regularly, even if not used frequently. Avoid extreme temperatures.



Image: The Sport2 Wireless Headphones shown in their folded configuration, ready for compact storage.

Troubleshooting

No Power

- Ensure the headphones are fully charged. Connect to a power source and check the charging indicator.

Cannot Pair with Device

- Make sure the headphones are in pairing mode (LED flashing red and blue alternately).
- Ensure Bluetooth is enabled on your device and it is within 10 meters (33 feet) of the headphones.
- Try turning off and on both the headphones and your device's Bluetooth.
- If previously paired, try "forgetting" the device on your phone's Bluetooth settings and re-pairing.

No Sound or Low Volume

- Check the volume levels on both the headphones and your connected device.
- Ensure the headphones are properly paired and connected.
- Try playing audio from a different application or device to rule out source issues.

Poor Sound Quality or Intermittent Connection

- Move closer to your connected device to reduce interference.
- Avoid obstacles between the headphones and your device (e.g., walls, large metal objects).
- Ensure there are no other strong wireless signals interfering (e.g., Wi-Fi routers, other Bluetooth devices).

Specifications

Feature	Detail
Brand	66 Audio
Model Name	Sport2 Wireless

Feature	Detail
Color	Black and Red
Ear Placement	On Ear
Form Factor	On Ear
Noise Control	Active Noise Cancellation
Bluetooth Version	5.0
Bluetooth Range	10 Meters
Battery Life	Up to 25 Hours (Music Playback)
Standby Time	400 Hours
Charging Cable	USB Charging Cable (Included)
Microphone	Built-In Noise Cancelling Microphone
Sound Quality	HD Stereo Sound
Control Type	Touch Control
Frequency Range	20 Hz to 20,000 Hz
Water Resistance Level	Water Resistant
Additional Features	Fast Charging, Foldable, Neckband Design, Lightweight, Sports & Fitness Optimized
Compatible Devices	Smartphones, Tablets, Laptops, Desktops, Gaming Consoles, Smart Speakers
Enclosure Material	Velvet
UPC	766234932615
ASIN	B083LLLB81

Warranty Information

The 66 Audio Sport2 Wireless Headphones come with an**18-Month Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

Support

For further assistance, technical support, or warranty inquiries, please refer to the official 66 Audio website or contact their customer service directly.
Note: Product specifications and features are subject to change without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B083LLLB81

More documents and user manuals: **https://manuals.plus/**