Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sandoo B0841FPJB3

Sandoo 1800W Portable Induction Cooktop User Manual

Model: B0841FPJB3

Introduction

Thank you for choosing the Sandoo 1800W Portable Induction Cooktop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance generates heat during use. Proper precautions must be taken to prevent the risk of burns, fires, or other damage to persons or property.
- Ensure adequate ventilation around the cooktop during operation.
- Only use induction-compatible cookware.

Product Overview

Familiarize yourself with the components of your Sandoo Induction Cooktop.



Figure 1: Front view of the Sandoo Induction Cooktop, showing the ceramic glass surface and the integrated control panel at the bottom.



Figure 2: Angled view of the Sandoo Induction Cooktop, highlighting its compact and portable design.

Control Panel Features:

- **Power Button:** To turn the unit on or off.
- **Temperature/Power Adjustment Buttons:** To increase or decrease heat settings.
- **Timer Button:** To set the cooking timer.
- **Display Screen:** Shows temperature, power level, or timer settings.

Setup

1. **Unpacking:** Carefully remove the cooktop from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the induction cooktop on a dry, stable, heat-resistant, and non-metallic surface. Ensure there is at least 4-6 inches (10-15 cm) of clear space around all sides for proper ventilation. Do not place near water sources or heat-sensitive materials.
3. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet. Ensure the outlet is properly grounded.

4. **Cookware Check:** Ensure you have induction-compatible cookware. Compatible materials include cast iron, enameled iron, steel, and stainless steel with a magnetic bottom. Non-compatible materials include glass, ceramic, copper, aluminum, and non-magnetic stainless steel. A simple magnet test can confirm compatibility: if a magnet sticks to the bottom of your pot or pan, it is induction-compatible.

Operating Instructions

1. Powering On/Off

- To turn on, press the **Power Button**. The display will illuminate.
- To turn off, press the **Power Button** again. The unit will power down.

2. Selecting Temperature or Power Setting

- After powering on, place an induction-compatible pot or pan with food on the cooktop surface.
- Use the **Temperature/Power Adjustment Buttons** to select your desired heat level. The cooktop offers 15 settings for precise control.
- The display will show the selected temperature or power level.

3. Using the Timer Function

- While cooking, press the **Timer Button**.
- Use the **Temperature/Power Adjustment Buttons** to set the desired cooking time.
- The timer will count down, and the cooktop will automatically turn off once the set time expires.

4. Cookware Detection

The cooktop features automatic cookware detection. If no compatible cookware is placed on the surface, or if it is removed during operation, the unit will display an error code and automatically shut off after a short period. This is a safety feature.

Maintenance and Cleaning

- Always unplug the cooktop from the power outlet and allow it to cool completely before cleaning.
- Wipe the ceramic glass surface with a damp cloth and a mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic cooktops.
- Do not use abrasive pads, scouring powders, or harsh chemicals, as these can scratch or damage the surface.
- Clean the control panel with a soft, damp cloth. Do not allow water to enter the control panel area.
- Ensure the ventilation openings on the bottom and sides of the unit are clear of dust and debris. Use a soft brush or vacuum cleaner to gently clean them.
- Never immerse the cooktop in water or any other liquid.
- Store the cooktop in a dry place when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Cooktop does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure power cord is securely plugged in. Check circuit breaker. Try a different outlet.

Problem	Possible Cause	Solution
Cooktop turns on but does not heat.	Incompatible cookware; no cookware present; cookware not centered.	Use induction-compatible cookware. Place cookware on the center of the cooking zone.
Display shows an error code (e.g., E0, E1).	Specific error condition (e.g., no pot, overheating).	Refer to the specific error code in the full manual (if available) or contact customer support. Often indicates no pot, or an internal issue. Try resetting by unplugging for 5 minutes.
Cooktop makes a humming or buzzing noise.	Normal operation with certain cookware; cooling fan.	This is normal for induction cooktops, especially with multi-layered or thinner-bottomed pots. The cooling fan also produces a sound.

Specifications

Brand	Sandoo
Model	B0841FPJB3
Power Source	Induction (1800W)
Heating Elements	1
Controls Type	Push Button
Burner Type	Radiant (Note: The product operates on induction technology.)
Material	Stainless Steel (housing), Ceramic Glass (cooking surface)
Item Weight	5.53 pounds
Package Dimensions	16.42 x 12.68 x 3.15 inches
UPC	795787634066

Note: The product is an induction cooktop, despite a specification listing "Burner type: Radiant". Induction technology uses electromagnetic fields to heat cookware directly.

Warranty and Support

For warranty information, technical support, or customer service inquiries, please refer to the warranty card included with your product or visit the official Sandoo website. Please have your model number (B0841FPJB3) and purchase date available when contacting support.
For further assistance, you may also refer to the product page on Amazon:Sandoo Induction Cooktop on Amazon

© 2023 Sandoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0841FPJB3

More documents and user manuals: **https://manuals.plus/**